

This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

Usage guidelines


Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.

We also ask that you:

- + *Make non-commercial use of the files* We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.
- + Refrain from automated querying Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.
- + *Maintain attribution* The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.
- + *Keep it legal* Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.

About Google Book Search

Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at http://books.google.com/

















PRINTED BY BALLANTYNE AND COMPANY
EDINBURGH AND LONDON

MECHANIC'S FRIEND:

A COLLECTION OF

RECEIPTS AND PRACTICAL SUGGESTIONS

RELATING TO

AQUARIA, GLUES. PYROTECHNY. HOROLOGY, BRONZING, RAILWAYS, CEMENTS, LACQUERS, SOLDERS, DRAWING, LOCOMOTIVES, STEAM-ENGINE. MAGNETISM, TELEGRAPHY METAL-WORKING, TAXIDERMY, TELEGRAPHY. DYES, RLECTRICITY, GILDING, MODELLING. VARNISHES. GLASS-WORKING, PHOTOGRAPHY, WATERPROOFING.

AND

MISCELLANEOUS TOOLS, INSTRUMENTS, MACHINES, AND PROCESSES

CONNECTED WITH THE CHEMICAL AND MECHANICAL ARTS.

With Aumerous Diagrams and Woodcuts.

EDITED BY

WILLIAM E. A. AXON, M.R.S.L., F.S.S.
MEMBER OF THE LITERARY AND PHINOSOPHICAL SOCIETY OF MANCHESTER, ETC. ETC.

LONDON:
TRÜBNER & CO., LUDGATE HILI.
1875.

[All rights reserved.]

KLM

T.49 A9

•

PREFACE.

THE present differs in some important particulars from the many "receipt-books" which have preceded it. It is the result, not so much of individual judgment as of the action of a number of "friends in council," whose varied practical experiences have inspired the instructions and hints it contains, The articles of which the volume consists have already appeared in the English Mechanic, a wellknown periodical, in whose pages lovers of science, practical mechanics, chemists, photographers, &c. &c., have for years past been in the habit of affording mutual help to each other. Hence almost every item of information in the present volume is a statement of a difficulty experienced by one person, and responded to by another, who has already met and overcome it. This fact will stamp the book with a practical value in the eyes of those who know how much more important such individual experience is than any mere theory or tradition. The workman

who looks here for help will know that he is listening to those who have been in his own circumstances, and who by perseverance, it may be, in spite of repeated failures, have at last found out the method they now offer to him.

There is a large and rapidly-increasing class of amateurs who devote some of their leisure to working in the mechanical and other branches of practical science. These persons will, it is hoped, in this volume find many things to save them trouble and speed them on their way. Whether they want to skeletonize the leaf of a plant, or to construct a steam-propeller for a model boat; to make a skyrocket or an electric clock; an artificial magnet or a photographic handkerchief, they will not look in vain. The tendency to the traditional in every trade renders it probable that, with persons of this class, many improved processes will originate. The amateur workman looks at things with a fresher eye than one who has come to regard the processes learned in youth as the finale of perfection. Discoveries sometimes arise from the extension of principles and methods that have proved successful in one department to other spheres of operation. Bearing this in mind, it is perhaps not to be regretted that so few men adopt as "hobby" the pursuits by which their living is obtained. The joiner whose evenings are given up

to clockmaking, the printer whose holiday-time is spent in photography, are not to be discouraged as perverse. They bring trained intelligence to bear upon fresh fields, and the stoutest resister of outside suggestions in his *trade* may be the most daring experimenter in relation to his *hobby*. Both classes will, it is hoped, find something to suit them in the following pages.

In preparing for the press the contributions of so many individuals, a considerable amount of revision and condensation has been necessary, and every possible care has been taken to exclude matter already easily accessible.

The topics have, as far as possible, been grouped together according to their mutual relationship; but as all such attempts at classification are in their very nature defective, this arrangement has been supplemented by a copious alphabetical index.

٠			
	·		
		·	
		·	

TABLE OF CONTENTS.

							PAGE
METRIC SYSTEM	•	•	•	•	•	•	1
MISCELLANEOUS	TOOLS,	INSTRU	iments,	AND	PROCES	SES	3
CEMENTS AND G	LUES	•	•		.•		79
VARNISHES AND	LACQUI	ERS			•		83
SOLDERS AND SO	LDERIN	rG .			•		90
METALS AND ME	TAL-WO	RKING	•	•			92
STEAM ENGINE	•		•				102
RAILWAYS AND	LOCOMO	TIVES	•		•		130
FIRE-ARMS .	•	•	•				148
HOROLOGY ,	•	•					150
GLASS .	•	•	•				175
WOOD-WORKING			•				179
HOUSE AND GAR	DEN					•	184
DRAWING AND M	(ODELLI	NG					197
PHOTOGRAPHY			•				203
MUSICAL INSTRU	MENTS	•			•		228
TAXIDERMY .	•		•				234
PLANT PRESERVI	NG	•					238

								PAGE
AQUARIA	•	•	•	•	•	•	•	240
MISĆELLA	NEOUS	CHEMIC	AL PRO	CESSES	AND	COMP	osi-	
TIONS	s .	.•	•	•		•		246
LIGHTING	•	•	•	•	•		•	262
DYES	•	•	•	•	•	•	•	265
WATERPR	OOFING		•	•	•	•	•	268
GILDING .	AND BI	RONZING	•	•	•		•	270
PYROTECH	INY	•	•	•	•	•	•	289
ELECTRIC	ITY, M	AGNETISI	d, AND	TELEG	RAPH	Υ.	•	295
INDEX			•	•				333

THE MECHANIC'S FRIEND.

French Weights and Measures, and their English Equivalents.—The very general use of the metrical system in scientific investigations renders a brief statement of it indispensable. The following will be found sufficient for all ordinary purposes:—

I.—WEIGHTS.

						English Troy Weight.				
						lbs.	oz.	dwts.	grains.	
Bar (cubic me	re of	wate	r) .		=	5673	6	3	8	
Myriagramme					=	26	9	IO	20	
Kilogramme					=	2	8	3	2	
Hectogramme					7		3	4	7.4	
Decagramme					=		_	6	10'34	
GRAMME .					=				15'434	
Decigramme					=				1.2434	
Centigramme					=				0 15434	

II.-LINEAR MEASURES.

			•	French Foot.		English Foot.
Quadrant of meridian			=	30784440	_	32809167
Degree centesimal .			=	307844.4	=	328091.67
Myriametre			=	30784 44	=	32809.167
Kilometre			=	3078.444	=	3280 9167
Hectometre			=	307.8444	=	328 [.] 09167
Decametre			=	30.78444	. =	32.809167
METRE			=	3.078444	=	3.2809167
						A

					French Lines.		English Lines.
Decimetre		•		=	44:3296	=	47:2452
Centimetre		•	•	=	4.43296	=	4.72452
Millimetre	•	•	•	=	0.443296	=	0.472452

III.-SQUARE MEASURES.

			III.—SQUARE MEAS	UKES	5 .
			French Square Feet.		English Square Feet.
Myriare	•	=	9476817:46113	=	10764414:3923
Kilare	•	=	947681 746113	=	1076441:43923
Hectare		=	94768.1746113	=	107644:143923
Decare		=	9476 [.] 81746113	=	10764:4143923
Are		=	947 [.] 681 7 46113	=	1076:44143923
Deciare	•	=	94.7681746113	=	107.644143923
Centiare	•	=	9°47681746113	=	10.7644143923
			French Square Inches	.	English Square Inches.
Square de	cime	tre	= 13.646617	=	15.200762
			French Square Line	English Square Lines.	
Square centimetre			= 19.651134	=	22:321088
Square m	illime	tre	= 0.19621134	=	0.22321088

IV .- SOLID MEASURES.


The Stere, being a cubic metre, it follows that the Decastere is equal to the Myrialitre.

Stere = Kilolitre.
Decistere = Hectolitre.

V.-MEASURES OF CAPACITY.

Myrialitre Kilolitre (or cubic metre) Hectolitre	French Cubic Feet. = 291.738519 = 29.1738519 = 2.91738519	English Cubic Feet. = 353'1714695 = 35'31714695 = 3'531714695
Decalitre LITRE (cubic decimetre) Decilitre	French Cubic Inches. = 504'124160 = 50'412416 = 5'0412416	English Cubic Inches = .610.2802806 = 61.02802806 = 6.102802806
Centilitre	French Cubic Lines. = 871.126926	English Cubic Lines. = 1054.5643249

Hand Drilling-Machine. - The following machine answers



for all work, and is said to be nearly equal to steam power.

The machine is made by E. & H. Widdall, of Beverley, Yorkshire. I is a small handwheel; 2, a pair of bevel-wheels; 3 is a stationary collar for pressure-screw; 4, the sliding-racks for lowering the drill; 5, centre of drill bolted to shaft. Fig. 2 is an end view of small wheel.

Cork-Boring.—There are three sorts of tools for boring cork: the French (Danger's), a sharp-edged steel cylinder, fixed in a handle, like a bradawl, with the cylinder partly cut away, to get the cut piece out. Mohr's way is to use a tin tube, with a milled rim at the handle end, and the pieces of cork push each other out at the top, as in a punch. The objection to this

the cheapest method) is the welt, which can hardly be

avoided in tin tubes. Griffin prefers a brass tube filed to an edge. All these tools should be oiled, and turned round while cutting, or they will not make a clean cut; when the tool is nearly through, a piece of cork should be placed at the back of the piece you are cutting. The pieces cut out and uninjured, and will do for corking small bottles.

Rose-Bit for Lathe.—This rose-bit may be used in the




lathe or drilling-machine. As a countersink it works well. The nose is formed

by filing away to a little below the centre, as shown.

Renovating Files.—The file is to be first cleansed from a foreign matter, and then dipped in I part of nitric acid, 3 parts of sulphuric acid, and 7 parts of water, the time of immersion will be according to the extent the file has been worn, and the fineness of the teeth, varying from five seconds to five minutes; on taking it out of the mixture, wash in water, then dip in milk of lime, and then wash off the lime, dry by a gentle head and rub over equal parts of olive oil and turpentine, and finally brush over with powdered coke. It is stated that a new file is improved by a few seconds' immersion, and also that rasps may be renovated in the same way.

To Draw Spirals.—A simple method of drawing spirals is:

AA is a piece of wood of any length, fitted near one end
with a pencil B; CC is a string fixed at either end of the



wood, and passing once round the roller D; E is placed at the centre, from which the spiral is to be described; F is an extra point to prevent turning round. As AA is

turned round the roller D, the pencil will be moved towards or away from it, and so a spiral will be described, the pitch of which may be altered by varying the diameter of the roller D.

Quickening Curves.—Spirals, or quickening curves, as they are called, are made as follows:—

Draw a straight line of any length; divide this line into any number of equal parts, as shown in cut. Next divide one of

these parts into halves, as at 0; now divide with the compasses (placing one foot upon 0), strike the semicircle 1 2. Now place the compasses upon 1, extending them to 2, and strike the semicircle 2 3, but on the opposite side of the line from the other



semicircle. Now return and place the foot of the compasses on o, extending them to 3, and upon the opposite side, and again strike the semicircle 3 4. Now return again to 1 and so on, alternately placing the compasses on o and 1, striking the curve on alternate sides of the line.

Measuring Heights of Towers, &c.—Various modes are in operation, but the following will be found simple and practical:

Choose that side of the tower around which the ground is most level. Should an entirely level plain not be obtainable,

allowance must be made for the inequalities of the surface.

At some distance from the tower place level on the ground a small pocket mirror, C, and recede backwards from it until the top of the tower E is seen reflected in the centre of the mir-



ror. Then, as experimenter's height BA is to his distance from mirror C, so is the distance CD to height of tower.


If, instead of a mirror, a trough of mercury, or even a pool of water, be employed for the reflection, the height of the

tower may be correctly ascertained, provided the base of it and the medium of reflection be on the same level. Should it not be possible to get a level base, the difficulty is got over when the relative heights of the tower base and the water or mercury are known, such difference having only to be added or subtracted when the water or mercury is below or above the tower's base, as the case may be.

Another method is this: Measure out the base line AB,



ing made the other end of the line fast at B once set, multiply



erect a sliding staff, similar to the sketch at C, one-twentieth of the length of the base line from B. which will be ten feet. Then site his staff line BD in a direct line with E. by raising or lowering the top part of the staff, as the case may be. Havthe length of BD by 20-that is, the number of times the base line is divided into, which will give the exact length of the hypothenuse. Then the square root of the difference of the squares of the hypothenuse and the base is the height of the perpendicular. The sketch F of the sliding staff will explain itself.


200 feet long, then

Distances: How to Ascertain .- The following plan, or

modification of other plans, in use by architects and others, will be found simple in application:—

First obtain a wooden tooth-powder box of the size shown by the circle, find the centre by a pair of compasses; then

draw the line A a little below the centre , as shown. Next mark on the line AB at an angle of $22\frac{1}{2}^{\circ}$, as shown. Next get two slips of silvered lookingglass of good quality, but on thin glass of the respective sizes, B and C D, and nearly as deep as the box shown on section. Fix the piece AB



by small blocks of wood glued or cemented on each side, and take care to have them as upright as possible.

It will be perceived the glass AB is to be permanently fixed at the angle shown. Then take the other piece CD, and cut a slight notch in the inner rim of the box so as to serve for a stay, and also as a centre for this to turn upon A at the back of this glass. Cement a thick piece of shoe-sole leather, about $\frac{3}{8}$ in. square, with a hole bored entirely through. In the side of the box opposite this, make a corresponding hole, and insert a screw which will embrace the leather at the back of the glass. The whole object of this is to adjust the glasses truly, as the angle before given cannot be got sufficiently accurate without subsequent adjustment.


Having thus fixed your glasses, cut two gaps entirely down the box, as shown at RV, and in a line with R, and perpendicular to A , cut a smaller slit F for the eyehole. Now scrape away neatly the silver from the upper portion of AB down to half its depth, as shown in section, and sufficiently wide to admit of seeing each side of the hole R, when the eye is applied to the slit. Blacken those portions of the glass not visible from the eyehole, as they only tend to procure false

images, about two thirds of C, and may also be blackened from D to about F.

The instrument now merely requires to have the lid put on premising that you have first blackened every portion of the inside of it as well as the box.

To adjust the instrument proceed as follows:—

Get three sticks or laths about 3 feet long, find a tolerable



level piece of ground, pain A, then with a tape of rod measure 24 ft., and pain B; then from B with 46 ft. on the tape, and using B as a centre for the ring to work upon, strike the arc EF on the ground. Againstreturn to A, and with a radius of 32 ft. cut the former arc with another arc GH, and at the front of intersections.

put in your third stick. You have now a true square to work upon.

Now measure off on the line AC 24 ft., and replace the stake C at that distance. You will then have a square whose sides are equal, and whose angle is a right angle.

Place the instrument on the stick B, and look through the upper part of the glass AB, so as to see the stake A. Next turn the screw O more or less until the stake C is just in a line with the stake A, the one seen by direct vision, the other by double reflection. Your instrument is now adjusted. Thenglue similar blocks of wood on each side to retain it in place, as in the case of AB.

To use it, proceed as follows:-

For vertical heights, ascertain the height of your own eye, and mark upon the building or spire this height, either as a line or a white chalk dot, walk backwards, still looking directly through the instrument until you see its summit, or any part you wish to measure, brought down on the said dot by reflection. You have only then to measure the distance of your own feet to the base of the spire, and add the height of your eye to it, and you have the perpendicular height you require.

For horizontal distances, say a tree C, on the opposite side C of the river on which you are standing, fix a

square or cross staff at A, and put a staff in the direction of the square at B; then, with the instrument in your hand, move backwards, looking the control in a direct line until you see the reflected image of

at A \square in a direct line until you see the reflected image of C corresponding with A \square . Then measure the distance AB, and this is equal to CA.

This instrument is, of course, held horizontally for the latter, and edgeways, or vertically, for perpendiculars.

Sharpening Edge Tools.—The simplest mode of sharpening an edge tool is to place the cutting part in water containing 1-20th of its weight of sulphuric or muriatic acid; after allowing it to remain there for half an hour, wipe it gently with a piece of soft rag, and in a few hours set in on an ordinary strop. This method, not generally known, is by no means new; the effect of the acid is to supply the place of the cilstone, but uniformly corroding the entire surface, so that nothing but a good polish is afterwards needed.


To Harden Axles.—To harden pattern axles with the prussiate of potash of commerce, make the work red hot, then put on plenty of potash, and plunge in water; or you may get some burnt leather or bone-dust. You can put a lot of axles into a wrought-iron box; put the bone-dust or leather-cinders in, ram down well, put some clay over the top, build a brick fire round the box for about three hours, then pull out, and rinse in cold water; this is the case-hardening process: you will find potash the quickest way.

To Temper Drills and Taps.—Heat them first to a bloodred, and then quench (this gives them extreme hardness, as well as brittleness), then, when dry, pour oil on them, and hold them in the fire, fixed in a piece of iron, till the oil blazes off, withdrawing very frequently to watch the process. This leaves a hardness that the file will just touch. images, about two thirds of C, and may also be blackened from D to about F.

The instrument now merely requires to have the lid put on, premising that you have first blackened every portion of the inside of it as well as the box.

To adjust the instrument proceed as follows:-

Get three sticks or laths about 3 feet long, find a tolerably



level piece of ground, put in A, then with a tape or rod measure 24 ft., and put in B; then from B with 40 ft. on the tape, and using B as a centre for the ring to work upon, strike the arc EF on the ground. Again return to A, and with a radius of 32 ft. cut the former arc with another arc GH, and at the front of intersection

put in your third stick. You have now a true square to work upon.

Now measure off on the line AC 24 ft., and replace the stake C at that distance. You will then have a square whose sides are equal, and whose angle is a right angle.

Place the instrument on the stick B, and look through the upper part of the glass AB, so as to see the stake A. Next turn the screw O more or less until the stake C is just in a line with the stake A, the one seen by direct vision, the other by double reflection. Your instrument is now adjusted. Then glue similar blocks of wood on each side to retain it in place, as in the case of AB.

To use it, proceed as follows:-


For vertical heights, ascertain the height of your own eye, and mark upon the building or spire this height, either as a line or a white chalk dot, walk backwards, still looking directly through the instrument until you see its summit, or any part you wish to measure, brought down on the said dot by reflection. You have only then to measure the distance of your own feet to the base of the spire, and add the height of your eye to it, and you have the perpendicular height you require.

in any other part but that which is required hard, and it will then keep straight in hardening; at least it will keep very much truer than if it were heated in the midst of the ignited fuel of the fire.

Fire-Fan.—This fan may be applied to any ordinary firegrate, and it is almost impossible to imagine its power. A

welding heat on inch iron in a common fire-grate may be obtained by its means.

The sides are formed of two pieces of sheet iron, the bottom of wood, length I ft. 3 in.; the nose may be made 6 in. long, 2 in.; height 61 in. is a wheel turning on a loose spindle. with lock - nuts for the end, to make a centre for the fanspindle: B is a sheet-brass pedestal moving on a pin, with a spring at the



bottom to keep the belts in tension; C is a bit of iron, with three arms riveted on to the side—the centre takes the spindle H; D is a riveted arm to admit a large hole being made in the side, and to take a set screw for the other end of the fanspindle; E the fan; FGI are wheels to increase the revolutions of the fan.

Hardening and Tempering Tools and Weapons.—The colour and temperature required in hardening the above-mentioned articles are as follows: For very soft temper, 630° Fah., colour greenish blue; pale blue, 610° Fah., for saws, the teeth of which are set with pliers; blue, 590° Fah., for

large saws; dark blue, 570° Fah., for small fine saws; dark purple, 550° Fah., for soft swords and watch-springs; light purple, 530° Fah., for ordinary swords and watch-springs; very pale purple, 520° Fah., for table-knives; brown yellow, 500° Fah., for adzes and plain irons; clay yellow, 490° Fah., for chisels and shears; dark straw, 470° Fah., for penknives; dark yellow, 470° Fah., for razors, &c.; pale straw, 430° Fah., for lancets, &c.


On Grindstones. — Discard every contrivance for fixing tools on the grindstone; they are one and all eminently unpractical. A grindstone will not do nice work unless it is kept true, and fixing the tool against it will of course wear it away unevenly. Tools should always be traversed across the face of the stone, and when a flat surface is to be ground by a circular stone, it is clear that this traverse must not be exactly straight across it, or the bevel will be hollow. A very slight hollow is perhaps rather an advantage than otherwise in such tools as chisels and plane-irons for wood; but there are numerous cases where the face should be ground as flat as possible. This, as just stated, cannot be accomplished by keeping the tool fixed against the stone. Turning-gouges, again, must be continually swept round in a semicircle on the stone if the proper form is to be obtained; and, whatever the tool may be, it should be continually traversed if the figure of the stone is to be preserved, which is a matter of the first importance where accuracy in the angles of the edges is aimed at. true that some workmen have a knack of producing wonderful edges on stones that run like eccentrics; but this is a rare gift, and the bad state of the stones in many large workshops has much to answer for in the very indifferent character of the metal-turning to be found in them. Where all run to one stone, few take any care of it, and it becomes almost a practical impossibility to grind up a slide-rest tool with anything like the accuracy required for first-class toolwork. Regular grinders, however, know the value of a true stone, and are very careful in keeping them so. A true-running stone with a good face will make the workman independent of any rests and holders beyond his own arms and hands. that goniostats are used for very fine and delicate tools where extreme accuracy of form is essential; but these are generally

in any other part but that which is required hard, and it will then keep straight in hardening; at least it will keep very much truer than if it were heated in the midst of the ignited fuel of the fire.

Fire-Fan.—This fan may be applied to any ordinary fire-grate, and it is almost impossible to imagine its power. A

welding heat on inch iron in a common fire-grate may be obtained by its means.

The sides are formed of two pieces of sheet iron, the bottom of wood, length 1 ft. 3 in.; the nose may be made 6 in, long, breadth in.; height 6½ in. is a wheel turning on a loose spindle. with lock-nuts for the end, to make a centre for the fanspindle; B is a sheet-brass pedestal moving on a pin, with a spring at the



bottom to keep the belts in tension; C is a bit of iron, with three arms riveted on to the side—the centre takes the spindle H; D is a riveted arm to admit a large hole being made in the side, and to take a set screw for the other end of the fanspindle; E the fan; FGI are wheels to increase the revolutions of the fan.

Hardening and Tempering Tools and Weapons.—The colour and temperature required in hardening the above-mentioned articles are as follows: For very soft temper, 630° Fah., colour greenish blue; pale blue, 610° Fah., for saws, the teeth of which are set with pliers; blue, 590° Fah., for

large some tack ince. For Fun, for small fine some; dak
pumpe. 1907 Fall, for soft somes unit words-some; light
pumpe. 1907 Fall, for military sources and words-sorings;
very pace pumpe. 1907 Fall, for mine-sources instant wolden,
1907 Fall, for stores and piant runs. may relow, 1907 Fall,
for closely and closures itak some, 1907 Fall, for perhapses;
large pellow. 1907 Fall, for manys, for, pale some, 1907 Fall,
for lances, in.

Or Occasiones - Listeri ever mentiones for fixing wis in the gradiente: they are me unit all eminently asproduci. A gracistane will not in mer work unless it is kept true, and fixing the real persons I will of mourse were it away mercair. This should always be inversel across the face of the stone, and when a flat surface is to be ground by a circular wine, it is clear that this traverse must not be exactly straight action in or the best will be hollow. A very slight hollow is perhaps racher an advantage than otherwise in such tools as chinele and plane-irons for wood: but there are numerous cases where the face should be ground as flat as possible. This, as just stated, cannot be accomplished by keeping the Ved fixed against the stone. Turning-gouges, again, must be continually swept round in a semicircle on the stone if the proper form is to be obtained; and, whatever the tool may be, it should be continually traversed if the figure of the stone is to be preserved, which is a matter of the first importance where accuracy in the angles of the edges is aimed at. It is true that some workmen have a knack of producing wonderful edges on stones that run like eccentrics; but this is a rare gift, and the had state of the stones in many large workshops has much to answer for in the very indifferent character of the metal turning to be found in them. Where all run to one stone, few take any care of it, and it becomes almost a practical impossibility to grind up a slide-rest tool with anything like the accuracy required for first-class toolwork. Regular grinders, however, know the value of a true stone, and are very careful in keeping them so. A true-running stone with a good face will make the workman independent of any tests and holders beyond his own arms and hands. that gonloatats are used for very fine and delicate tools where Paliente accuracy of form is essential; but these are generally ground on laps running horizontally and presenting a plane grinding surface.

For amateurs' use nothing is better than a treadle grindstone about 20 in. or 24 in. in diameter; and if the tools are always traversed on it, and it is never allowed to lie in—or even over—water, it may be reduced 2 in. or 3 in. diameter by honest work, before it requires turning up again; and the operator will find, that when he has accustomed himself to grind true by hand alone, he will seldom want even a rest, and would certainly never think of spoiling his stone by using such an awkward and unpractical contrivance as a fixed holder.

Saw-Benches.—The following plan of a saw-bench will suit any possessor of a lathe. The box ABC rests on the bed

of the lathe, and is kept in position by the tenon D fitting the lathe-bed, and fastened by the nut and screw EF. The platform G is hinged at the back to C, and in front is fixed by the three tenons of A-shown by dotted lines-and the hook H. I is the guide for the wood while being sawn, and which is always retained parallel to the saw by the parallel movement IK; it is secured by the nut




M working in the slot N. The circular saw works through the groove O. This is a very simple and cheap method of mounting a circular saw; but a vertical machine is more convenient, as the friction is less.

The top plate should be about 18 in. long by 12 in. broad, the spindle about 18 in. long by 3½ in. thick; the small pulley 3 in. large, wheel about 30 in. in diameter and weighing about 56 lbs. You can determine the height of the bench by the wheel, which should work freely.

A is the edge of the iron plate. B and C the centre

screws for the spindle to run on, with nuts to lock the screws tight; the sockets can be of cast iron for cheapness, and



must be screwed on the plate from front, which must be countersunk. D is one of the sockets with the two screws. E and F are the nut and centre screw; the point must be of hard steel. G is the saw and spindle, which should be made of iron, with the ends drilled out cone shape to fit the screws, H is the iron plate with the slot for the saw to run in, which must 3-16ths of an inch thick, and firmly screwed to the bench. I is the guide made of wood 9 in. long, with even face. one of the thumb-

screws with which to fasten the guide 3-in. screw.

Fret-Saws.—1. The following is run at a speed of from 300 to 500 cuts per minute, and the length of stroke of the saw is regulated, as will be seen in the drawing. When circles are required to be cut, adjust a clamp, with centre pin, to the saw-table, and set it to the required radius.

A, disc, with adjustable crank-pin for regulating the throw or length of cut. B, saw-table on a pivot C, and fixed by thumb-screw D. E, saw held in screw jaws. F, slide carrying

the elbow lever, and fixed by a set screw behind. GG, grooved pulleys. H, stretching band of crinoline steel, kept


in tension by the slide F.

2. This fret-andscroll saw is constructed on the following principle:—

A is the driving shaft which carries a fly-wheel B, a fast-and-loose pulley CD, and on the end of the same shaft B is a disc communicates the

shaft B is a disc crank E. F is a connecting rod which communicates the motion to a slide-block G. At each

end of the block G is fixed a rope H and I, which transmit the action to two other slideblocks K and L, between which the saw-blade is fixed. MNOP are four guide pulleys for the ropes. Q is a hand-wheel keyed on-a lifting screw R, which screw goes through a nut on which the pulley P is bolted fast; by this contrivance the saw-blade is tightened or slackened. S is a pin on which



the table T is centred; on its bottom side is fastened a segment U, to change it to any angle required. V is the belt guard.


3. A vibrating fret saw. Fig. 1 is a side view of the in-

images, about two thirds of C, and may also be blackened from D to about F.

The instrument now merely requires to have the lid put on, premising that you have first blackened every portion of the inside of it as well as the box.

To adjust the instrument proceed as follows:—

Get three sticks or laths about 3 feet long, find a tolerably



level piece of ground, put in A, then with a tape or rod measure 24 ft., and put in B.; then from B with 40 ft. on the tape, and using B as a centre for the ring to work upon, strike the arc EF on the ground. Again return to A, and with a radius of 32 ft. cut the former arc with another arc GH, and at the front of intersection

put in your third stick. You have now a true square to work upon.

Now measure off on the line AC 24 ft., and replace the stake C at that distance. You will then have a square whose sides are equal, and whose angle is a right angle.


Place the instrument on the stick B, and look through the upper part of the glass AB, so as to see the stake A. Next turn the screw O more or less until the stake C is just in a line with the stake A, the one seen by direct vision, the other by double reflection. Your instrument is now adjusted. Then glue similar blocks of wood on each side to retain it in place, as in the case of AB.

To use it, proceed as follows:-

For vertical heights, ascertain the height of your own eye, and mark upon the building or spire this height, either as a line or a white chalk dot, walk backwards, still looking directly through the instrument until you see its summit, or any part you wish to measure, brought down on the said dot by reflection. You have only then to measure the distance of your own feet to the base of the spire, and add the height of your eye to it, and you have the perpendicular height you require.


just low enough to admit 1-in, square iron to pass nicely

between the saw Y and the bottom of the recess A. You must place the open side of each iron cramp opposite to the way in which you are standing. That will then bring the recess O close to you, when, placing the saw Y on the cast-iron cramp,



you will have the teeth towards you, and the blank part of the saw will rest against the shoulder of the recess O. You can let it lie on the ground when the bolt-cramp AAAAAA has got hold of the saw Y. The tongs used require to be $7\frac{1}{2}$ -in. square iron, and to come close together. A second pair of tongs are also required; they must fit nice and close, and must be $7\frac{1}{4}$ in, wide and $\frac{1}{2}$ in, thick; they are for laying hold of the joint after the hot tongs to keep it well together, and also to cool it. When commencing to braze, file $\frac{3}{4}$ of an inch off each end of the brass, and taper it down to nothing. After that, bring the filed ends over the vacancy K, one end over the other, put some spelter and borax in between, and then screw the saw Y down with bolt-cramps AAAAAA. Now everything

is ready for brazing, get your tongs a white heat, put them over the joint, open, just to see how the brass is going on; when the blue flare rises, the brass has melted, and get someone to put the second pair of tongs on, when you can take the others away. Then loosen the bolts, cramp the joint from over the vacancy, and



bring it farther up the recess O. Now it must be screwed down tight, and filed down to a uniform thickness, and you

will find a good strong joint; smooth, file, and emery the


joint, so that it will slip through the wood.

Fig. 2.—A side view of one of the iron cramps. The dog Q is hollowed out in the centre, just leaving each end a little thicker. O is a fly-nut, H a bolt to pass through the surface of cast-iron cramp. Q is $\frac{1}{2}$ in, wide, 3 in, long.

Fig. 3 shows the end of cast-iron cramp, and how the taper can be filed at G. By screwing the bolts on to the saw you can hold it tight while you file it, which you will find a great

advantage. In the plan, O is merely the file.

Sawing-Machine.—The saw-frame ABCD has a central wooden rod EF, and a saw-blade G and H on each side, which are stretched by nuts and screws at ABCD in the usual way. The saws are guided perpendicularly by the fixed rods IJKL;




these pass through holes in the cross heads of the saw-frame AB and CD. The saw-frame is suspended from the steel bowspring M, attached to the column N erected at the back of the bench, and which serves to support O and P, in which the upper guide - rods are fitted; the lower end of the saw-frame is connected by the hook 0. with the treadle R.

For straight cuts a wide saw H is used, and the wood is guided against the square fence S, which overlaps the front edge of the bench, and is fixed by the binding screw T passing

through a groove in the fence S. For circular pieces a narrow saw G is employed, and an adjustable centre point U, fastened by the nut V, and working in the stationary bar P, serves as an axis of motion for the piece of wood to be tuc.

For horizontal distances, say a tree C, on the opposite side C of the river on which you are standing, fix a

square or cross staff at A, and put a staff in the direction of the square at B; then, with the instrument in your hand, move backwards, looking at A \square in a direct line




at A \square in a direct line until you see the reflected image of C corresponding with A \square . Then measure the distance AB, and this is equal to CA.

This instrument is, of course, held horizontally for the latter, and edgeways, or vertically, for perpendiculars,

Sharpening Edge Tools.—The simplest mode of sharpening an edge tool is to place the cutting part in water containing 1-20th of its weight of sulphuric or muriatic acid; after allowing it to remain there for half an hour, wipe it gently with a piece of soft rag, and in a few hours set in on an ordinary strop. This method, not generally known, is by no means new: the effect of the acid is to supply the place of the oilstone, but uniformly corroding the entire surface, so that nothing but a good polish is afterwards needed.

To Harden Axles.—To harden pattern axles with the prussiate of potash of commerce, make the work red hot, then put on plenty of potash, and plunge in water; or you may get some burnt leather or bone-dust. You can put a lot of axles into a wrought-iron box; put the bone-dust or leather-cinders in, ram down well, put some clay over the top, build a brick fire round the box for about three hours, then pull out, and rinse in cold water; this is the case-hardening process: you will find potash the quickest way.


To Temper Drills and Taps.—Heat them first to a bloodred, and then quench (this gives them extreme hardness, as well as brittleness), then, when dry, pour oil on them, and hold them in the fire, fixed in a piece of iron, till the oil blazes off, withdrawing very frequently to watch the process. This leaves a hardness that the file will just touch. Key shown disarranged in a manner suitable for the conservation of magnetism, and being so applied to the lock (after the bolt is protruded by means of the handle) produces a like arrangement in the lock and the effect of locking.



Lock with front plate removed to exhibit the interior mechanism, where the key, being supposed to be adjusted over the righthand end, has rotated the magnets to the proper position, enabling the bolt to be withdrawn by turning the handle.

Key shown ready set by owner to turn over upon its proper

place on the lock, so as to cause the rotation of magnets as required to enable the bolt to be withdrawn. In the owner's memory the key would be set thus: $4\frac{1}{2}$, $3\frac{1}{2}$, $8\frac{1}{2}$, $1\frac{1}{2}$.



Improved Screw-Driver for large Screws.—This tool possesses very great advantages over the common ones, in consequence of its being worked by a lever, and having a re-It is especially suitable volving top. for wheelwrights, railway-carriage builders, roof-makers, and will turn out twice as much work as the old ones. following is a description: A is the point of the tool; B is the lever, which can be made to fold up (when not in use) at the joint, as shown in the cut. The dotted lines near the joint are the four squares upon which the lever fits.


and while in this position, you draw it to you, then lift it up clear of the square part, and on to another, and so on. C the

in any other part but that which is required hard, and it will then keep straight in hardening; at least it will keep very much truer than if it were heated in the midst of the ignited fuel of the fire.

Fire-Fan.—This fan may be applied to any ordinary fire-grate, and it is almost impossible to imagine its power. A

welding heat on inch iron in a common fire-grate may be obtained by its means.

The sides are formed of two pieces of sheet iron, the bottom of wood, length 1 ft. 3 in.; the nose may be made 6 in. long. in. ; height 61 in. is a wheel turning on a loose spindle. with lock - nuts for the end, to make a centre for the fanspindle; B is a sheet-brass pedestal moving on a pin, with a spring at the



bottom to keep the belts in tension; C is a bit of iron, with three arms riveted on to the side—the centre takes the spindle H; D is a riveted arm to admit a large hole being made in the side, and to take a set screw for the other end of the fanspindle; E the fan; FGI are wheels to increase the revolutions of the fan.

Hardening and Tempering Tools and Weapons.—The colour and temperature required in hardening the above-mentioned articles are as follows: For very soft temper, 630° Fah., colour greenish blue; pale blue, 610° Fah., for saws, the teeth of which are set with pliers; blue, 590° Fah., for

large saws; dark blue, 570° Fah., for small fine saws; dark purple, 550° Fah., for soft swords and watch-springs; light purple, 530° Fah., for ordinary swords and watch-springs; very pale purple, 520° Fah., for table-knives; brown yellow, 500° Fah., for adzes and plain irons; clay yellow, 490° Fah., for chisels and shears; dark straw, 470° Fah., for penknives; dark yellow, 470° Fah., for razors, &c.; pale straw, 430° Fah, for lancets, &c.

On Grindstones. — Discard every contrivance for fixing tools on the grindstone; they are one and all eminently unpractical. A grindstone will not do nice work unless it is kept true, and fixing the tool against it will of course wear it away unevenly. Tools should always be traversed across the face of the stone, and when a flat surface is to be ground by a circular stone, it is clear that this traverse must not be exactly straight across it, or the bevel will be hollow. A very slight hollow is perhaps rather an advantage than otherwise in such tools as chisels and plane-irons for wood; but there are numerous cases where the face should be ground as flat as possible. This, as just stated, cannot be accomplished by keeping the tool fixed against the stone. Turning-gouges, again, must be continually swept round in a semicircle on the stone if the proper form is to be obtained; and, whatever the tool may be, it should be continually traversed if the figure of the stone is to be preserved, which is a matter of the first importance where accuracy in the angles of the edges is aimed at. It is true that some workmen have a knack of producing wonderful edges on stones that run like eccentrics; but this is a rare gift, and the bad state of the stones in many large workshops has much to answer for in the very indifferent character of the metal-turning to be found in them. Where all run to one stone, few take any care of it, and it becomes almost a practical impossibility to grind up a slide-rest tool with anything like the accuracy required for first-class toolwork, Regular grinders, however, know the value of a true stone, and are very careful in keeping them so. A true-running stone with a good face will make the workman independent of any rests and holders beyond his own arms and hands. that goniostats are used for very fine and delicate tools where extreme accuracy of form is essential; but these are generally


ground on laps running horizontally and presenting a plane

grinding surface.

For amateurs' use nothing is better than a treadle grindstone about 20 in. or 24 in. in diameter; and if the tools are always traversed on it, and it is never allowed to lie in—or even over—water, it may be reduced 2 in. or 3 in. diameter by honest work, before it requires turning up again; and the operator will find, that when he has accustomed himself to grind true by hand alone, he will seldom want even a rest, and would certainly never think of spoiling his stone by using such an awkward and unpractical contrivance as a fixed holder.

Saw-Benches.—The following plan of a saw-bench will suit any possessor of a lathe, The box ABC rests on the bed

of the lathe, and is kept in position by the tenon D fitting the lathe-bed, and fastened by the nut and screw EF. The platform G is hinged at the back to C, and in front is fixed by the three tenons of A-shown by dotted lines-and the hook H. I is the guide for the wood while being sawn, and which is always retained parallel to the saw by the parallel movement JK; it is secured by the nut




M working in the slot N. The circular saw works through the groove O. This is a very simple and cheap method of mounting a circular saw; but a vertical machine is more convenient, as the friction is less.

The top plate should be about 18 in, long by 12 in, broad, the spindle about 18 in, long by 3\frac{1}{4} in, thick; the small pulley 3 in, large, wheel about 30 in, in diameter and weighing about 56 lbs. You can determine the height of the bench by the wheel, which should work freely.


A is the edge of the iron plate. B and C the centre

hold on drifts, long enough to clear fire and smoke box doors, is necessary.

An Adjusting Carrier.—Here is a sketch of an adjusting



AAA is the front view, B the edge; they are made either in gun-metal, iron, or steel; CCC to the dotted lines are one and the same pieces : DDDD are separate pieces fitted to CCC at the bottom by screws EE, and at the top by screws FFF. which fit into a revolving steel nut GGG, the faces of the screws binding upon the faces of the nuts and the faces of DDDD, at one and the same time, just sufficiently tight to allow



For horizontal distances, say a tree C, on the opposite side C of the river on which you are standing, fix a

square or cross staff at A, and put a staff in the direction of the square at B; then, with the instrument in your hand, move backwards, looking at A \(\square \) in a direct line until you see the reflected image of C

at A □ in a direct line until you see the reflected image of C corresponding with A □. Then measure the distance AB, and this is equal to CA.


This instrument is, of course, held horizontally for the latter, and edgeways, or vertically, for perpendiculars.

Sharpening Edge Tools.—The simplest mode of sharpening an edge tool is to place the cutting part in water containing 1-20th of its weight of sulphuric or muriatic acid; after allowing it to remain there for half an hour, wipe it gently with a piece of soft rag, and in a few hours set in on an ordinary strop. This method, not generally known, is by no means new: the effect of the acid is to supply the place of the oilstone, but uniformly corroding the entire surface, so that nothing but a good polish is afterwards needed.

To Harden Axles.—To harden pattern axles with the prussiate of potash of commerce, make the work red hot, then put on plenty of potash, and plunge in water; or you may get some burnt leather or bone-dust. You can put a lot of axles into a wrought-iron box; put the bone-dust or leather-cinders in, ram down well, put some clay over the top, build a brick fire round the box for about three hours, then pull out, and rinse in cold water; this is the case-hardening process: you will find potash the quickest way.

To Temper Drills and Taps.—Heat them first to a bloodred, and then quench (this gives them extreme hardness, as well as brittleness), then, when dry, pour oil on them, and hold them in the fire, fixed in a piece of iron, till the oil blazes off, withdrawing very frequently to watch the process. This leaves a hardness that the file will just touch the fabric. The improvement is in forming the shank with one or more swells or enlargements, beginning at or near the point, and terminating in square or bevelled shoulders; or if designed to be permanently placed, as in fastening papers together, the expanded portion is provided with barbed points, so that if once inserted it cannot be withdrawn.

French and English Nails compared.—A writer, asserting the superiority of French over English nails, says:




"The fault of the English nails is their being made in the shape of a wedge, which detracts from their holding power and makes them more likely to split the wood. French nails same thickness all the way down, and have a sharp point, which is an improvement that the English makers seem to think quite unnecessary. French nails are made of wire, they are less brittle than the English, and can be used over and over again without breaking. French nails have another great advantage, which is this, when an English nail is drawn out of its hole

to a certain extent, it (owing to its wedge shape) loses all power of holding, whereas the French nail holds to the last."

Drilling-Machines.—Of late years much of the harder part of mining, excavating, &c., is performed by machinery; a description, therefore, of the principal instruments in use for that purpose will not be without interest to our readers. First we have the drilling-machine patented by Mr Newton. The invention relates to machines in which the working parts and bed are attached to an upright. The feeding of the drill is

ed by a weight applied directly to the drill-stock, reguy an adjustable counterpoise connected to the drill-stock ystem of levers, which also raise the stock and drill the work, to permit of the adjustment and removal of rk from the drilling bed; and it is in this counterpoise stem of levers and their connections that the first part invention lies. The second part of the invention conf a bracket attachment, which, with the bearings in the drill-stock works, are all cast in one piece and to the standard. The third part consists in furnishadjustable bed-plate with a fixed jaw and a sliding jaw works in fixed guides on the bed, and is adjustable by v for clamping the articles between the two jaws. The on consists finally in constructing the standard and bedwith a recess for the introduction of large articles, withving the drill-stock, or the table or bed-plate, set out at a listance from the face of the standard.


ling Holes in Glass, &c.—A practised man t as his experience that a splinter of a diamond best article with which to drill holes in glass. dinters are mounted as in the diagram. A, brass is made to fit drill-stock, sawn down a little way notched knife to allow the splinter to fit tight; splinter of stone cemented by heat with a little or sealing-wax. The drill is to be used quite d with care.




k-Drilling Machinery.—An improved drill has been inby Mr Christian Jurgens, of Weber Creek, California,
consists of three angular cutting bits, having an obtuse
thus giving it three regular inclined faces and three
s. When the drill has become worn and dull from use,
ventor uses a die, by means of which the smith may
readily and perfectly restore the drill to its original shape.
ming the original drill, the inventor uses a swage block,
hich the bar of metal, after being heated, is placed horiy, where it is hammered and turned until properly shaped
eive its cutting faces and points. This swage may be
dvantageously used in repairing drills, and in keeping
ill in proper shape as it is gradually worn up by use and
quirements of new cutting edges. By the use of these

shaping tools a drill may be more perfectly and readily shap and sharpened than in the ordinary manner of hammering an anvil.

Alley's Drilling-Machine. This instrument was introduc




by Messrs Neilson Brothers of Glasgow, and was designed Mr S. Alley of that firm. Its chief peculiarity is that near



all the gearing is enclosed within the hollow pillar and rad arm, thus protecting it from the dust and from contact w iding objects, whilst the tool as a whole is rendered very ct. The pillar, which is of the telescope form, is raised

lowered by in the smaller es, but for sizes an arnent reprein the secview is adopt-The wheel and on the top of rtical pillar on ft - hand side main pillar is ved for raiscoupling on driving shaft, ch means the



screw is coupled to it. The drill-spindle is provided self-feeding motion, which can be engaged and dis-

ed at pleaby means of tion - clutch, ther parts of nachine are early shown the woodcut further deon is not re-


ng-Machine.
following
machine is
used where
ower is net: A is
and which



ts the flywheel B. A cogwheel C revolves on the axle as this flywheel, and turns another cogwheel D, revolves on a pivot, to which is attached the auger E.

The flywheel is turned by the treadle and crank H. would give sufficient power to the auger to bore throug thickest planking.

Pillar Drilling-Machine.-This compact and usef




strument occupies a space of less than 2 ft. square, the being only 5 ft. 3 in. It can be worked as advantageous

steam as by manual labour. When worked by the latter, the pressure on the drill is produced by the feet, leaving both hands at liberty to hold the work and turn the machine. On removing the foot the drill is instantaneously lifted out of its work; the pillar being accurately turned, the table is easily adjusted to any depth, so as to take in articles not exceeding 2 ft. 3 in. in height. This pillar drilling-machine requires only one person to work it. The drill makes two revolutions to one of the hand-wheel, consequently, for holes up to \(\frac{1}{2}\) in, diameter, it will drill two to one of any other machine, and when worked by steam power, it retains this advantage up to \(\frac{3}{2}\)-in, holes.

Boring-Tools.—There are several boring-tools for wheels, &c., to follow up drills, or to finish holes left in the castings. The rose-bit is of very general use in boring out brasses

for bearings. It is made of steel turned, filed into teeth, and hardened. Fig. 1 represents two forms. Fig. 2 is the regular boring-bit of



engineers; it is a semicircular bit of hard steel shown more plainly at B; the other end is drilled to receive the point of

the back centre of lathe, which keeps it up to its cut. Let the wheel to be bored be chucked, and after being drilled (if required) turn out a recess the exact diameter of the



tool, thus: ab is the recess; de, top of rest; c, spanner of back centre. Then lay the tool in the recess, flat side up, place a spanner on the shank, which is squared, and let spanner lie on the rest so as to prevent the tool from turning, screw up back centre, and work away. Holtzapffel keeps the standard tools required.

Sprinkling Book Edges.— Procure for 'red edges a penny-worth of Spanish brown, and for brown edges a penny-worth of burnt umber, and take sufficient paste to mix a quantity of either colour on a stone slab, adding, when well mixed, a few drops of sweet oil; then put the mixture into an earthenware jar, and add some water to it. Before using it stir it well with an iron-bound brush, then twirl the brush well round in the jar, and strike it against a wooden rod, held in the left hand, till it throws fine spots on a piece of paper; then proceed in the same way to sprinkle the book edges, taking care to wipe the wooden rod occasionally.

Home-made Drill.—A simple drill for small objects can be made, as shown below, for about six-FIRE. In fig. 1, AC is a shaft of pence. common deal, thick where the flywheel is placed and tapering towards each end; HE is the flywheel, also made of deal and weighted with lead; KL is the wood; and HF, HE, two rings of lead: instead of rings a piece of pipe flattened might be nailed on the circumference. Fig. 2, HZ, ZF, shows the breadth of the rings of lead; S is the hole where the shaft 11143 Figs. 1 and 3, NO is a is fixed. cross-bar working on the shaft; S' is the hole where the shaft passesthis must be loose; N and O, where the twine is fixed; PC is a wire wrapping to hold the bit (a small bradawl) firmly. The working is very simple. The twine NX, X0, must be fixed at and wound round the shaft & few times, which raises the arm of


cross-bar to Y. Pressure must then be alternately applied and relaxed to the bar.

with a lead wheel and emery, the emery to be mixed with water to a paste and applied with a small brush; after they are sufficiently ground, the next process is smoothing. Work the emery on the wheel, it will soon smooth; if the wheel should get dry or blue, take a little more emery and another stone, and smooth it on the wheel and then finish off scratches. Now for polishing. Be sure and wash all the emery off before commencing this step. Polishing is done on a block-tin wheel with rotten-stone. All the wheels run horizontal, and are

cast about 8 in, in diameter and turned true.


To Cut Brooch Stones.—If the pebbles are round they must be slit. This is done with diamond-dust, applied to the edge of a tin wheel with the finger, and then oil is kept on with a feather as long as you cut; after that, the stones are blocked to shape with a pair of soft iron nippers 6 in. in size, and then stuck on a stick and cut into shape and finished.

Vertical Drilling-Machine.—This small machine can be fixed upon the bed of a lathe, and worked by a small pulley on the flywheel shaft. A, the bed; CC, a wrought-iron pillar supporting the brackets BB; EEE, screws for holding the brackets; D, hand wheel for raising and lowering the drill; F, bolt to




the end of the pillar C for holding it down to the bed of a lathe.

Another design is shown in annexed diagram.




A is a stand of hardwood with upright and cross piece at top firmly fixed; B, nuts to screw the whole to bench; C, flywheel; D, crank for treadle, or may be shifted towards the outside of flywheel, and act as a handle; E, pulleys; F, lead weights moving nearer centre if required; G, pivot upon which extra weights may be placed; H, pulley; I, piece screwed on to work in slot in pulley; K, dovetail, which may be removed and plate M substituted, in which the squares move towards the centre, and thus clamp the

work; L, blocks to keep pulley in position.




nother simple machine is made as in above engraving, be made of any size to fix on the table conveniently. rilling-machines for stoves, &c., can be made thus:—



t shows the tool applied to a work-bench; fig. 2 as applied wall.

entre Bit for Outting Leather Washers.—A is a piece on $3\frac{1}{2}$ in. long by $\frac{1}{2}$ in. square, tapered at the end to fit into ommon joiner brace. The bit C_I is to be filed out with a ll round file for the catch in the brace to fit it. AA is a ce of iron I in. thick, I in. broad, I in. long, with a slot


§ in. square through it. B is the slot, D is the centre, the same as that of a lathe. CC is the slide, § in. square, to fit in



HH is a the slot. square piece of iron I in. long, \frac{3}{2} in. broad, I in thick, with a slot 1 in. square through it FF is the cutter that fastens in the head HH. G is a thumbscrew that fastens the cutter in the head. HH. cutter, must be the same shape as a

spear-point penknife-blade. The bit CI in the cutter must be filed out so that the thumbscrew can fit in to keep the cutter fast. E is for a thumbscrew to hold slide from moving when used.

Water-Wheel.—The leverage in all the weight of water in the buckets from D to E is the same as the pressure of a col-



umn of water of corresponding dimensions suspended from D to F. The shorter column CE would be also equal to CF; but experience proves it to be advisable to throw all the force into a column of water, as above, with full buckets, rather


than to expend velocity at a lower range, the intermediate buckets from C to E being only partially filled. This reasoning can apply only to a properly-made breast-wheel.

Cotton Waste may be thoroughly cleansed from oil and grease in the following way: It is put into an iron furnace (heated with steam from a pipe led into it), together with steams

little black-soap and soda. The action given to the water by the rushing in of the steam keeps the waste continually moving, thus freeing it of its impurities. After boiling for about two hours, it is taken out and laid on a boiler or warm place till dry.

To Make the Ram of a Hydraulic Press Water-tight.—
The ram A is surrounded by a collar of leather D; the leather is formed as shown in fig. 3, being turned up to form a double cup, so that it resembles the cuff of a coat-sleeve. When in its place, it is kept distended by the copper ring E entering the circular channel or fold of the leather. This ring has a lodgment in a recess formed within the cylinder B. The leather is kept down by a brass or bell-metal ring C, which is received into a recess formed round within the cylinder B, as shown in fig. 1. The interior aperture of this ring is adapted to receive the ram A, and thus the leather becomes confined in a cell, with the edge of the interior fold applied


to the ram A, whilst the edge of the outer fold is in contact with the interior surface of the cylinder B. In this situation the pressure of the water acting between the folds of the leather, forces its edges into close contact with both, and makes a tight fitting round the cylinder and



ram; and as the pressure of the water is increased, the leather is applied more closely, so as to prevent leakage under any circumstances. The metal ring C is truly turned in the lathe, as well as the cavity or cell formed for its reception; then to get it into its place, it is divided by a saw into five segments, as shown in fig. 2. Three of the lines by which it is divided point to the centre, but the other two are parallel to each other, and the ring is put into its place (after the leather and copper rings are introduced) by putting in the four segments sepa-

rately, and the one with parallel sides is put in last. The ram A is then put down in its place, and ready for action. The upper part of the cylinder above the ring C is filled with tow or other soft packing impregnated with sweet oil, which is confined by a thin plate or ring. A, piston or ram; B, cylinder; C, brass ring; CI, segment with parallel sides; D, leather collar; E, copper ring; F, oiled tow. The same letters refer to all the figures.

Air-Engine.—The principle on which this engine works is as follows:—



The air at the bottom of A is heated, and thus expands past the piston B, which is made to clear $\frac{1}{8}$ of an inch, reaches the top, where the brickdust cools it, thus causing a vacuum under piston in D, which draws it down.

A, main cylinder regenerator. Dimensions, 15 in. diameter, 51 in. long.

A1, top or cold end of ditto.

A2, hot end of ditto.

- B, hollow piston working in A, 1½ in. diameter, 3½ in. long. C, air-tube, connecting A with D.
- D, working cylinder, I in. diameter, I 9-16 in. long.


E, spirit-lamp or gas-jet.

- F, casing round top of A, containing brickdust to keep down heat.
 - A, length of stroke = $1\frac{1}{6}$ in.
 - D, length of stroke = $1\frac{1}{4}$ in.

Syphon, the Principle of.—Let a bent tube ABC have its shorter leg AB immersed in any liquid—say water—having been previously filled with the same liquid. The water

maintained up to the level D by the force of the in the vessel, and may therefore be left out of conion.

forces tending to the water in the in DBEC will be ssure of the atmosransmitted through iter in the vessel, e weight of water portion BC. The tending to move ter in the opposite on will be the pressf the atmosphere at the orifice C, and of water in the BD.




pressures of the

here being equal will neutralise each other, and there a tendency of the water to move towards C, in proto the excess of BC over BD.

phon will conduct water from a high to a lower level. fundamental law in hydrostatics, that the pressure of d upon any point is in direct proportion to the depth of bint below the surface.

Pumps.—1. The following is a suggested air-pump. not, so far as we are aware, been tried. To work

is the indiadome, and return until is exhausted, mahogany covered with plate; B, re-C, india-rubne to act as D, wooden



protect dome from the spring; E, steel spring to keep stretched out; F, brass cylinder on which dome is

fastened; G, valve to prevent return of air into receiver; H, outlet valve, protected by brass cage; I, screw to let air into dome; J, outlet air passage; K, exhaust passage.

2. The following plan will, it is asserted, answer well for

small experiments:-

If applied to exhaust the air from a large receiver it should be applied only as a finishing pump, as the action is slow compared with many double-actioned air-pumps.

FI TOCOCCOORDINATION OF THE SECOND OF THE SE

FIG S

AA, cylinder of brass; B, piston, which should have a thread all the way down; CCCC, plates of brass, with DDD layers of vulcanised indiarubber (I inch in the whole) between, which are kept firmly in place by means of the screws EE. F shows the situation of the tap, the working of which is shown in fig. 2. The tap, as there represented, should work right into the cylinder, but not to interfere with the action of the piston. G is a brass plate, and should be ground down so as to fit perfectly air-tight to the end of the cylinder and piston; H is a brass cap for the purpose of holding on the brass plate G during the first move of the piston.

The pump should be worked in the following manner:—


Screw down firmly, by means of the nuts EE, the brass plates and layers of vulcanised india-rubber marked C and D in the diagram, to the bottom of the piston; then, having forced down the piston to the bottom of the cylinder, which is made to fit level to the end of the cylinder, put the brass plate G, with a little grease rubbed on the inside face of it, against it—this will be kept in its place by the cap H; then the tap being turned so as to open a communication with the receiver, draw up the piston the full length of the cylinder—this will remove a cylinderful of air from the receiver; then eject

this quantity of air by cutting off the communication with the receiver and pushing down the piston. Repeat this process till a perfect vacuum is formed. [The above is interesting


as a suggestion. We believe it has never been practically tested.]

Capstan Pumps for Hydraulic Presses .- The arrange-

ment of pumps for working hydraulic presses shown by our engravings has been invented and patented by Messrs Peel of Manchester. The pumps are placed in a horizontal position, with their axes radial to the circle formed by the lid of the cylindrical water-cistern,




connected to an eccentric disc, keyed on to the vertical capstan shaft, which in this manner forms the crank for all of them, since at every revolution of the eccentric each pump completes a full double stroke. The pumps enter the corresponding phases of their movements in rotation, and divide the power very regularly all over the



the form of which, as shown in the drawing, is intended for being worked by men. An arrangement is provided for throwing the greater number of pumps out of action


when the pressure increases beyond a certain point, so that the ultimate compression given to the bale can be increased by these means.



Cork Springs.—In a report upon new mechanical applications the secretary of the Franklin Institute called attention to the use of cork in place of india-rubber as a support for freight cars and like heavy vehicles. One would not be led by any means to predict the efficiency of cork in this connection from ordinary impressions of its properties. The cork used for these springs is of the commonest description, harsh, hard, and full of fissures. It is cut into discs of about 8 inches diameter, each pierced with a central hole. Previous, however, to cutting it, it is soaked in a mixture of molasses and water, which gives it some softness and renders it permanently A number of these cork discs are placed in a cylindrical cast-iron box, a flat iron lid or disc is placed over them, and by hydraulic pressure is forced down so as to reduce the thickness to one-half. A bolt is then run through box, corks, and cover at the centre, and a nut being screwed on this, holds all in place, when the press is relieved, and the box of compressed cork disc or cork spring is ready for use. of these springs, placed in a testing machine under a weight of 20,000 lb., shows an elasticity suggestive of compressed air in a condensing pump. One would expect, from the appearance of the material, that under heavy pressure it would be pulverised or split into shreds, especially if this pressure was assisted by violent shocks; but, in fact, no such action takes place. A pressure which destroys india rubber, causing it to split up and lose its elasticity, leaves the cork unimpaired; and with the machinery in use, it has even been impossible, with any pressure attainable, to injure the cork, even when areas of but I inch was acted upon. In connection with this subject, the president, Mr William Sellers, remarked, at the conclusion of the secretary's report, that he had for some five years employed a forging-machine in which a spring of the form and material above described was used, and subjected to continual and violent shocks, and that its performance had been most thoroughly satisfactory, with no signs of deterioration.


Camera Obscura for Drawing Objects.—The following sketch will be useful to amateurs wishing to construct a camera obscura: The best form of lens is a Meniseus (the focus for

sketch 16 in.) with its convex side to the mirror, the diameter 21 in., the mirror 4 in, by 3 in. K is a hole to see the image. One of the sides is made to open, for the hand to draw the object. The height of the camera is 19 in.; the lens to be 15 in. from the bottom: the mirror to be as close to the lens as possible, at an angle of 45°. The mirror and lens should be



made in a square box to fit in the top, so as to allow the sides abc to fall in, and d to form a lid.

Pump for Deep Wells.—A model pump, made by an ordinary tinworker, is thus described:—



about 3 ft. long. Filled with water, it was found that the water in the barrel balanced the water in the pipe, and remained there by keeping the lower end of the sucking pipe under water; consequently, a pump fixed on the short pipe C would work with as much ease as though the water rose to the top of the well. A is an opening to fill it with, and while filling, the short pipe C must be stopped when Secure the opening at A, making it air-tight.

This pump will require a valve to act with the bucket. For convenience the barrel B may be put above, below, or half-way with the surface of the ground.

The opening at the top A may be omitted in a miniature model, as it will only be required for convenience in a large domestic concern.

Pump for Tube Wells .- During the Abyssinian War the Government supplied various kinds of pumps, of which the following was the best example. The whole apparatus is very simple and ingenious, being one of the numerous American inventions designed for the saving of labour, more especially in farming and mining districts.

A well on this new principle may be sunk in from one to three hours. The tube of the well is simply an iron gas or steam pipe 11 in, in internal diameter.


The lower end of the tube AB in the accompanying diagram is furnished with a solid steel or case-hardened iron spike B of the shape of a four-sided pyramid. The lowest end of the pipe itself is pierced by numerous small holes at N. After the pipe has been driven into the ground, a small pump is screwed into the top; the water, if present in the place, finds its way

h the holes at N, and may be pumped up to a height ich exceeding 28 ft., which is usually all that is neces-

the least ingenious aspect useful little invention is thod of driving the pipe ground with the smallest ture of time, labour, and ls.

movable clamp F is screwed to the outside of e, above the level of the HK. Near the top of e, some distance above similar clamp is fixed, upper clamp carries two wheels for ropes. The opes also pass round the wheel DE of the monkey means of the ropes a of men can easily pull the C up the pipe, and ly let it fall upon the of the clamp F; and the of each blow of course the pipe deeper into the

By successive blows mp F at last reaches the the ground HK, when unscrewed and refixed up the pipe. The upper may be shifted in a manner, and in this way e AB can be driven, if ry, as deeply into the as a pump can raise



advantages claimed for Norton's Patent American Tube s it is called, are hat it costs only a tithe of a bored or dug well, and vater-rates, because by the 11 and 12 Vict, cap. 63, it is enacted that no water-rates can be levied where there pumps giving a proper supply of water.

2. That the water is purer than usual, because of freed


from the upper surface drainage.

That by this method wells may be easily made in lo soil, and the strata below may be pierced should there be

water at the bottom of the loose soil aforesaid.

A plan somewhat similar to this has long been in use to result from its subterranean beds. Sir Robert Kane, M.D., his book on "Chemistry," says: "Owing to the admixture earthy matters, the rock-salt, as quarried, is generally brown coloured, and hence requires to be dissolved in water a crystallised for use. The expense of extracting the salt in be in many cases lessened by simply boring down to the with a pipe a few inches in diameter, and letting there water run in upon the salt; a strong solution of salt is the produced, which is pumped up and evaporated. The expense of sinking a shaft and quarrying out the solid salt is the avoided."


Sack-Holder. - The diagrams below illustrate a simple :



useful invention for sack-holding, inasmuch as it is the sav of a vast amount of labour and material. It possesses seve decided advantages, combining strength with simple construc-

tion and direct action. The height can be regulated as required by opening or closing the legs $\epsilon\epsilon$, being kept in the required position by the perforated plate d, which is fastened at f, passed through an opening in f, and is held by the iron pin g.

After adjusting the holder to the proper height, fold the back part of the mouth of the sack outwards, place it over the clamping-bar b, draw the spring arms co forward, and place the hooks over ee; the sack will then be firmly held between the bars ab (fig. 2). In this position it



By a simple modification of the above the "holder" may be adjusted on wheels, thus combining with it sack-cart (fig. 3).





It can also be fixed on beams or walls (figs. 4 and 5).

Diamonds, to Polish.—The plan in use at all the large diamond-cutters' is simply a circular cast-iron disc of good metal, with a vertical spindle running through its centre, balanced and turned and faced true in a lathe. The disc revolves at about 1000 revolutions per minute, With a little diamond-dust and oil the stone is set in a small brass cup filled with common soft solder; it is then screwed up in the clamps, and applied to the skive till the facet is formed.

To Fasten Driving Straps.—Two thin metal plates, their inner faces roughened like those of a vice, and held together by screws, form a cheap, strong, and convenient fastening for

driving straps. If the strap stretch, the screws (which pass between the ends of and not through the strap) have only to be loosened, the ends of the leather cut shorter and clammed anew.

To Draw Radii to Inaccessible Centres.—The following

instrument will be of use:

A is the blade with a slot in one end for set screw C to work in.

BB are the legs to run against cylinder, &c.

DD are radius bars to keep the blade central.

Bookbinding — Marbling.—Use the following colours: Scarlet drop lake, Chinese blue, indigo blue, ultramarine, orange lead, Dutch pink, Chinese blue can only be used by grinding with a small piece of pipeclay, and when properly ground, add a little gum arabic dissolved in water. tramarine blue, with a small portion of indigo, makes a good colour, and is less troublesome to but does not manage, stand so well. Green.

manage, but does not stand so well. Green, indigo and Dutch pink, mixed to the shade required. Red, use scarlet drop lake. All the above colours must be ground in neat gin, no water to be used either in grinding or afterwards. A few drops of ox gall must be put in each colour to make it spread on the size. Use the colours about the thickness of treacle.

Size.—This is the principal ingredient in marbling, and therefore requires much attention. Use the best gum drachan,

which should be white and clean; soak a handful in soft water for twenty-four hours, beat well up with a roller, then add water until about the thickness of cream; pour through a sieve

into your trough, let it stand to clear, add a little salt, and it is ready for use. For non-pareil marble use the same size, but thinner; and in grinding the colours, add a little bees-wax dissolved in turps,

Gas - Generator .-Procure a half-gallon jar capable of standing a good pressure, then turn a cap to fit the neck with a screw inside, as N; then the headpiece P, with a screw at S to fit into N. the head to contain a tap moved by a handle H, when the water will be forced through the glass tube A, which must be connected with the opening O, and reach to within ½ in. of the bottom of thejar. To



Work it, fill it three parts full of water, then add $\frac{1}{2}$ oz. each of carbonate of soda and citric acid, or a sufficient quantity to generate gas enough to force the water up through the tube.

Papier Maché.—The substance known as papier maché is extensively employed in the construction of tea-trays, picture-frames, &c., and even railway carriages. There are two kinds—the pasted sheets and the macerated. The latter, which is the

more common, is made of paper cuttings boiled in water, and beaten in a mortar till they are reduced into a kind of paste. and then boiled with a solution of gum or size, to give tenacity to the paste, which is afterwards formed into different articles by pressing into oiled moulds; when dry it is varnished and polished. The black varnish for papier maché toys is thus prepared: Some colophony, or turpentine boiled down till it becomes black and friable, is melted into a glazed earthen vessel, and thrice as much amber in fine powder sprinkled in by degrees, with the addition of a little spirit or oil of turpentine now and then; when the amber is melted sprinkle in the same quantity of sarcocolla, continue from time to time to stir them and to add more spirit of turpentine till the whole becomes fluid, then strain out the clear through a coarse hair bag, pressing it gently between hot brands. This varnish mixed with ivory-black, in fine powder, is applied in a hot room on the dried paper paste, which is then set in a gently-heated oven, next day in a hotter oven, and the third day in a very hot one, and let stand each time till the oven grows cold. The paste then varnished is hard, durable, glossy, and bears liquors hot or cold.

Wheeled Skates,-The following sketch is sufficient to




wing sketch is sufficient to allow any clever mechanic to make a pair of wheeled skates that can be used both in and out of doors, on any level ground. They are fastened on the feet with a strap from heel to instep, and a couple of straps across the toes. A screw passes into the heel, at the back instead of the bottom, as in the ordinary skate. The skate itself is formed of iron, slightly curved to fit the foot, and rolls upon four little

wooden wheels, with indiarubber tires.

Omnibus Register.—Various plans have been from time to time suggested for registering the number of passengers carried

and upon an omnibus during the day. The present plan especting the conductors to mark down each "fare" upon card is confessedly incomplete, and the more simple one of



Omnasus Passenger Registering Mackine.


ng each passenger a ticket from a numbered book does not n to have suggested itself to the omnibus proprietors, following apparatus for registering the number of passengers conveyed and the amount of money taken has been invented by Mr R. H. Thomas of Kidsgrove, near Birmingham.

Fig. 1 of the diagrams is a 1-size plan of the machine closed ready for use, to be suspended under the left arm by the two rings OO to a shoulder strap, the hollow side next the body, and the cover C towards the right hand.

Fig. 2 is an elevation with the front plate L and the bearing

bar M removed to show the movement.

A is a thumbstand on a sliding rod jointed at the bottom end to a ratchet hook B and a spring S; C is a cover for protecting the stud A when not in use, but is turned up to the dotted lines when it is required; D is a detent click and hammer; E is a spring to force it down in the ratchet teeth, and at the same time to strike the bell R; F is a plate ratchet wheel numbered for pence, from I to I2 and from I to I2, with a pinion on its arbour, which drives the shilling plate wheel G, with another pinion to drive the pounds wheel H; I I I are




three indicators pointing to the numbers on the wheels F, G, and H; R is a bell on the arbour of the wheel H.

Ratchet-Wheels.—RW, ratchet on end of wheel nave, both cast together; CC, a collar on the shaft end which works inside of nave; C, a movable catch kept in its place by the small spring S. The collar answers for two purposes—viz.,

to keep the wheel on and to work it round. D is a set screw to fasten a tin cap on end of nave or boss of the wheel; SC is a set screw to fasten the collar on the shaft; WBC, the wheel boss and cap fitted on over the ratchet. The ratchet is a rim by itself, and may be cast at rights and lefts.

Cutting out Bowls.—An inspection of fig. 1 will show

hat after the first groove is cut, a very long straight hook can be placed beside the centre block, but it would be impossible to place it for the edge to cut. But in fig. 2, a small tool, figure 1. is shown in position, and it can be brought to touch, cut the block, and when gradually advanced till the shank of the tool touches the block, will be undercut to the dotted line. Then you can place 2 so as to begin to cut, it is so placed to commence where the other left off; by the time this has been advanced the block will be undercut to the second dotted Insert a longer one in the same way the block falls out. With curved hook tools wooden bowls are thus cut out one from inside another, so as to have no waste.



Ivory Bleaching.—Should antique works in ivory become iscoloured, their original whiteness may be recovered by xposing them under a glass shade to the action of the sun's ays. If a piece of sculpture is disfigured with cracks, although less defects cannot be removed, they may be rendered much so apparent by brushing them over with soap-and-water. The rocess of bleaching will be much accelerated if before exposing

to the sun, the articles are brushed over with calcined diluted pumice-stone.

Ivory Cleaning. — Rub it with finely-powdered pumices stone and water, expose to the sun whilst moist under a glass shade, and repeat until the whiteness is restored; or immerse for a short time in water slightly mixed with sulphuric acid, chloride of lime, or chlorine, or it may be exposed in the moist state to the fumes of burning sulphur, largely diluted with air. Ink-stains may be removed by repeatedly using a solution of quadrozalate of potassa in water.

Ivory, to Soften.—Dr Lankester recommends phosphore acid, of the usual specific gravity, which renders ivory soft and nearly plastic. When washed, with water, pressed, and dried, the ivory regains its former consistency, and even its microscopic structure is not affected by the process.


Dyes for Ivory.—Billiard-balls and other articles in ivory are often dyed. A good red dye may be given by first imbuing the ivory in a solution of nitro-muriate of tin, and then plunging it in a bath of Brazil wood and cochineal. Lac dye may be used with still more advantage to produce a scarlet tint. If the scarlet ivory be plunged for a short time in a solution of potash, it will become cherry red. To dye a purple the ivory must first be mordanted for a short time in the above solution of tin, and then immersed in a logwood bath. This gives & When the bath becomes exhausted it imparts violet colour. Violet ivory is changed to purple by steeping * a lilac tint. a little while in water containing a few drops of nitro-muriatic The aniline dyes can only be used for mauve and magenta, but unfortunately they soon fade. To dye ivory green it must first be dyed blue by immersing it for a longer or shorter time, according to the depth of colour required in a dilute solution tion of sulphate of indigo, partly saturated with potash. wards dipping the blued ivory in the solution of nitro-muriate of tin, and then in a hot decoction of fustic. By omitting the indigo bath the ivory will be dyed a fine yellow. Ivory takes the dyes much better previous to polishing. Should any dark spots appear, they may be cleared up by rubbing them with chalk; after which the ivory should be dyed once more to produce perfect uniformity of shade. On taking it out of the soiling hot dye bath, it ought to be immediately plunged into cold water to avoid the chance of fissures being caused by the heat.

A simple way of dyeing old billiard balls is to procure a piece of thin, fine-faced scarlet cloth, wrap it tightly round each ball, being very careful to have as few creases in it as possible, and boil in water till the colour has reached the required depth. Rough-faced cloth will give the balls a mottled appearance.

Another plan is to take 2 ounces of verdigris and 1 ounce of sal-ammoniac, grind them well together, pour strong white wine vinegar upon them, and put your ivory balls in. Let them lie covered till the colour has penetrated.

Saving Life on the Ice.—Below is a diagram of a proposed raft to be used in rescuing persons from drowning consequent

upon the breaking up of the ice. It is constructed upon the well-known plan of the toy regiment of soldiers. It



might be made of battens 5 ft. long, 4 in. by 2 in., bolted together, having a few friction rollers; and irons turned up at ends similar to skates. By means of the two ropes it could be worked from the bank, and got into any desired position with




great facility. Such rafts would be very useful to cover any weak place on the ice, and one or two extended would be effectual in keeping it clear of skaters. The whole would occupy about 5 ft. square, and when extended would form a raft 50 ft. long and 4 ft. wide.

Vellum Cleaning.—Muriate of tin, oxalic acid, binoxalate of potash, of each ½ ounce; powdered pumice-stone and cream of tartar, 2 ounces of each, and water 2 pints. Put all together and allow to remain till the oxalic acid and binoxalate of potash are dissolved. Shake well up before using, and rub well the bindings with it, by means of a sponge or piece of flannel, till clean. The bindings should turn out nearly white. Ink-stains will mostly be taken out. It will be well not to try to do too much at once, as more good may be done by applying a second time, in a day or two, after the books have got dry.

Parchment Cleaning.—Strain the parchment tight with the finger and thumb over a ruler, and "shave" it out (the very same action being used as when shaving the face) with a very thin sharp knife. The two principal difficulties in this are, not bringing the pieces clear off, and thereby leaving jagged ends; and bringing them too clear off—i.e., making holes. When he has mastered this the amateur will be able to cut out a line or two, if he likes, and it will be scarcely visible unless held up to the light.

Tortoiseshell, to Polish.—Handles and similar work are first sawn into shape, then filed and scraped with a joiner's scraper; afterwards polished on a buff wheel, first with calcined Trent sand, and finished on another wheel with oil and rottenstone. Flat works are treated in a similar way with flat pods. Turnery works are smoothed with fine glass or emerypaper, and finished with rottenstone and oil. Horn is treated in the same way, but the sand need not be calcined.

Cutting Hinges. — Amateurs will find the following plans useful for cutting the concave parts of hinges: The holes aaa, fig. 1, are first drilled to admit the steel rod, fig. 2, which has




one end squared enable it to be turned by a hand-vice. On this rod fits the cutter, fig. 3, which is a cylindrical piece of hard steel bored to fit the rod, and cut with teeth on the outer cvlindrical part on one flat surface: 2 pin is inserted through both the cutter and bar, so that the two may be united after they have been placed within the joint to be worked.

recess must first be cut to admit the cutter, and then the hollow parts of fig. I are cut throughout their length with the cutter, which afterwards serves to flatten the faces of the knuckles in exact parallelism throughout and at right angles to the central

hole. For cutting the knuckles and tenons for the small joints of mathematical instruments, &c., such as fig. 4, the work is usually supported on a small iron platform, the surface of


which is horizontal, with a notch to receive the saw B (worked by the lathe) and a cylindrical stem C · to adapt the platform to the bed-piece of the common rest. This platform is fixed a little below the axis, in order to place the knuckles exactly central to the saw, so as to make the notches equally deep on both sides, and if the surface of the platform is parallel with the axis



of the spindle, the notch is sure to be square with the side of the work. For fig. 4, E, two saws are used upon the same spindle to ensure the parallelism of the sides of the middle piece or tenon. Fig. 6 will also answer the same purpose without a lathe, by passing a pin through the centre hole and working it backwards and forwards in the hinge to be finished.

Kaleidoscope.—Below is a suggested improvement upon the old style of kaleidoscope. It claims to be better inasmuch as the body of it does not require turning. The objects change


by turning the small shaft that drives the wheels. The large one is only a toothed rim, into which is fixed a tin case with a glass at each end, between which are fragments of coloured glass. The



whole is fitted in a box with ground glass at one end and a convex lens on the other.

The simplest form of kaleidoscope consists of a cylinder of

tin, in which two plain rectangular mirrors of polished metal or of glass having the back blackened, are fixed at such angle of inclination to each other as may be obtained by divide ing 360° by the numbers 3, 4, 5, 6, 7, 8, &c. The cylinder covered at one end with a circular plate of metal, having small hole in the centre, while a rim of metal is fitted over the other end, which is so constructed that two circular pieces glass may be fixed in it at a short distance from each other having some pieces of coloured glass, beads, lace, feathers, &c. in the space between them. The piece of glass that is placed at the extreme end of the cylinder should be ground glass, so that while the light is admitted into the interior of the instrument, external objects may be prevented from becoming perceptible to the observer. An angle of 60° is perhaps the best angle of inclination for the mirrors, as it may be readily determined, and affords a sixfold repetition of the pattern, which presents a tolerably uniform appearance of colour in all parts. If the angle of inclination be greater than 60°, the pattern will not be multiplied to so great an extent, but if less, although the pattern will be repeated a greater number of times, it will lose considerably in brilliancy at and towards the parts where the reflections of the pattern meet by the frequency of the



multiplication. In some kaleidoscopes the mirrors are made trapezoidal in form instead of rectangular, the broader ends being placed at the lower end of the tube.

The principle of the kaleidoscope will be understood from the accompanying figure, in which the smaller circle ABC represents a section of the tube of the instrument and AB, AC sections of the mirrors, which ar

represented as inclined to each other at an angle of 60° . The objects in the space a between the glasses are seen directly be the eye, the part of the pattern in the space b is formed by the

reflection of the objects in the space a, in the mirror AB; and the part C, by the reflection of the objects in the space a, in the mirror AC. These reflections are again mutually reflected by the opposite mirrors, and form the part de of the pattern while the images reflected in each mirror for the third time mite in the part f, so as to form a corresponding appearance to the other parts. It is manifest that unless the angle at which the mirrors are inclined be accurately determined the reflections will not coincide, and the pattern will not be complete in the part f.


Kaleidoscopes are made in which the angle of incidence of the mirrors may be varied at pleasure, and by the aid of a lamp and a system of lenses in connection with the instrument, the pattern may be projected on a screen in an enlarged form, like the image thrown from a slide in a magic lantern. pleasing effect of a similar nature, in which the images of the original object are multiplied and produced in different directions, may be produced by fitting the edges of three, four, or six trapezoidal mirrors together, so as to form a hollow prism, and putting them into a tube similar to that in which the two mirrors of the ordinary kaleidoscope are inserted. Instruments

of this kind, which were invented by Roget, are called polycentral G kaleidoscopes.

-To strike out a pair of bevel-wheels.

Bevel - Wheels.


The following is the method of finding the taper or bevel for any line or angle: Let the line AB represent the shaft coming from a wheel, draw the line CD to in-



ersect the line AB in the direction intended for the motion o be conveyed, and this line CD will represent the shaft of the bevel-wheel which is to receive the motion. Suppose, the shaft CD to revolve three times whilst the shaft revolves once, draw the parallel line FE at any moderate tance (suppose a foot by scale), then draw the parallel FG at 3 feet distance, after which draw the dotted line through the intersection of the shafts AB and CD, likewise through the intersection of the parallel line FE FG, to the point H, then FH will be the pitch-line of two b wheels,

Feathering Float.—The following design for a feath float of a paddle-wheel is stated to have the following at tages:—

The float keys are in a vertical position during an e revolution of the wheel ahead or astern, thereby making a



feather.
paddle - who
no heavier
the oldest st
paddle-wheel
has also a
nal-bearer a
extremity o
shaft, whic
a decided
provement c
present I
feathering wheel.

Suppose a to lose her n When all means of ste are lost, the

can be steered by this wheel by angling the floats by r of a handle or wheel conveniently placed on deck, w interfering with the speed of the engines.

Amateur Lens Grinding. — The process of grilenses for telescopes, cameras, &c., is much more simple to usually supposed. If you wish to grind a lens for a tele first determine the length of focus and diameter of lens for

object glass, and make a drawin gon paper; you will then find by the drawing the thickness of glass required. We will suppose you commence on a small lens of $1\frac{1}{2}$ inches diameter and of 15 or 18 inches focus. You must draw two short lines parallel to each other $1\frac{1}{2}$ inches apart, next open a pair of compasses to 5 inches and draw a portion of that curve between the lines, as in fig. 1. Next procure a piece of plate glass of the thickness shown by the drawing, and nibble it round with a pair of pliers, using a circular piece of paper as a guide. Smear one side of the glass with pitch, and stick it on a cylinder of wood of the same diameter and 3 inches high; the crown lens will then be ready for grinding.

The tools for grinding are either of iron or brass, brass being best. Take a piece of thin zinc twice the width of the lens, and with the compasses at 5 inches describe a portion of that curve across the zinc, and separate the zinc at the curve; you will then have a couple of patterns to get the brass tools made by. If you do not possess a turning-lathe, go to a wood-turner's and get two patterns made to fit the zinc gauges; the patterns must have a stud on each, as in fig. 2, whereby to fasten a bit of wood with pitch, to act as a handle. After the patterns are cast in brass they ought to be again turned to fit the gauges, and finally rubbed together with emery until they fit each other. An amateur need not have the tools much larger than the lens.


Next procure from an emery-grinder three kinds of emery, lb. of the finest washed emery, I lb. fine-grained emery (a little coarser than flour of emery), and I lb. coarser still. Begin and rub the glass with the coarse emery with water, using the hollow brass tool until the glass is ground of the same curve as the tool. At this stage you will not be able to see through it, because of the great hollows dug into it by the particles of the coarse emery. Therefore wash away all coarse particles and rub again with the next degree of emery, which will put a finer surface upon it. Wash all this off the glass again, and with the finest emery put the last grain on the glass previous to polishing, using a strong magnifier to look for scratches; being satisfied the lens has a fine equal grain all over and free from scratches, wash all clean and prepare the polisher. Procure lb. of the finest putty powder, warm the brass tool and smear the inside of it with pitch; lay a piece of fine cloth over the lens and turn up the tool with the pitch upon it; the cloth will stick to it, and when cold smear the cloth with the putty powder and water, rubbing the lens until on looking with the eyeglass no trace of the effects of the fine emery is seen. Warm the lens before a fire, slide it off the wooden holder, wash the pitch from the lens with turpentine, spirits of wine, or other solvent, and you will have ground and polished a plane convex lens of 10 inches focus, it being a rule in optics that a lens ground on one side only will have its focus at twice the radius; but ground on both sides, will have its focus at the radial point. You must now turn the other side, taking care of the feather edge as you approach it, by not going so far with the coarse emery. When the second side is finished, you will have a crown lens of 5 inches focus. To make the terrestrial telescope an achromatic one, add a concave lens of flint glass to it.

We will suppose the crown lens is finished; but as its form is thick in the centre and thin at the edge, it will be similar to a circular prism, and would show all objects with the chromatic colours; another lens must therefore be ground that is thick at the edge and thin in the centre, to counteract the dispersive power of the convex lens, and as flint glass has in general twice the specific gravity of crown, and consequently has twice the dispersive power, it will of course do the same amount of work with one-half the angle of the crown lens, as in fig. 3. and so reunite the coloured rays and form again white light, Accordingly grind one from the bottom of a flint-glass tumbler. Grind it on a flat stone to the proper thickness, and also get it to the diameter by taking a strip of sheet iron an inch wide and bend it so as to form a collar; by putting emery and water betwixt the collar and the glass, by pinching the collar with the fingers while the glass revolves on the nose of a wooden chuck, it will be reduced in a few minutes. After it is the proper diameter and thickness, commence rubbing it on the convex tool and finish it in the same manner as before; you will now have a concave side finished which will fit the convex lens: take it off the holder and turn the last side up, and now learn that it is a very difficult thing to grind and polish a surface truly flat, so that you had better grind the last side concave upon a tool of a large radius, say 30 inches. The two glasses must then be cleaned and made warm gradually before a fire: a drop or two of Canada balsam being let fall into the concave

lens, drop the convex one on it, press the air bubbles out, and when the balsam sets you will have a small achromatic lens. The streaks or strize in the bottoms of tumblers are not of so much importance in a terrestrial telescope. Some of the best photographic lenses have air bubbles, and some when accidentally cracked work quite as well as before. In astronomical telescopes the glass must be of the purest kind.

Now take your compound lens and try its focus by the sun, and make the tube 3 or 4 inches longer, so as to support the magnifying tube called the eye-piece. The object lens will form an image of anything within the tube, say the clock-dial of a distant church—the tube called the eye-piece merely magnifies

this image, and a variety of eyepieces may be used for the same object glass, according as a high or a low power is required; in short, a telescope



may be compared to a camera obscura, with a microscope attached, to enlarge the image formed by the object glass.

Now then about the eye-piece. The subjoined formula may be taken, because the lenses for it are all planos, so that you will only have to grind one side of them, if a piece of plate glass be used. Focus of front lens 18ths, ditto of second lens 18ths, ditto of third lens 18ths, ditto of lens next the eye 18th. The first and second lenses may be a little under ½ inch diameter; the third or field lens may be a little more than ½ inch diameter; and the lens next the eye may be about 8ths diameter.

Make two short tubes $1\frac{3}{4}$ inches long (they are called cells), and fix your lenses to each end of the two tubes or cells, then take a tube called the eye-piece $6\frac{1}{8}$ inches long, and slide the two cells into each end of this tube; you will then have an eye-piece which must slide into the larger tube to focus on the mage formed by the object glass.

In the following machine for grinding and polishing speculum, I is the base, f is the worm-shaft which drives the worm-wheel

mu me e namer to a since-when a back of ninery. In tim in a state of and in made with a remailer frange near the retinier in the tree summe or which being more a tree of A ALL US BITTER OF SECURITY SUPPORT IT THE SPECIAL AND BE asten an sawn i de enginere. The wheel c drives nuter a new-viring seen, but attached it the lower surfact. the auto of the greened this is engaged a gen, fixed in the a ver surtant to the cast level a vital is thus made to vibra-The error time a series of boles, to an ಟ್ರಾಮಕ್ಕೆ ಮತ್ತು 🚓 🗈 ne vinan and the national one and affile link, whose other calis connected to the inter or shring-plane B, which thus by THE TOTAL OF THE CORE OF THE TOTAL TO EACH FOR ACCORDING to are recoursed in your national law being that of uniform The rank F marks a strong spinale & on which



vibraces the arm i This arm can be at there either held in position by the connecting-link &, or made to vibrate by in revolution of the TITIDE crank 4 which is driven by a shaft at the back of the slide-plate B. The arm carries a variable crank # which can be driven either quickly by the shaft and pulley & or slowly by the weren-wheel o. The pin of m drives the polisher. If it be recuired to give Lord

Force's action, the crank m being fixed, and its pin set central, the crank l is set in motion; this gives the primary stroke, and the reciprocation of the slide plate B gives that of the eccentric. If the worm-wheel o be made to act, at the same time a light lever attached to m will carry round with a slow motion the polisher by a study projecting at its circumference. If it be wished to have

Mr Lassell's motion the crank / is stopped, and it is fixed in such a position that the pin of m shall be at the required distance (equal radius of S) from the centre of the speculum, the arm i being held firm by the link; the pin of m is next set to the distance which equals radius of G, and it is driven by n. In this case, however, there is no provision to secure the rotation of the polisher. The eccentricity can also be given by means of B, and as it can be made to vibrate slowly on each side of this to any required extent, the effect of Mr Lassell's last improvement is given to perfection. Mr Grubb decidedly prefers the Rossean action for grinding, but thinks the other less likely to fail in the polishing with unpractised hands, and uses it himself. He begins with a large eccentricity, and gradually diminishes it, which can be done without stopping the machine. His polisher is made of wood with peculiar care. It is formed by six layers of mahogany, each 5-16ths of an inch thick, and not continuous, but built up of pieces 3 in. square: these are only glued where they cross, being, at least in the interior, not in close contact at their edges, and the direction of their grain is varied as much as possible. The disc. when turned true, is plugged at the edges, varnished, and coated with tinfoil at the edge and back. It is the same diameter as the speculum. He uses pitch alone, rolls it in the same manner as Lord Rosse, cuts it into squares of 3 in., and attaches them to the surface, warming it by a spirit lamp. The machine measures about 3 ft. every way, and can work a 2 ft. speculum.

Power of Lenses.—The magnifying power of lenses is determined by the focal length and the density of the glass of which they are composed. In the case of a telescope, the power may be calculated approximately by the following rule:—If the focus of the eye-piece be I in., the number of inches in the focal length of the object-glass will give the magnifying power; if the eye-piece be $\frac{1}{2}$ -in. focus, the power will be twice as great as with the I-in., and so on in proportion.

The following is a more full explanation of the mode of ascertaining the power of a telescope. First focus it accurately upon a distant object. If now you turn the object-glass up to the sky, and remove your eye to some distance from the eye end, you will perceive a circular spot of light upon the eyeglass. This is an image of the object-glass, diminished in the exact

ratio of the magnifying power of the instrument. If then you will measure the precise diameter of this image upon a finelydivided scale (assisting your vision, if necessary, by means of a magnifying-glass), and will then ascertain the diameter of your object-glass by the aid of the same scale; the division of the latter sum by the former will give the magnifying power of the instrument. Thus, supposing that the aperture of your objectglass is 2 in., and the little circle of light in the eve-piece is ·08 in. in diameter, the telescope will magnify exactly 25 times; or, assuming that you have a 11-in. object-glass, and that the projected image on the eye-piece measures .08 in. in diameter, your instrument would then magnify 18.75 or about 19 times linear. In obtaining the magnifying power of a single lens, we proceed upon the assumption that the distance of distinct vision is to in. If now we find the focal length of the lens, and divide 10 in, by it, we shall get the magnifying power. For example, a lens of 1-in, focus magnifies 10 times, one of 1-in. focus 20 times, one of 1-in 40 times, and so The focal length of a lens (when not very short) may be obtained with considerable accuracy by projecting an image of the sun upon a card, by means of the lens whose focal length is to be measured, and when such image is accurately defined, measuring the distance between the lens and the card. This may be conveniently accomplished by mounting the card at the end of, and at right angles to the length of, a graduated scale, and sliding the lens along the scale with its diameter parallel to that of the card. In the case, however, of a lens of very short focus, this method becomes impracticable; and we may then have recourse to the admirable mode invented by that excellent astronomer, the Rev. T. W. Webb, which we cannot do better than describe in his words, "Three pieces of cork are perforated by a knitting-needle, so as to slide along To the centre one is attached, in a vertical position, and with its axis parallel to the knitting-needle, the lens to be measured; in each of the others is inserted a piece of a sewing-needle with the point uppermost, and having its length so regulated that a line joining these points would pass, as nearly as may be, through the centre of the lens. The cork discs carrying these needles are then moved backwards and forwards, till the inverted image of the one needle's point, formed by rays passing through the lens, is seen coincident and equally disith the other needle's point, when both are viewed at rough a tolerably strong magnifier applied to the eye. ected towards the lens. Then if the needle-points are r equidistant on each side of the lens, a condition which quite sufficiently attained in the course of a few trials, vident that they occupy the conjugate foci, and the. e between them being carefully measured with comwill be, as a very simple proposition in optics will show, mes the amount of the focal length of the lens for ! rays."

w-Propeller.—The primary consideration of the appliof a screw-propeller to the work it has to do is its ," that is, the length in which the screw-whirl makes a te turn round its central axis, and this "pitch" is either " or "coarser," as the length of the axis AB is shorter or

: or in other as the turns screw are together or apart. It is : that if there "slip," that he screw reill hold upon ter, as a cars screw does board—that ry revolution : screw-pro-1 distance of igth of the the full turn screw will een accomthe If thus the " of the be 40 ft.,

, if from A to B be 40 ft., then every full revolution of the will, if there be no "slip," advance the vessel 40 ft.

by

through the water. From repeated experiments it has determined that the best form which can be given to a is that of two halves of a spiral feather, placed on opposite



in length which they would otherwise require, are f with equal surface, more efficient than the continuous formerly in use. The rectilinear edges AB and C the ordinary screws are highly disadvantageous, on accordinary screws are highly disadvantageous, on accordinary screws are highly disadvantageous, on accordinary screws at the screw caused by the sudden and viole actions of the disturbed water in that place against the lof the screw as they enter and emerge from thence—sing whole of an edge enters and leaves at once the water on side of the aperture; within which aperture the water is paratively in a quiescent state; but if the leading edges of a blade were curved as ApB, GpH, they would slide obliqued continuously through the water. . . . The curved edges



beside, the advantage of ing off any floating ma that may come in c with them" (Sir H Douglas on "Naval W


with Steam"). The pitch of screws vary with the ratio circle described by the screw to the midships section.

For 2-bladed screws (Molesworth's formulæ).

Gyroscope.—To make a gyroscope, get a brassing about 5 in. in diameter, $\frac{1}{2}$ in. broad, and $\frac{1}{8}$ in. having a projection B at one part. On the flat sur the ring, near to B, must be a small lump C, also a just opposite D. These must be screwed on by two small

and are for the purpose of holding the spindle EE, which turn freely on FIG.1.


centres. At iddle of this e must be the disc FF, should be two or three as heavy as ng. A hole be drilled h this spindle ne convenient or the string, nethod of ustring. The



the spindle must be threaded with a piece of string, and

ic turn round,
ig the string
e same as is
with a humtop. The string
drawn sharp, and the disc
to spin rapidly


to spin rapidly
If the inentisthen supby a loop of
or on a point



t will (instead of falling to the ground, as might be supposed) n in a horizontal position, moving round B as a centre. ngraving.) The ring AAA should be placed horizontally. other method, identical in principle, but differing slightly ail, is as follows:—

wheel is brass, turned to the shape shown in sketch; is of the wheel is steel. The wheel is first bored for the ion of spindle; then the spindle is driven in after being its proper length, and drilled with very fine centres; it is turned on its own centres perfectly true. A lathe with ead centres is the best for turning it. After it is turned, ds of the spindle are properly hardened. A small hole

is inserted in one end of spindle for reception of twine. The



way to harden the ends of the spindle is this:—Get a plate of iron about \$\frac{8}{8}\$ in thick, bore a hole in it just large enough to admit the end of the spindle, then place it on the fire (a small slow fire). Fill the upper recess of wheel with cold water, to keep the brass cold.

The ring is made of brass, is about }

in, thick and 1 in, broad, with two bosses in the direction of the centre line. These bosses are bored and tapped about 3-16ths or 1 in. for the reception of steel screws. The ring is bored out, and filled up until the ring is equally balanced; if the ring is not balanced, it will not hang horizontally as it rotates round the point, but the heavy side will hang down, and cause it to "waver." One steel screw is ground to a sharp point at both ends, with a square shoulder to screw it in with. The point of these screws are hardened, the other screw has a square head with a sharp centre drilled in it. A small steel bracket is secured by this screw, as shown in sketch. This bracket has a sharp centre in it made with a sharp centre punch to rest on the point of upright spindle; this bracket is also hardened. The upright spindle is made of steel, screwed into a base of lead, as shown in sketch. The spindle is turned and ground to a very sharp point, then properly hardened. The wheel will not only revolve horizontally round the point, but will revolve when placed perpendicular by placing the centre in head of screw (as shown) on the point of spindle; it will also spin on the point of the other screw if placed on a plate or any smooth surface. After the points of spindle or axis of wheel are hardened, the points of screws being soft, the wheel is spun round a few times to grind the centres to fit each other. After that the points of screws are hardened.

Telescope, to Make.—To make a Galilean telescope the following articles are required:—A double-convex lens of 5-ft. focus and 2-in. diameter; a double-concave of 1-in. focus and about 1-in. diameter; a large tube of tin-plate, zinc, or cardboard, 4-ft. 8 in, long, and 3 in. diameter; a cylinder of wood, turned to fit tightly in one end of the large tube, and having a central hole of about 1 in. diameter bored through it; and a small tube for the eyeglass 6 in. or 8 in. long, and of just sufficient diameter to slide into the central hole of the cylinder: The section will

explain the use of these articles. A is the large tube; B, the object-glass; C, the wooden cylinder; D, the

eye-tube; and E, the eyeglass.

The object-glass and eyeglass must be at a distance from each other equal to the difference of their focal lengths, and the power will be equal to the number of times the focal length of the eyeglass is contained in that of the object-glass. In the present case this is 60.

Tin-plate is the best and cheapest material for the tube, but in reality it matters little of what it is made, so that it be straight and not too heavy. Its interior should be coated with a mixture of lampblack and turpentine. A diameter of three inches is best, in order to decrease the liability of flexure which very narrow tubes possess, and also to give more facility in

mounting the object-glass.

In purchasing this article, it is much the better plan to buy one from the optician already centred; but if such cannot be obtained, one should be selected the edges of which possess an uniform thickness. In such a one the optic axis will not be very far from the actual centre. In mounting it, glue it between two circular rings of cardboard, whose outer diameters just fit the large tube, and with a central circle cut out of each 1½ in, in diameter. The lens must be fastened between these, so that its centre will coincide as nearly as possible with the centres of the cardboard circles. It should be placed an inch or two within the tube, as it is then better defended from injury than when at the very extremity.

A ring of iron wire soldered within the tube will do to rest

the mounted lens upon, and another ring of wire pushed down upon it will hold it firmly in its place. These rings are shown in the section by the four black dots, two on each side the cardboard mounts of the object-glass. The eyeglass may be fitted in a similar manner. The length of the wooden cylinder should not be less than 2 in.

In making the Galilean, or any other telescope, the one great thing to be attended to is to keep the centres of all the lenses coincident with the axis of the tube, and their planes at right angles to it. . Inattention to this is certain to injure the performance of the telescope, however good its glasses may Most of the failures in amateur-made telescopes that have come under my eye have arisen from this cause. It will be seen that a first requisite to success on this point is to make the tube perfectly straight and rigid, and its section perfectly circular. The wooden cylinder should be turned perfectly true. the hole drilled through it perfectly central, and not the slightest lateral play allowed to the small eve-tube. Though in none of these particulars is absolute perfection attainable, yet any one making a telescope should never forget that the nearer he can approach it, the more satisfactory will his instrument be.

There is one point to which the attention of all beginning to handle lenses should be directed, and that is, to avoid wiping and rubbing as much as possible. Remove any dirt that may fall on the glass by blowing it away, and remember that the definition of a telescope is much less injured by a deposit of dust on the object-glass than by the numberless small scratches which much wiping invariably causes.


The cost of this telescope is as follows:—Object-glass, 2s.; eye-glass, 1s.; tube (if home-made) of tin-plate, 1s. 6d.; wooden cylinder, lampblack and turpentine, say 6d more; total, 5s. It will show well Jupiter's moons, and more conspicuous belts, Saturn's ring, and one or two α his moons on favourable nights, the phases of Venus and Mars, the hills and valleys of the lunar surface, and the solar spots splendidly, together with many nebulæ and double stars.

A stand for our telescope must not be forgotten. A poor telescope on a good stand is greatly superior to a good tele scope or a poor stand.

Telescope Stand.—An excellent stand was made a few years ago on the following model:—

It is made of deal; the advantages are steadiness, the work being thrown into triangles, the steadying cords and weights

checking all vibration. The spindle may be placed and adjusted to the position of a polar axis, and by fixing pins on permanent blocks in the ground, with brass sockets on the bottom of the legs, the stand may be always placed in the same position. There may be various changes in the position of the cords and weights. The first use made of them was to steady the end of the telescope put through a window by cords and weights in the



position figured, where CCC are cords, and T telescope.

Made in two movable parts, feet of one A, of the other BB; hinged together at HH; E, screw-bolt; F, cross-piece from fore to hind part; CCC, steadying cords, with weights W and W¹, the latter running on pulley P; SS, spindle turning in brass bearings; Y, iron supporting the sides of telescope on two screw-pins.

The Y spindlehead suspending the sides of the telescope is much steadier than a swivel-joint




under the telescope tube. Height to pivots of telescope 6 ft.

A good "Dead-Black" for Telescopes, Cameras, somewhat troublesome to make. Take some ordinary polish, or dissolve some shellac in methylated spirit, ar lampblack until the happy medium is attained, that applied to a piece of warm brass, it shall dry a dead-black it dries with a dead-black surface which rubs off, more or shellac must be added; if it dries bright, more lamp

Another plan is to put the brass-work into dilute nitr to take off any oxide, and put it into a solution of bic of platinum; when it has changed colour, brush the sharply up with a brush and dry blacklead, after lacquer it.

A third method is to take lampblack and mix it with and just sufficient size to keep it from rubbing off.

To Cut Microscopic Sections of Wood.—The fol engraving is half-full size of a machine for cutting thin so of objects for microscopic examination, which has been for some years, and which is one of the cheapest, simple



most effectual that could AB represents a vised. of 1-in, brass tubing, flange CD, of about 21 diameter, at the end A, and a female screw tapped at the to receive the capstan-headed E: F is a brass plug or which is driven up the tub perfectly obvious way by the E. This screw has 30 thre the inch. A razor ground one side, to slide accurate the upper surface of the flan (which must itself be quite completes the apparatus.

The mode of using it is simply this:—The wood, or substance of which a section is to be made, is to be down the tube at A. The screw is then turned until the to be cut projects slightly above the mouth of the tube, a razor is slidden across it, taking off a slice of the material, and reducing it to a level with the surface of the flange. By turning the screw again to a small extent, and again sliding the razor (which should now be wetted) across the flange, it is perfectly clear that we may remove a slice of wood of any tenuity we please, its thickness being regulated by the extent to which the screw is turned. The sections thus made may be conveniently washed off into a cup of water, to be taken out as required.

Several more or less elaborate pieces of mechanism may be purchased at the optician's, at prices varying from 15s. to £4; but none will do their work more effectually than that described, which ought not to cost more than six or seven shillings.

Another Cutting-Machine.—B, a block of wood with a hole, into which is fitted C, a brass tube; D, a brass plug or lift accurately fitted, and having two studs S to work in corresponding slots in C; E, an iron pin without head fixed with D—pitch

25 threads; H, a
brass nut, the top
fitted to C, through
it works E. The
nut has two collars
or flanges, M and N,
and between is O, a
split collar, which is
screwed on to the
box B. This collar
keeps the nut in
place, and yet allows

it to be turned; XX, two studs to turn the nut H; Z, a bending screw to keep object in place; T, a bench clamp; A,

brass plate on which to cut.

The great advantage in this construction is the pin and plug moving (up and down) vertically without turning or twisting in the tube or cylinder more than the fractional ease of the slots in which the studs work. The plug being fitted nicely to the cylinder, and the pin fixed into it, and the nut working nicely in the collar, gives a firmness not to be obtained in machines in which the pin turns. The pitch of the screw is 25, therefore a quarter turn of the nut gives the 100th part, and an eighth turn the 200th part of an inch.

The cutter is a spokeshave with the ends turned and fitted into handles. The hollow, or under side, on t is used, the face of the plate being very flat and straigh inventor of this machine prefers the under side of a cutter not flat, as recommended by many. There is less a resistance, and no slipping, as with the perfectly flat su


Hints on the Microscope.—A mechanical stage is qua non, and plenty of room beneath it for the illun apparatus. This stage should not be thicker than the an inch, a mere plate with a wide hole, say 2 in. squ milled hands and tangent screws being all placed beh frame, easy to get at, and out of the way of the objects.

This form does not admit of a circular motion, but v not yet learnt the real value of such a motion, while the tages of a thin stage are unspeakable.

A Coddington lens, or an eye-piece on Kelner's possesses a good condenser, and only cone eye-pieces are using; if you desire higher magnification, either get a power or lengthen your tubes.

An economic condenser made by an amateur micr is shown in the following sketches:—

Fig. 1.—A, spot-lens, about \frac{1}{2}-in. focus; B, ach



spot-lens, a in focus. at about th distance a Kelner eye a tube C, in a flat metal D, supported (plate G, by a hold allowing r tween for phragm F volve freel axis, which

by a screw passing through a holdfast into the plate (a tube $\frac{3}{4}$ in, long for carrying polariscope.

Fig. 2.—DIAPHRAGM.—A, for direct light; B, for difficult

test-objects; C, darkground illuminator; D, small aperture, with shutter E, having a small hole in The features presented by this condenser are that it is applicable for both high and low powers, can be used by merely sliding it into a tube under the stage, and never need be removed except for cleaning. For a micrometer, the following plan,




Fig. 2.

which any one can adopt, and requires no apparatus, is quite effective.

Find the exact size of your field by looking at a footrule laid beside your stage with the one eye, while the other is applied to the pipe; say it gives I ft. Now put the rule on the stage, and see how many divisions of an inch fill the field; suppose it is the inc in this assumed case, this object-glass, with the same length of tube, will magnify 96 linear, therefore all objects viewed will be increased to that extent.

Your instrument must be steady, the fine adjustment very fine, the spring very light, and the tube into which the object-glass is screwed, and which the adjustment moves, very true, and also very easy to lift, so that a coarse hand may neither damage the instrument nor object, and each turn ought to raise or depress it 1-100th of an inch, and so become a micrometer to measure depth.

For a camera lucida, get two bits of neutral-tinted glass, and place them at an angle of 45° before the eye-lens. A little practice will enable you thus to use the binocator, and the ease to the eyes is immense.

For polariscope, use a short white Nicol's prism, set so as to turn in a tube, and to which tube you can screw the object glass.

A number of large squares (16 or 20, $\frac{7}{8}$ size) such as we cow objects with, form the best analyser. The polariscope is, how ever, except in the hands of the chemist, pretty much a toy.

It is a great mistake to have slides in any numbers; have many compressioriums, lots of bottles and small tanks, and eschew diatomacæ valves. Wherever you go, carry a nail o two and an old lucifer-box, a walking-stick and a bit of string; tie a vial to the stick, and dip from top, bottom, and middle of every permanent water-hole; when you find a small insect, put him in the box. Your walks will be all pleasure, and you evenings both pleasure and instruction. Make for yourself al your apparatus; never mind the polishing, but make all good and true as to the brass, &c.; put all the polish on the glasses, and begin with a 2 in. and a 1-in.; the glass of moderate angle it much preferable to the ground 1708 lenses. These latter can not be illuminated by annular condensers, and thus the pretties and pleasantest way of viewing an object is lost. The "celia" of the Feloscalaria ornata, for instance,

Keep in your small tanks a few roots of Zitella, and Valis neria: both are good for the infusoria, and charming objects it themselves. From the air, ground, river, pond, or sea, ge your objects; remember that slides once seen become tire some.

Mathematical Instruments, &c. — All polished stee instruments are best kept from rust by enclosure in wool The high conducting power of metal causes easy condensation of moisture (the cause of rust); wool is a good non-conducto of heat or cold.

Weather-Glass.—Various experimental barometers have from time to time been constructed, all with the view of combining economy with simplicity in a greater degree than is obtained in the ordinary weather-glasses of commerce.

A simple barometer may be made as follows:-

A wide-mouthed glass bottle is filled with ordinary drinkin water up to the point indicated by the letter A; into this i dipped an inverted clean oil-flask, the extremity of the nec being allowed to dip just below the surface of the water.

The flask should be inverted quite empty during wet weather and as long as the atmosphere remains in a stormy condition no change in the water takes place; but immediately the

weather becomes finer, the water will rise in the neck of the inverted oil-flask, and if a continuance of

fine weather be probable, will rise to the

point indicated by letter B.

This simple contrivance gives sure and early warning of the approach of rain.

The principle upon which this little weather-glass acts is exactly similar to that of the ordinary mercury barometer, the rise and fall of the water due to the respective increase or decrease of atmo-

spheric pressure.

By dividing the neck AB into six or eight divisions with the aid of a diamond or piece of flint, and then marking the lines so cut with ink, an approximate graduation of degrees of pressure may easily be obtained,



Cements and Glue.-Below are given a variety of cements to join anything from a millband to a knife-handle. The relative proportions are given in each case, and the directions for mixture and application must be strictly followed.

Cement to join Leather or India-Rubber. - To unite pieces of leather or india-rubber, use either of the following:-

One ounce of caoutchouc cut in thin slices, and placed in a tinned sheet-iron vessel, with six or seven ounces of sulphide of carbon; the vessel is then to be placed in a watertank, previously heated to about 86° Fahr. To prevent the solution from becoming thick and unmanageable, mix with a solution consisting of spirits of turpentine, in which half an ounce of caoutchouc in shreds has been dissolved over a slow fire, and then a quarter of an ounce of powdered resin, from an ounce and a half to two ounces of turpentine being afterwards stirred in in small quantities.

Put a small quantity of virgin or native rubber, cut into shreds, into a wide-mouthed bottle, and pour over it benzine until the bottle is about three-quarters full. The rubber will, if often shaken, in a few days assume the consistency of honey, with a thick sediment at the bottom. If not thoroughly dissolved more benzine must be added. The benzine must be of the best quality, and free from oil. Except when using, the bottle containing this cement must be kept well corked.

This cement dries in a very short time, and three coats applied in the usual manner will serve to unite anything eitherin leather or rubber.

Dissolve gutta-percha (I oz.) in bisulphide of carbon (6 oz). Apply the solution to both surfaces to be joined, allow to dry, which will take a few minutes; then place a hot iron near enough to just melt the gutta-percha on both surfaces; immediately press them well together, through rollers or under pressure. Leather fastened in this way does not need sewing. [A hose-pipe can only be joined in one way—the broken part cut out, the edges made square, a short piece of brass tube—fitting the hose tightly—inserted, and the two ends brought together over it, and bound tightly with copper wire].

Another excellent cement for millbands, &c., is—To 4 oz. of bisulphide of carbon add ½ oz. india-rubber, and ½ oz. gutta-percha, cut in shreds; place the whole in a half-pint bottle, well corked. It will dissolve without heat in about 12 hours, and be ready for use. The parts to be joined must be thinly coated with the solution, and allowed a few minutes to dry; then heat to melting, very quickly place together, and well hammer the air-bubbles out; the joint will be nearly solid, and has been proved perfect. The parts to be joined should be thinned down a little, so as to make an even splice; and the vessel containing the cement kept, tightly corked, in a cost place.

Coment for Tracings.—Take I oz. of isinglass glue, and I oz. of glue made of parchment, 2 drachms each of sugarcandy and gum tragacanth. Add I oz. of water, and boil together till mixed; when cold, form into little cakes. When to be applied, the glue may be wetted on a bit of sponge, and rubbed on the edges to be cemented; they will readily cohere on pressure.

Cement for Uniting Wood with Metals, Glass, Stone, &c.—Dissolve glue in boiling water, and make it of the same consistence as cabinetmaker's glue; then add, while stirring, a sufficient quantity of wood ashes to produce a varnish-like mixture. While hot, the surfaces to be united must be covered

or coated with this glue compound, and firmly pressed together. When cold, the joint will be strong, and the article ready for use.

Chemical Cement.—By melting together 2 lbs, of wax, 10 lbs, of resin, mixed with 4 oz. of plaster of Paris, and 2 lbs, of red ochre, an excellent cement can be made to serve for chemical and electrical apparatus.

Cement for Fixing Metal, Glass, Porcelain, &c.—The following is a simple and useful cement, having also the additional recommendation of cheapness. Make a tolerably strong solution of alum, stir into it plaster of Paris, until the liquid becomes of the consistency of cream, and use while in a liquid state.

This cement may be used for fastening brasses on lamps, &c.

Cement for Mother-of-Pearl, &c.—In 60 parts of water dissolve 4 parts of white glue and 2 parts of isinglass; then strain and evaporate until its volume is reduced to \(\frac{1}{6}\text{th}\); add \(\frac{1}{17}\text{th}\) part of gum mastic dissolved in 1 part of alcohol, and 2 parts of zinc. When required for use, it requires to be warmed and shaken.

Glue that will Resist the Action of Water.—Boil 1 lb. of common glue in 2 quarts of skimmed milk,

Cement for Glass that will Resist Heat.—Equal parts of wheat, flour, glass, and chalk, finely powdered; to this mixture add half as much brick dust, and a little scraped lint in the white of eggs.

Cement for Aquaria.—Any of the following cements may be used to prevent leakage :—

1. 1 pint fine white sand, 1 pint litharge, 2ds of a gill of finely-powdered resin. Mix well, and keep in a corked bottle. When used, it requires to be mixed with boiled oil and driers, until of the consistency of putty. Do this mixing in quantities just sufficient for each piece of glass, as it dries very quickly.

2. Boiled oil, red and white lead, and litharge mixed together,

and spread on a flannel, and placed on the joints.

3. 2 oz. benice turpentine, and solution of glue 1 lb. Boil these together, stirring the whole time until perfectly mixed.

This cement sets slowly, and the joints require to be kept together for two days.

4. Collins' cement, which is elastic, waterproof, and harmeless, dries very quickly. When used, it should be cut up into small pieces about the size of a pea, and laid along the joint; a heated wire then being applied, the cement will run into a continuous strip along the joint.

Fire and Water-Proof Cements.—1. Take 2 parts of finely-sifted, unoxidised iron filings, mix with 1 part of perfectly dry and finely-powdered loam, and knead the mixture with strong vinegar until a perfectly homogeneous plastic mass is formed, when the cement is ready for use. It must be made as wanted, for it quickly hardens, and, once set, is never fit for use again.

2. A very excellent cement for smaller articles is made thus:
—Soak 2 drachms of cut isinglass in 2 oz. of water for twenty-four hours; boil to 1 oz., add spirit of wine 1 oz., and strain through linen. Mix this, while hot, with a solution of 1 drachm of mastic, in 1 oz. of spirit of wine, and triturate with drachm of powdered gum ammoniac, till perfectly homogeneous.

Postage-Stamp Gum.—The gum used for stamps is what is called British gum, which is made from starch; its propes name is dextrine C₁₈H₁₀O₁₀; it is usually made by heating commercial starch suddenly to 320°; anhydrous starch requires a temperature of 400°, and maintaining it at this heat for some time. The soluble product is dextrine or British gum, or the leiogomme of the French. Dextrine may be prepared on a large scale, of a much lighter colour, by the following process:—10 parts starch mixed with 3 of water, containing 1-150th of its weight of nitric acid, allowing the mixture to dry spontaneously, and then spreading it upon shelves to the depth of 1½ in., and heating for an hour or hour and a half wabove 240°.

Coment for Hot-Water Pipes.—Ram on to the flange a few strands of tarred rope, and fill up with iron boring cement, and ram in well.

Cement for Joining Steam Pipes.—Boiled linseed of litharge and whitelead, mixed up to a proper consistence

and applied to each side of a piece of flannel, linen, or even pasteboard; and then placed between the pieces before they are brought home, as it is called, or joined. The cement is useful in joining broken stones, seams of water cisterns, &c.

Cement for Joining Steam Joints.—Sal ammoniac, 2 oz.; sublimed sulphur, 1 oz.; fine cast-iron turnings, 1 lb.; mix in a mortar, and keep dry. When to be used, mix with twenty times its quantity of clean iron turnings or filings, and triturate the whole in a mortar. Then wet with water until of a convenient consistence.

Red Putty for Steam Joints.—Stiff whitelead worked well in redlead powder.

Durable Cement,—Common clay well dried and powdered, then mixed with boiled linseed oil: it will last years. Mix ground whitelead with as much powdered redlead as will make it the consistency of putty. Mix equal weights of redlead and whitelead with boiled linseed oil to a proper consistence. These three cements mend stones well, however large,

Liquid Glue.—White glue, 16 oz.; dry whitelead, 4 oz.; soft water, 2 pints; alcohol, 4 oz.; stir together, and bottle while hot.

Varnishes .- In accordance with the nature of the solvent. varnishes are called spirit varnishes, turpentine or volatile oil varnishes, or fat oil varnishes. The first of these, whose solvent is sometimes ether or chloroform, but more commonly spirits of wine or wood spirit, dry off rapidly. These are very thin in coat when dry, and are best suited for paper, fans, or any very fine work requiring perfect transparency in the varnishes. Volatile oil varnishes, in which the solvents are spirits of turpentine, or coal naphtha, or the like, are those mostly employed by the oil painter. What is called "French varnishing," so much employed upon the wood of furniture, &c., consists in the application of alternate films of lac varnish and of linseed oil, with constant and sufficient friction to polish the compound film of spirito-fat oil varnish as soon as it has become thick enough to afford a glossy surface, the total thickness being exceedingly small. The method of varnishing employed by the carriage-builder for his finest work is the very opposite of this. Over his last coat of paint he lays on coat after coat of copal or dammar varnish, until he has got a considerable thickness, often nearly $\frac{1}{10}$ th of an inch. When this to its full depth has got hard and perfectly vitreous in the warmth of the "varnishing-room," the whole surface is literally ground off with pumice-stone and water until a perfect form, as to contour, and a perfect superficies have been procured, when the glossy face of the varnish is then polished by putty powder, chamois skins, the hand, &c., just as a plate of looking-glass is polished.

Black Japan Varnish.—1. Boiled oil, I gallon; amber, 8 oz.; asphaltum, 3 oz.; oil of turpentine, as much as will reduce it to the thinness required.

2. Take pitch 50 lbs., dark gum amber 8 lbs., melt this, and add linseed oil 12 gallons. Boil this, and add 10 lbs. more gum amber, previously melted and boiled with 2 gallons of linseed oil, 7 lbs. each of litharge and redlead, and boil for two hours, or until a little of the mass can be rolled into pills; then withdraw the fire and thin the varnish as required for use with turpentine.

Varnish for Coloured Drawings.—Take 4 oz. of spirits of turpentine, and mix with 2 oz. of Canada balsam. Size the picture with a solution of isinglass in water. When this is dry, lay on the varnish with a camel's hair brush.

Varnish for Paintings.—Take mastic, 6 oz; pure turpentine, $\frac{1}{2}$ oz; camphor, 2 drachms; spirits of turpentine, 19 oz.; add first the camphor to the turpentine. The mixture is made in a water-bath; when the solution is effected, add the mastic and the spirits of turpentine near the end of the operation; filter through a cotton cloth.

Varnish for Glass.—Dissolve gum adragant in the white of eggs, beat up well, and lay it on the glass with a soft brush. The gum will take about twenty-four hours to dissolve.

Aniline Black Varnish.—The following is an approved Parisian varnish:—In a litre of alcohol, 12 grammes of aniline blue, 3 grammes of fuchsine, and 8 grammes of naphthaline yellow are dissolved. The whole is dissolved by agitation in less than twelve hours. One application renders an object

ebony black. The varnish can be filtered, and will never deposit afterwards,

Paper Varnish.—Below we give an excellent method of varnishing paper. First prepare the following varnish:—Pound very fine 4 oz. white sealing-wax, and after having sifted it through a lawn sieve, dissolve it in 2 oz. of alcohol. To dissolve, the ingredients must be put into a large bottle, and be shaken frequently during the space of forty-eight hours. Give your work two coats of a size made by boiling parchment cuttings in clear water, observing to do it quickly. When dry, apply the above varnish.

To Varnish Rarefied Air Balloons.—With regard to tarefied air machines, first soak the cloth in a solution of sal ammoniac and common size, using 1 lb. of each to every gallon of water; and when the cloth is quite dry, paint it over on the inside with some earthy colour, and strong size or glue; when this paint has dried perfectly, it will then be proper to cover it with oily varnish, which might dry before it could penetrate quite through the cloth. Simple drying linseed oil will answer the purpose as well as any, provided it be not very fluid.

Copal Varnish.—One of the best preparations for this varnish is the following:—Dissolve 1 oz. of camphor in 1 quart of alcohol, put it in a circular glass, and add 8 oz. of copal in small pieces; set it in a sand heat until it is dissolved, so regulated that the bubbles may be counted as they rise from the bottom, and continue the same heat until the solution is completed. Camphor acts more powerfully upon copal than any substance yet tried. If copal be finely powdered, and mixed with a small quantity of camphor, in a mortar, the whole soon becomes one tough, coherent mass.

Colourless Varnish with Copal.—To prepare this varnish, which can be applied to wood, metals, &c., the copal must be picked; each piece is broken, and a drop of rosemary oil poured on it. Those pieces which on contact with the oil become soft are the ones used. The pieces being selected, they are ground and passed through a sieve, being reduced to a fine powder. It is then placed in a glass, and a corresponding volume of rosemary oil poured over it; the mixture is then stirred for a few minutes until it is transformed into a thick

liquor. It is then left to rest for two hours, when a few drops of rectified alcohol is added and intimately mixed. Repeat the operation until the varnish is of a sufficient consistency; leave to rest for a few days, and decant and clear.

Varnish for Perforated Zinc.—I dwt. of Canada balsam, thinned with spirits of turpentine until it is the consistency of milk. Then with a camel's hair flat brush sparingly varnish the perforated zinc. It does not require to be made warm, as articles do which have to be lacquered. It is this varnish which is usually made use of in fixing and covering the silvered parts of clock faces.

Wood Varnish to Resist Boiling Water.—Boil 3 lbs. of linseed oil in an untinned copper vessel. While boiling, suspend in the oil a bag containing 6 oz. of minium and 10 oz. litharge, both finely powdered, so that it will not touch the bottom of the vessel. When the oil has acquired a deep-brown colour, take out the bag and replace it by one containing a small piece of garlic. Melt 2 lbs. of yellow amber with 4 oz. of linseed oil, and throw into the vessel. Let the whole boil for about four and a half minutes, stirring well. After it has rested awhile, decant it; and when cold, pour it into stoppered bottles.

The wood having received the necessary colour, and having been properly polished, four coats of the above should be laid on with a fine sponge.

A method of coating wood with a varnish as hard as stone has been recently introduced: the ingredients are—40 parts of chalk, 40 of resin, 4 of linseed oil, to be melted together in an iron pot. I part of native oxide of copper, and I of sulphuric acid, are then to be added, after which the composition is ready for use. It is applied hot to the wood with a brush, in the same way as paint, and as before observed, becomes exceedingly hard on drying.

Varnish for Wood Patterns.—3 oz. of shellac, $1\frac{1}{2}$ oz. of resin, dissolved in a pint and a half of wood naphtha.

French Polish.—Any of the following receipts for French polish may be used:—I. Shellac, I lb.; naphtha, 2 lbs.; dragon's blood, 3 oz. 2. Shellac, 15 oz.; powdered mastic, $\frac{1}{2}$ oz.; sandarac, $\frac{1}{2}$ oz.; copal varnish, 5 oz.; methylated spirit, 2 lbs. 3. Shellac, 22 oz.; spirit of wine, 4 pints;

cod-liver oil, 2 oz. 4. Spirit of wine or naphtha, 1 pint; gum, $\frac{1}{2}$ oz.; shellac, 3 oz.; dissolve with a gentle heat, and add 2 oz. of oil of sweet almonds. 5. Shellac, 1 oz.; oxalic acid, 1 drachm; naphtha, 4 oz.; dissolve, and then add $\frac{1}{2}$ oz. of linseed oil. 6. $1\frac{1}{2}$ lb, shellac to 1 gallon spirit is a good proportion; naphtha should be used only for coarse work. Methylated spirit is much preferable. No better polish is made than that with shellac alone, but in finishing, let the work, if small, and can be conveniently done, be warmed.

Varnish for Violins,-The varnish most used for violins is what is called a "fat" or oil varnish, made with amber. This is the most insoluble of gum resins, and, in its natural state. soluble only in chloroform. It contains an essential oil, oil of amber, and, until deprived of this by the process of melting, cannot be mixed or dissolved in spirits of turpentine. To form it into a varnish for violins, melt it very carefully in a sandbath. A small iron saucepan half-filled with sand, in which a small thin cup is embedded to contain the amber, which should be coarsely powdered, will answer the purpose. If black smoke comes from the melting amber, the heat is too greatthe amber is burning; the right heat must be found by trial, it will be pretty well marked by the smoke or vapour being light-coloured or white. This indicates the evaporating oil of amber, which may be condensed if a retort and receiver is used. The vapour has a very powerful penetrating smell, A small quantity of amber will suffice, say I drachm, to make varnish for two or three violins. The amber, when sufficiently melted, will, when cool, be of a dark-brown colour, and in small brittle flakes. In this state put it into a small bottle with camphine (the best spirit of turpentine procurable), sufficient for solution (about four times the bulk of the prepared amber). Allow the mixture to remain a day or two, with occasional shaking; then add best drying linseed oil, equal to 1th part of camphine. Size your violin, and get the grain of the wood thoroughly smooth, and apply the varnish with your finger on a warm sunny day, exposing the violin to the sun and air. A number of coats will be required, but a second should not be put on until the first is dry. Colouring-matter may be rubbed up with a palette knife, and some of the varnish, but there is great difficulty in laying the colour on smoothly.

Friction Polish.—A good polish for iron or steel rotating in the lathe is made of fine emery and olive, sperm, or neat's foot oil. Apply by lead or wood grinders, screwed together.

Soft Varnish.—For a good soft varnish, take linseed oil, 4 oz.; and $\frac{1}{2}$ oz. each of gum benzoin and white wax. Boil to two-thirds.

Dryers.—Grind I lb. of white copperas, I lb. sugar of lead, and 2 lbs. whitelead with boiled linseed oil. Boiled or drying oil is linseed oil mixed with powdered litharge, and heated till it becomes thick. A "pale" drying oil is obtained by mixing with linseed oil sufficient dry sulphate of lead to form a milky liquid, and shaking it repeatedly for some days, letting it stand exposed to the light. When it has become quite clear, it may be poured off from the dregs. The sulphate of lead, when washed from the mucilage, may be again used for the same purpose.

Vehicle for Colour.—A good vehicle for colour is made by boiling shellac and borax in water. This solution may be used as a varnish, and, mixed with lampblack, forms an ink which will resist almost any acid.

Substitute for Brewer's Pitch.—Coat twice the inside of a barrel with a solution of $\frac{1}{2}$ lb. of rosin, 2 oz. of shellac, 2 lbs. of turpentine, and $\frac{1}{2}$ oz. of yellow wax in 1 quart of strong alcohol. After the complete drying of the second coat, give a last coat by applying a solution of 1 lb. of shellac in 1 quart of strong alcohol. This varnish will perfectly cover up the pores, and does not crack off or impart a foreign taste to the beer.

Lacquers.—Lacquers are used upon polished metals and wood, to impart the appearance of gold. As they are wanted of different depths and shades of colours, it is best to keep a concentrated solution of each colouring ingredient ready, so that it may at any time be added to produce any desired tint. Lacquer should always stand till it is quite firm before it is used.

1. Deep Golden-coloured Lacquer.—Seed lac, 3 oz.; turmeric, 1 oz.; dragon's blood, ½ oz.; alcohol, 1 pint. Digest for a week, frequently shaking. Decant and filter.

2. Gold-coloured Lacquer,-Ground turmeric, 1 lb.; gam-

oge, $1\frac{1}{2}$ oz.; gum sandarac, $3\frac{1}{2}$ lbs.; shellac, $\frac{3}{4}$ lb. (all in owder); rectified spirits of wine, 2 gallons. Dissolve, strain, and add 1 pint of turpentine varnish.

3. Red-coloured Lacquer.—Spanish anatto, 3 lbs.; dragon's ood, 1 lb.; gum sandarac, 3½ lbs.; rectified spirits, 2 gallons; repentine varnish, 1 quart. Dissolve and mix as the last.

4. Pale Brass-coloured Lacquer.—Gamboge, cut small, 1 oz.; ape aloes, ditto, 3 oz.; pale shellac, 1 lb.; rectified spirits, gallons. Dissolve and mix as No. 2.

5. Seed lac, dragon's blood, anatto, and gamboge, of each lb.; saffron, 1 oz.; rectified spirits of wine, 10 pints. Disolve and mix as No. 2.

Excellent lacquers are also made by the following receipts:—
1. Gold Lacquer.—Put into a clean 4-gallon tin 1 lb. ground armeric, $1\frac{1}{2}$ oz. of powdered gamboge, $3\frac{1}{2}$ oz. of powdered m sandarac, $\frac{3}{4}$ lb. of shellac, and 2 gallons of spirits of wine. Iter being agitated, dissolved, and strained, add 1 pint of arpentine varnish, well mixed.

2. Red Lacquer.—2 gallons of spirits of wine, 1 lb. of dragon's lood, 3 lbs. of Spanish anatto, $4\frac{1}{2}$ lbs. of gum sandarac, pints of turpentine. Made as No. 1 lacquer.

3. Pale Brass Lacquer.—2 gallons of spirits of wine, 3 oz. of ape aloes, cut small, 1 lb. of fine pale shellac, 1 oz. of gamoge, cut small, no turpentine varnish. Made exactly as before.

Those who make lacquers frequently want some paler, and ome darker, and sometimes inclining more to the particular int of certain of the component ingredients. Therefore, if 4-oz. vial of a strong solution of each ingredient be prepared, lacquer of any tint can be procured at any time.

4. Pale Tin Lacquer.—Strongest alcohol, 4 oz.; powdered armeric, 2 drachms; hay saffron, I scruple; dragon's blood a powder, 2 scruples; red saunders, ½ scruple. Infuse this aixture in the cold for forty-eight hours, pour off the clear, and train the rest; then add powdered shellac, ½ oz.; sandarac, I drachm; mastic, I drachm; Canada balsam, I drachm. Dissolve this in the cold by frequent agitation, laying the bottle on its side, to present a greater surface to the alcohol. When dissolved, add 40 drops of spirits of turpentine.

5. Deep Gold Lacquer.—Strongest alcohol, 4 oz.; Spanish anatto, 8 grains; powdered turmeric, 2 drachms; red saunders, 12 grains. Infuse and add shellac, &c., as to the

pale tin lacquer; and when dissolved, add 30 drops of spirits of turpentine.

6. Another Gold Lacquer.—Seed lac, 6 oz.; amber gum, guttæ, 2 oz. each; extract of red sandal-wood in water, 24 grains; dragon's blood, 60 grains; oriental saffron, 36 grains; pounded glass, 4 oz.; pure alcohol, 36 oz. Grind the amber, the seed lac, gum guttæ, and dragon's blood on a piece of porphyry; then mix them with the pounded glass, and add the alcohol, after forming with it an infusion of the saffron and an extract of the sandal-wood. Then grind all thoroughly. The metal articles destined to be covered by this varnish are heated, and such small articles as will admit of it, as small cases, watch keys, &c., are immersed in packets. The tint of the varnish

Before Lacquering Brass boil it in a solution of potash and soda, after which dip them in aquafortis, 3 parts water. Then wash them in two different waters, and rub them through sawdust. Then place on a gas stove. When warm, brush and put the lacquer on. After this operation is complete, the work is put back on the stove with a piece of brown paper over it. You can burnish or pick out, as you please.

may be varied by modifying the doses of the colouring substances.

Good Lacquer for Brass.—Seed lac, 6 oz.; amber of copal, 2 oz.; best alcohol, 4 gallons; pulverised glass, 4 oz.; dragon's blood, 40 grains; extract of red sandal-wood, obtained by water, 30 grains.

Pale Lacquer for Tin Plate.—Best alcohol, 8 oz.; turmeric, 4 drachms; hay saffron, 2 scruples; dragon's blood, 4 scruples; red saunders, I scruple; shellac, I oz.; gum sandarac, 2 drachms; gum mastic, 2 drachms; Canadabalsam, 2 drachms; when dissolved, add spirits of turpentine, 80 drops.

Lacquer for Philosophical Instruments.—Alcohol, 84 oz.; gum gutta, 3 oz.; gum sandarac, 8 oz; gum elemi 8 oz.; dragon's blood, 4 oz.; seed lac, 4 oz.; terra merita, 2 oz.; saffron, 8 grains; pulverised glass, 12 oz.

Solders and Soldering.—Soft Solders.—Tin and lease in equal parts. Easier of fusion still is tin, lead, and bismuth, in equal parts; or 1 or 2 bismuth, I lead, and I tin easier still. For soft soldering brass, tin-foil makes a fine

juncture, applied between the joints, care being taken to avoid too much heat. This is most excellent for fine brass-work. The tin-foil must be moistened in a strong solution of salammoniac.

Plumber's Solder.—I part bismuth, 5 parts lead, and 3 parts tin, forms a compound of great importance in the arts.

Brass Solder for Iron.—Melt the plates of brass between the pieces that are to be joined. When the work is very fine, the parts to be brazed should be covered with powdered borax, melted with water, so that it may mix with the brass powder which is added to it. Expose the piece to a clear fire in such a manner that it shall not touch the coals, and let it remain until the brass begins to run.

Silver Solder for Jewellers.—Take 20 dwt. of brass, 2 dwt. of copper, and 38 dwt. of fine silver, and melt them together.

Silver Solder for Plating.—Take $\frac{1}{2}$ oz. of pure silver and 5 pennyweights of brass, and melt them together.

Soldering Steel and Iron without heat.—Take $\frac{1}{4}$ oz of thirid acid, $\frac{1}{4}$ oz, of spelter, $\frac{1}{4}$ oz, of bismuth, and $\frac{1}{4}$ oz, of nitric acid. Put them all into the thirid acid; after well mixing, touch each part required to be soldered with the mixture, and put them together.

Solder for Tinware.—An excellent solder for tinware can be made from the lining of tea-chests.

Soldering for Leaden Gas-Pipes.—The blowpipe is not absolutely necessary, as the flame of the candle gives heat sufficient for the purpose by itself: prepare the joint in the usual way, then grease and sprinkle on a little powdered rosin. Now apply the flame of the candle, and touch with a strip of fine solder: as soon as the joint is sufficiently heated, the solder will flow easily. One candle will be sufficient for the smaller sizes of pipe; but by using two or more candles, joints may be made in this way up to 1 in. or $1\frac{1}{4}$ in. The solder must be fine, such as tinners use; poured out in thin strips, and cut by the shears $\frac{1}{4}$ in, broad. In gas-pipes of what is called composition metal the blowpipe is absolutely necessary;

and, in fact, a blowpipe is most useful, and used in directing the flame round the pipe or to a required spot, and keeping up a continuous heat.

Blowpipe Joints are thus made:—Slightly taper one end of the pipe, and open the other end for it to fit into; clean the inside of the opened length, and the outside of the tapered end. Grease the same with common tallow, and sprinkle a little powdered rosin on it. Now with 10-in. blowpipe in the mouth, and rushes or spirit lamp held in the left hand, and a thin strip of soft solder in the right, gently heat the pipe before applying the solder. This solder should be composed of 3 parts fine tin, to 2 of lead. A small portion of bismuth will make it flow more easily.

Soldering, Hard.—One of the most common is that ofsilver soldering; it is composed of silver 2 parts, brass I part (common pins are the best). The silver is melted first, the brass then added and well melted together; it is then milled to the thickness of stout paper.

The work that requires to be soldered should be scraped clean and bound together with iron binding-wire,

A piece of lump borax is next rubbed with a little clean water on a piece of slate to the consistency of cream: the work should be covered with this by means of a small pencil, especially the parts to be soldered; the solder is then cut into very small pieces and laid across the joint with the pencil also; the work is then put on a piece of charcoal or bundle of iron wires, and gradually heated till the solder melts (by means of the blowpipe and gas). For rings, a piece of solder is passed between the join, and served as above (be careful of the stones, they must not be made red hot). Gold is generally soldered by gold of an inferior quality, as 22 carat soldered with 18 carat, 18 carat with 16 carat, &c. After soldering the binding-wire is removed, and the work boiled in nitric or sulphuric acid pickle (1 part acid, 10 parts water), and finished accordingly. It requires much practice to become master of the blowpipe.

Brass Melting.—The best method of melting brass is in a plumbago crucible. The best furnaces are built of fire-brick, open at the top, with an opening in the upper part of the back, connecting the furnace with the chimney, and another larger opening in the front, below the grate bars. A good

ractical furnace may be made 12 in, square inside, 18 in, eep to grate, 12 in, below grate for cinders and air-passage, himney opening $4\frac{1}{2}$ by 3, and 3 in, from top of furnace. This furnace is large enough for a No. 25 crucible, which will nelt about 50 lbs. of brass.

To avoid Air-holes or Flaws in Brass Castings.—
The theory of their formation is as follows:—Melted metal is more bulky than cold metal, and as the outside of castings cool irst, it follows that the shrinking must take place within. The co-called air-holes are in reality not air-holes at all, but cavities formed by the shrinking of the metal. To avoid them, endeadour to equalise the patterns by coring, &c. If such is not to be done, run from the thickest part with a heavy runner. This process will tend to keep all in a fluid state until the outer portions have set, and so fill the cavities as they form.

Bending Brass Tubes.—Brass tubes are best joined by brazing up with melted brass. Tubes for musical instrunents are bent by first filling them with lead, which, as soon is they have been brought to the required shape, is easily melted out again.

Brass Pickling or Brightening.—In order to remove he grease and dirt that may have accumulated during the process of fitting, the work should be placed in a red-hot huffle, or over an open fire; unless it be soft soldered, when of course it must be annealed before being fitted. If that be the case, or if the work have ornamental surfaces, it should be boiled in potash lye. When this is done, immerse it in a bath composed of diluted sulphuric or nitric acid in the proportions of 1 part acid to 3 of water. Allow the work to remain in this solution for from one to two hours, according to the thength of the acid; then rinse with water, and scour with and, using a common scrubbing-brush; then wash well, make the pickling-bath, dissolve 2 parts of zinc in 6 parts of nitric acid of 36° Baume, in a porcelain vessel, then add to the mixture 16 parts of nitric acid and 16 parts of sulphuric Boil this liquid, and while boiling, plunge the work into it for about half a minute, until the nitrous vapour ceasing, the surface becomes uniform. Then rinse it well in clear water, to remove the acid. Should the work have

assumed a greyish-yellow tint, this may be removed by immersing the work for a short time in nitric acid. It should then be rinsed in a weak solution of potash, and covered with beech or boxwood sawdust, and afterwards rubbed until quite dry; after this it should be lacquered, to prevent the action of the atmosphere; and if a green tint be required, a little turmeric mixed with the lacquer will give it. By immersing the work in a solution of white arsenic in hydrochloric acid, a dark-greyish tint is obtained.

Coating Copper.—To coat with Antimony.—Dissolve 2 ca. of butter of antimony in 1 quart of spirits of wine, and add hydrochloric acid until the solution is clear. Into this solution put the object to be coated, previously well cleaned and polished. In the course of three-quarters of an hour a solid and brilliant covering of antimony is deposited. Cast iron may be coated with copper by placing it in an alkaline solution of chloride of copper, and then covered with antimony by the above process.

Coating Copper.—The best way to coat copper with platinum for a battery is to bend a sheet of zinc to enclose a porous cell, and connect the zinc without the cell in a suitable vessel with the copper in the cell, then fill both vessels with sulphuric acid 1, water 10, and drop a little solution of bichloride of platinum into the porous cell: it will be instantly thrown down on the copper as black powder.

German Silver, to polish.—An excellent powder for cleaning German silver and other bright metals can be made in the following manner. Take ½ lb. of peroxide of iron (crocus). Put it into a wash-basin and pour on water, stirring with the hand. While the water is in slow motion, pour off the mixture, leaving the grit at the bottom; repeat this operation, and then put it at one side until the crocus has settled at the bottom. When it has done so, drain off the water, dry the powder, and keep in a bottle or canister.

If the work to be cleaned is very dirty, mix a little of the powder with oil; rub it on with the fingers, and polish in the usual manner. If only slightly tarnished, put a little of the powder on a piece of wash leather, and polish well, taking care that the leather be free from dust.

Hardness of Silver.—Goldsmiths often complain of the hardness of silver, which is sometimes very difficult to carre,

nd presents a dead grey cut. These properties are generally ttributed to the presence of a foreign metal; but M. Mathey, ssayer at Locla, has shown that in this silver there is neither in, lead, nor any other injurious metal. He considers this roperty to be due solely to the high temperature at which silver is cast. By letting the crucible cool till a slight solid crust s formed on the surface of the fused metal, and casting at this noment, a soft silver with a brilliant cut is obtained.

Tarnished Plate, to clean.—Silver or plated objects may be cleaned, if tarnished, by dipping them, when they are small, nto a moderately concentrated solution of cyanide of potassium, and when they are large, by brushing the solution over the tarnished portions, then washing well with distilled water, and afterwards drying with a linen cloth.

Silver and Galena, to separate. - If sulphuret of silver s melted with chloride of lead, a decomposition takes place, and sulphuret of lead and chloride of silver is formed. If, therefore, galena, which consists of sulphuret of lead with some sulphuret of silver, is melted together with chloride of lead, the silver is extracted from the galena, and lead takes its place. On this principle depends the new process, which is carried out as follows: - The galena is mixed with 1 per cent, chloride of lead and 10 per cent, common salt. If it contains much silver, a greater quantity of chloride of lead is added. The mixture is melted, and the chloride of silver formed by these means, together with the salt, floats on the top, and can easily be separated from the pure galena. The mixture of chloride of silver and common salt is afterwards melted together with lime and charcoal, or treated in some other suitable manner, whereby the silver and the lead contained in the remaining thloride of lead is reduced. The mixture of silver and lead thus obtained is afterwards separated in the ordinary manner.

Artificial Gold.—Take 16 parts virgin platina, 7 parts copper, 1 part zinc. Place the whole in a crucible, covered with powdered charcoal, and melt until formed into one mass. For a brazing solder, take 12 lbs. of copper, and 11 lbs. of zinc; flux with powdered brimstone.

Gold, to Dissolve.—2 parts hydrochloric acid and I nitric acid (aqua regia) will dissolve gold. Apply gentle heat to

accelerate chemical action. To colour gold, make up 2 dws. of sulphate of copper, 4 dwt. 12 gr. French verdigris, 4 dws sal ammoniac, 4 dwt. nitrate of potassa, acetic acid about 1 ot Reduce the sulphate of copper, sal ammoniac, and nitrate of potassa to a powder, add the verdigris, then pour in the acid little by little; dip the article in by any convenient means, and heat on a piece of copper till black. When cold, place in tolerably strong sulphuric acid pickle, rinse well in water, to which a little potash has been added.

Case Hardening.—For occasional case hardening upon small scale a very good box may be made by welding a plan into the end of a piece of wrought-iron pipe, and using a loos plug for the opposite end; the loose plug will, of course, require to be fastened into its place with an iron pin passing through and the pipe; it will require to be luted with clay or loam; part of the plug must project out of the pipe for the convenience of pulling it out.

Composition used in Welding Cast Steel.—Borax, to sal ammoniac, 2; flowers of sulphur, I part; grind or pound them roughly together; then fuse them in a metal pot over a clear fire, taking care to continue the heat until all scum has disappeared from the surface. When the liquid appears clear, the composition is ready to be poured out to cool and concrete being ground to a fine powder, it is ready for use. To use this composition, the steel to be welded is raised to a head which may be expressed by "bright yellow;" it is then dipper into the welding powder, and again placed in the fire until it attains the same degree of heat as before; it is then ready to be placed under the hammer.

Inlaying with Mother - of - Pearl. — Having procured mother-of-pearl of the required shades, and properly cut into thin scales, fasten the pieces on the article to be inlaid with cement, according to whatever design you may have chosen. Then cover the rest of the surface with successive coats of Japan varnish, baking after each coat, until it is flush with the surface of the pearl.

White Metal is an alloy of 10 of tin, 1 of copper, and 1 of antimony. This is a capital composition, running very smoothly; when kept from heating it will last longer than brass, and with a good deal less friction. It was used a great

eal for lining the working-parts of eccentrics, also for the stern ube bearings of screw propellers, before the introduction of he use of timber for this purpose. It is generally cast inside of cast-iron steps, merely as a liner, the low temperature at which it melts rendering it dangerous to make the whole step of this composition, except in cases where the entire bearing is enclosed in a bath of oil or water. It is a fact which has been practically proved, though not generally known, that for extremely high speeds, such as fan-shaft, saw-mills, &c., nothing beats cast iron on cast iron. For locomotive-work, or first-class engine or machine work of any description, nothing is better than what is known by the name of gun metal, which is an alloy of 1 of tin, 1 of zinc, and 8 of copper.

Polished Steel, to Preserve.—You can preserve polished steel from rust by mixing some oil with caoutchouc; melt in a close vessel, stirring to prevent burning. A high temperature will be required. This will form a perfect air-proof skin over the surface, which may very easily be removed by brushing with warm oil of turpentine.

Glazers for Polishing Metal.-There are two kinds of glazers for polishing metal; dry and soft. The dry glazer is for doing coarse work, and is constructed as follows:-An outer coating of wood of a uniform thickness, say 2 inches, is secured by means of screws to a cast-iron wheel; the wood must be turned after it is fastened. It is then surrounded by a eather strap, which must be thoroughly soaked in water to make It pliable. The strap is fastened in this manner: a coating of glue is placed on the wood, one end of the strap is nailed to the glazer, the strap is then pressed round the circumference by means of a round iron bar, and at intervals of 3 or 4 inches a tow of nails is driven through the strap—these nails are made expressly for the purpose, they are round, with square heads and polished points, to keep them from rusting and make them easily drawn. The strap having been all nicely secured, the glazer is hung up to dry, a process which generally requires a week, in consequence of the soaked state of the leather. When the glazer is dry enough, the leather is coated with glue, the emery is placed on a paper on the floor, a spindle having been attached to the glazer. A man is placed at either end of the pindle, who rolls the glazer over the emery backwards and

forwards, lifting it up and letting it down, in order to make the emery fast, and to cause as much to adhere as possible; it is then hung up to dry, and it is fit for use in a few hours.

The soft glazer is made all of wood, except that it is secured by iron bands. The emery in this case is mixed with tallow and formed into cakes. When the emery is to be applied, the workman takes a tool something like a hoe with a hammer shank, and along the cutting edge is a row of teeth; he then strikes the glazer all round, leaving the teeth-marks as thick as possible; he then takes a piece of cake emery and tallow, and presses it all round the glazer; it is fit for use immediately after. No amateur should work on a wood glazer; because if an edge catches the wood, the consequences will be serious.

Breaking Weight of Cast-Iron Rectangular Beams.—The breaking weight of rectangular beams may be correctly ascertained from data given by Dr Fairbairn. His experiments on 43 samples of hot and cold blast iron bars, each I in. square, and supported on bearers placed 4 ft. 6 in. apart, gave, as the average breaking weight, 452.74 lbs.; hence, for any other bar or beam of similar section:—Breaking weight $W = \frac{4.56 d2.5}{b}$ where b = breadth, d = depth, and l = length beam, s = the co-efficient above given—viz., 452.74 lbs. It the beam be fixed at both ends, it will sustain one-half as much again as when supported.

Preservation of Polished Steel Surfaces. — Polished surfaces of steel and iron may be preserved from rusting by exposure to water, if whilst so exposed they are covered one with a mixture of lime and oil.

Taking Buckles out of Sheet Iron.—The tools generally used are as follows:—A large cast-iron plate, about 2 ft diameter and 2 in. thick, with the face a little convex (it is called a setter), and a hammer of about 4 lbs. or 5 lbs., about 2 in. flat face. Hammer the sheet iron wherever it is tight, where it does not buckle, so as to stretch it equal to where the buckles are; by so doing you will bring it flat, but this require patience and practice. A large plate of iron, as above stated is the best to set your work out on; because you can more

ly see the extent of the buckle, and where the tie is located t requires to be hammered. The process can be made ch easier by passing the sheet iron through a pair of rollers h as are used by tin and iron plate workers.

Preservation of Sulphate of Iron.—Mix 4 parts of pure stallised sulphate of iron, and an equal quantity of finely-wdered gum arabic, with distilled water, and evaporate solution in a water-bath, at a low heat, till it has a sufficient consistency to be poured out on plates of glass. When has been poured out in this way, and allowed to dry at a imperature of 30° Cent. in the dark, it may be cut up into zenges, which can be kept for any length of time in a coloured oppered bottle.

Composition of Mixed Metals. Pewter.—1. 100 parts tin, 17 parts of antimony; the French add a little copper. 12 lbs. of tin, 1 lb. of antimony, 4 oz. of copper. 3. 7 lbs. tin, 1 lb. of lead, 6 oz. copper, 2 oz. zinc. Melt the copper st.

White Metal.—2 lbs. of antimony, 8 oz. of brass, and 10 to 10.

Mosaic Mixture.—Equal parts of tin, bismuth, and mercury, orms a metal used for various ornamental purposes.

Silvery-Looking Metal.—A very fine silvery-looking metal made from 100 parts tin, 8 parts antimony, 1 part bismuth, and 4 parts copper.

German Titanium.—2 drachms of copper, I oz. of antimony,

Spanish Titanium.—8 oz. of scrap iron or steel, 1 lb. of antimony, and 3 oz. of nitre. The iron or steel must be heated to whiteness, and the antimony and nitre added in small portions.

2 oz. of this compound are sufficient to harden 1 lb. of tin.

Columbia Metal.— $4\frac{1}{2}$ lbs. of tin, $\frac{1}{2}$ lb. of bismuth, $\frac{1}{2}$ lb. of antimony, and $\frac{1}{2}$ lb. of lead; or, 100 lbs. of tin, 8 lbs. of antimony, 1 lb. of bismuth, and 4 lbs. of copper. This alloy is used for making teapots, and other vessels which imitate silver.

Type-Metal of the French letter-founders: \(\frac{4}{5}\) of lead and \(\frac{1}{1}\) of regulus of antimony. The letter-founders of Berlin use 11 lbs, of antimony, 25 lbs, of lead, and 5 lbs, of iron. Many

add tin, copper, and brass; while some make their types from 3 parts of lead to 1 of antimony.

German Silver.—1. 25 parts nickel, 20 parts zinc, and 60 parts copper. If for casting, add 3 parts of lead. 2. 16 parts copper, 8 parts zinc, and $3\frac{1}{2}$ parts nickel. 3. 8 parts of copper, $3\frac{1}{2}$ parts zinc, and 2 parts of nickel. 4. 28 parts copper, 13 parts zinc, and $7\frac{1}{2}$ parts nickel. 5. Copper, 8 parts; zinc, $3\frac{1}{2}$ parts; nickel, 3 parts. This last is a very beautiful compound. It has the appearance of silver a little below standard. By some persons it is even preferred to the more expensive compound. Manufacturers are strongly recommended not to use a metal inferior to this.

Speculum Metal.—1. Copper, 32 parts; tin, 14 parts; arsenic, 2 parts. A very good metal. 2. Copper, 32 parts; tin, 13½ parts; arsenic, 1½ parts. 3. Copper, 32 parts; tin, 15 parts; arsenic, 2 parts. 4. Copper, 32 parts; tin, 15 parts; brass, I part; silver, I part; arsenic, I part. 5. Copper, 6 parts; tin, 2 parts; arsenic, 1 part. Sir Isaac Newton's It is very yellow when polished. 6. Copper, 1 parts; tin, 11 parts. Compact, and whiter than the last 7. Brass, 6 parts; tin, 1 part. Compact, but too yellow. 2 parts of 6th composition, and I part of 7th. Much too 6, 7, and 8, are experiments by yellow when polished. Professor Molyneux, F.R.S. 9. Copper, 32 parts; tin, 2 parts; arsenic, I part. A pretty good metal, but polishes too yellow.

Mercury, to Extract.—Make a solution of sulphate of mercury by dissolving it in a solution of common salt. Add to the about one and a half or twice its bulk a solution of protochloride of tin (price 3d. per oz.) You will get a white precipitate which will afterwards turn grey. This is metallic mercury. To collect it, let the precipitate settle, and pour off the liquid; additte hydrochloric acid (equal parts of acid and water) to the precipitate, and boil. The mercury will gradually collect in globules.

To Prevent Sand sticking to Articles when Moulded. Take a little finely-powdered charcoal, in a fine muslin be and shake it on the face of the flask of sand after moulding patterns, and before putting the top flask on, and when we dusted with the charcoal, it will prevent them from sticking.


iking of Castings.—For shrinkage of castings, the maker's rule should be, for cast iron, $\frac{1}{8}$ th of an inch per lineal foot; brass, $\frac{3}{16}$ ths ditto; lead, $\frac{1}{8}$ th ditto; h ditto; zinc, $\frac{5}{16}$ ths ditto. The following is the linear on by heat from 30° to 212° of—

y, I part in	•	923	Iron, cast, 1 p	art in	•••	901
, ,,	•••	719	Lead, pure,	,,	•••	349
,,	•••	584	Platinum,	,,	•••	1131
,,	•••	581	Silver,	,,	•••	524
ss, ,,	•••	1248	Tin, pure,	,,	•••	403
, ,,	•••	682	Tin, impure,	,,	•••	500
ought, ,,		846	Zinc,	••		322

Amateur's Smelting Furnace.—A simple smelting for brass, &c., is made thus:—

large vessel No. 1 is filled with sand, to prevent

n of heat. The ucible stands on . I. A large sel; 2. a large crucible; 3. l crucible; 4. r charcoal; 5. ble blast bel-




ing.—First cleanse the articles to be tinned by placing warm water, mixed with a little oil of vitriol. After the articles in clean water, dip them in a solution of noniac, and let them dry. When they are thoroughly lace them in a shallow pan, the bottom of which is full s. When the tin is melted, sprinkle a little sal amover the surface, and dip the pan containing the into it. When the smoke has cleared away, take them ke them over the pot, and sprinkle a little sal ammoniac em; then plunge them into cold water.

lphide of Tin.—Kletinsky dissolves 4 parts of salt of 20 parts of water, previously mixed with 2 parts ng hydrochloric, or 1 part of strong sulphuric acid. Ilution is heated nearly to boiling, and then saturated phuric acid gas. The following reaction takes place:— $+2HO+SO_3$, $HO+5SO_2=SnS_2+2(SnO_2,2SO_3)+3H$

Cl. The yellow sulphide of tin is collected on a filter, wa and dried, and the filtrate may be distilled to recover hydrochloric acid, sulphate of tin remaining in the retort, the dried sulphide of tin is sublimed at a red heat, acces air being prevented, beautiful mosaic gold is obtained in a shining scales, and spangles of a brilliancy that is never swith the old way of making the gold.

Oxychloride of Zinc may be prepared by dissolve granulated zinc in hydrochloric acid, and evaporating who semi-solid hydrated mass is obtained (butter of zinc), oxychloride is prepared by strongly heating this mass is porcelain crucible.

Working Poor Ores of Lead.—The operation on lead of which contain too little lead and too much earthy matter to smelted profitably, scientific smelters treat with muriatic a with heat, upon plates of stone or lead, by which the galent completely converted, if the ore has been properly prepared into chloride of lead. The mass is then lixiviated in tube to double bottoms, holding each 15 or 20 cwt., with boiling we to extract the chloride of lead, which crystallises out in goart on cooling, the mother liquid being again heated to ling, and used over again continually. The deposited chlorof lead is reduced to the metallic state by zinc, forming spongy lead, which may be either melted down or used



making whitel &c. Some having been thr down from the cride of zinc soluby chloride of I the zinc must precipitated by as pure white cof zinc, suitable pigmentary poses,

Rotary Eng
— The follo
sketch and e

nation shows the principle of a simple Rotary Engine :-

cylinder; B, piston; C, slide; DD, slide box; E, t port; F, steam port; G, shaft.
ill be seen that the piston works the slide.

am Governors.—The "pendulum ball" contrivance is oly about the best to employ as a regulator, and about the to use—as it is ordinarily used—as a governor of machine

The following invention simply embodies a plan for ying the "centrifugal principle" in the way for which it

d, instead of (as sent in "Watt's nor") the mode ich it is especially

apparatus will sily understood he skeleton diasubjoined.

1. A is a box ning a train of vork, kept going pring or weight, egulated by the l pendulum B. orks are wound ry morning when gine starts, and rotative moveis given to the C throughout rking day, which l practical purmay be regarded ariable.

fig. 2, A and B o circular discs, edgewise. One each, the inner







Fig. 2.

flat. On the other, a wheel or pulley is fixed, by which e motion is communicated. The discs revolve freely and indently on fixed axles. One of these discs, A, receives its rotation by a strap from wheel C in fig. 1, and therefore revolves at a regular rate. Disc B in like manner receives rotation from the engine. The discs are so fixed that thin flat surfaces revolve in parallel planes, but in opposite directions. Through the fixed axles central holes are drilled to receive the spindle of the "governor," shown in fig. 3, where A is a spindle carrying an arm B, which is crowned by a wheel C, revolving freely on its centre. The length of the arm B is rather less than the radius of the discs A and B in fig. 2; and the diameter of the wheel C is just equal to the distance between those discs. All these dimensions, as well as the velocity of rotation of the discs, are merely matters of convenience.

When put together, the ends of the spindles pass through the holes in the fixed axles, and play freely in them. The arm B



projects between the discs and the wheel C, which traverses round near their outward edge, and is pretty tightly clipped by them. Its rim is belted by a ring of vulcanite, or other elastic material, 50 as to establish a good bite. One end of the spindle projects beyond the framework, and carries at its extremity an endless screw, which works into the teeth of a quadrant D. connected with, and

governing, the throttle-valve. The wheel arrangement is shown in fig. 4.

The action of the instrument is very simple. So long as the "engine" disc keeps time with the "chronometer" disc, its "governor" wheel C will simply revolve on its axis, keeping the spindle, and therefore the throttle-valve, fixtures in their existing position. When any change of power or load occurs,

I the engine disc begins to gain or lose, the "governor" eel at once begins to traverse round the circle, carrying with he spindle, and thus acting on the throttle-valve until a new nt is reached, when the disc velocities are again equal; and re it remains until new conditions supervene requiring fresh justments.

By this means the engine disc can never vary in velocity m the chronometer disc for more than a few seconds at a ne, while the process of adjustment can be made as prompt d delicate as any practical necessities may require.


Preventing Incrustation in Boilers.—Mr William Irwin's rention of "an improved compound for preventing incrusion in boilers," consists in the mixing with the water in a am boiler a compound composed of the following ingredients, itch, by preference, are mixed together in the following prortions:—

French ochre	3	lb.
Oxford ochre	ž	,,
Brown ochre		,,
Yellow ochre	3	,,
Vandyke brown	į	,,
Spanish brown	ż	"
Purple brown Ground umber	\$	"
Ground umber	ž	"
Ground ochre	4	"
•	6	lbs.

e above proportions mixed in a gallon of water, and put into poiler 17 by 5 feet, will prevent incrustation.

Another plan is to introduce a small quantity of chloride of monium, when the lime which forms the incrustation will held in solution, and the boiler cannot foul. The process qually applicable to fresh or salt water. This will effect a ing of time, heat, and fuel, and, more than all, will prevent of the principal causes of explosions, for it has been proved t, in most instances, the foulness of the boiler has been the scipal cause of accident.


fuch of the "fur" in boilers depends on the chemical comtion of the water used. Sometimes a pound of common a, introduced daily, has been found to prevent incrustation. s for driving a 20 horse-power engine. The deposit is in the state of powder. Two months is too long to work a boiler without cleaning, except in rare cases. To introduce the sods,



have a small cisters connected with the pump, dissolve in the cistern, and then turn on your tap.

Blast Engine— In the following, the swan-neck rol should be made of two flat, tapering bars. In the sketch the crank is represented as working 6-feet stroke, and the cylinder working 8-feet stroke.

Self-Acting Boiler Feeder.—The figure is a section of the apparatus. The water from a cistern enters the cylindrical reservoir A through the pipe E, closed by a valve B opening upwards. The water passes into the boiler through the pipe



H, closed at top by the valve C opening downwards, and closed by a slight spring.

D is a small steam-pipe reaching to the top of the reservoir, and having a 3-way cock where shown. The action is as follows:—On turning the 3-way cock a communication is opened between the cylinder and the outer air; the water then enters through the valve B, and fills the reservoir, ulti-


mately escaping through the lateral opening in the 3-way cock. This shows the reservoir is full. On now turning the cock, the lateral passage is closed, and the direct communication opened from the boiler through the steam-pipe D. Equilibrium of

re being thus established, the water descends through lve C and pipe H into the bottom of the boiler. On reversing the cock the steam escapes, and the water as before.

only thing to be done, therefore, is to turn the small t certain intervals, and this may be arranged by letting ter that overflows through it when the reservoir is full o a receiver so arranged as to tilt over when full, and in over turn the 3-way cock. The whole would thus be:ntirely self-acting.

ine Governor.—To make a governor that will work ly and show its speed, mark a diagram of the gover-

showing the lines only, in its proper position, ith the balls xpanded. If entre line of ig arm be ex-1 until it cuts entre line of indle, we are measure by on the the distance he horizontal of the balls up point in the e where it is the extended line of the




this distance is the vertical height, on the length of depends the speed of the governor. The rule now

√=revs. per min. vertical height in inches.

gives the correct speed of the governor, and that of the being also known, before the required size of the wheels at once determined upon.

Expansive Governor for Steam Engines, &c.—It frequently happens in many manufacturing operations that great variations occur in the work which the engine has to perform, and in all cases it is desirable that the steam should be used in the most economical manner. With the use of the ordinary throttle-valve this desirable result is not effected, inasmuch as the retardation is caused by expansion of steam before admission into the cylinder, thus losing the full benefit of the high



pressure stored in the boiler at so much risk. In order, therefore, to economise in this respect to the fullest extent, the steam should be admitted to the cylinder at full pressure, and the required diminution of speed effected by a proportionate duration of the admission. Such a variable "cut off" is produced by the invention we now describe.

Fig. 1 (the bottom of which is the top of the slide-valve case of a horizontal engine) has cast with it the small upright cylinder, closed at top communicating with the valve-case. The upper half of this has an opening extending about half-way round, which is shown as fig. 2. Over this, and fitting with proper ease, is another cylinder, open at both ends, and to \$ cross-bar at top is fixed the rod proceeding upwards, and working with the bent arms of the governor. the lower half is a cavity, as seen in fig. 3. Over these is bolted down the cylindrical steam-case, provided at the

side with steam-pipe and at top with stuffing-box, and also with support for the bevil-wheel actuating the governor. The revolutions of this wheel being made, by suitable means, to correspond with those of the main shaft, and proper adjusting weights placed upon the small shelf provided on the rod, going through the stuffing-box, the effect will be that, as the centrifugal force depresses the said rod, so will the openings before

described correspond for a shorter time, and the speed be regulated as desired. The effect will be better understood by referring to figs. 2 and 3, where, supposing fig. 3 passed across fig. 2, in the direction of the arrow, represents the steam on during the whole stroke, then by depressing fig. 3, and passing it across as before, the inclined sides are brought nearer together, and hence the "cut off" takes place sooner. The lower part of fig. 1 is in section.

The Giffard Injector consists of three cones, A, B, and C. B is the combining cone, A the steam cone, and C the receiving cone. The steam cone can be moved nearer to or further from the combining cone, which is fixed with its small end at a short distance from the receiving cone C, and the supply of steam can be regulated by the rod D, worked by the handwheel k. F is the steam-pipe opening into the steam cone above; g is the water-supply pipe opening into cone B. H is the overflow-pipe opening into an annular space oo, surrounding the ends of the cones B and C, finally I is the valve opening into the boiler.

The action is as follows:—The steam rushes through pipe F and cone A. Now take, for example, the case of a boiler working at a pressure of 60 lbs. per square inch from a vacuum.

A cubic foot of steam at the atmospheric pressure will weigh 047 lbs., therefore the weight of a cubic foot of 60-lb. steam

will be equal to $-- \times .047 = .188$ lbs.; also the weight of a


cubic foot of water is 62.4 lbs. Now the velocity of issue of a fluid under pressure is equal to the velocity of a body falling from a height equal to the height to which a column of the fluid would be raised by the pressure in question, which for 60-lb. steam

will =
$$8\sqrt{\frac{60 \times 144}{188}}$$
 = $8\sqrt{\frac{44800 = 1712}{12}}$ feet per second. Also for
188 $\sqrt{\frac{60 \times 144}{138 \cdot 4}}$ = $8\sqrt{138 \cdot 4}$ = 94 feet per $\frac{62 \cdot 4}{138 \cdot 4}$

second nearly. Now, suppose I cubic foot of steam coming out of the steam cone with a velocity of 1712 feet per second to be condensed between A and B, it would form about four cubic inches of water, which would retain the velocity of the

steam; and as this is rather more than 18 times greater than the velocity of the water issuing direct from the boiler, if it is mixed with about 16 times its bulk of water, it would still have a velocity rather greater than 94 feet per second, so it would easily open the valve and enter the boiler.

Now this is exactly what happens in the injector. Steam being turned on, rushes through the cones A and B, and escapes at the overflow-pipe H; but by the well-known principles of hydrodynamics, it induces an upward current of water



in the pipe g: and as soon as the water reaches the cone A, it will begin to condense the steam, and, by the principles already explained, if the bulk of the condensed


steam and water be not greater than about 17 times the bulk of the condensed steam, it will open the valve T and enter the boiler.

If the supply of water be too great, and the velocity thereby too much reduced, it will rush out of the overflow-pipe H instead of entering the boiler, and thereby give warning to the engineman to reduce the supply of water by moving the cone A nearer to the cone B, by means of the handle E, until the water just ceases to drip from the pipe H. If more water be wanted for the boiler, the pointed rod P is drawn further back to admit a larger quantity of steam, and the cone A also drawn back till a slight drip comes from the pipe H, when the injector will be working to its greatest effect. It is evident that the quantity of feed-water must in all cases be sufficient to condense the steam, and that the water must not be heated to more than about 110° Fahr., or it will not condense fast enough -or rather, the quantity required will be too great for the steam to take into the boiler with it.

Huxley's Internal Tappet Pump or Steam Engine.—As a pump this will be found specially useful in deep wells, where frequently much inconvenience, loss of time, and expense arises from the defective action of the ordinary valves, also necessi-

the descent of some one down to the pump. Here we lift and force pump, of double action, with the requisite s effected by a tappet piston in place of valves, whose is as certain as the revolution of a crank and fly-wheel, cessary appendage to the piston-rod, &c. Fig. 1 is the y cylinder and piston, the cover, however, having a long the stuffing-box in order to allow of the movement of

pet, which is fastened to ton-rod, and may be seen der the stuffing-box. At e, near the top of cylinder, ee ports, as usual; but the re altered in arrangement, be seen. The exit port communicates with the top on, through a circular pasnade in the tappet piston referred to, and surrounde piston-rod. The action llows :- The piston having ed to the limit allowed by nk, has pushed the tappet to near the top of cylinder, ready for descent, Supply is in communication with piston, causing it to deexit port b communicates port c through a cavity, is seen on the side of the piston, and thence descends ige and opening c to bottom on. The piston having next at bottom of cylinder, the has just pushed against a ar provided at the bottom pet piston, and its position



in fig. 2, where exit port b communicates through the e described in tappet piston to the top of piston, and pipe and port a with port c leading to bottom of piston, us proceeds the up-stroke, and produces the arrangements described ready for another down-stroke.


Power of Engines.—It is frequently asked. What is the power of an engine of such-and-such dimensions? tion will be answered by a glance at the following rules, which amongst many others, are used for ascertaining the horsepower, will explain the vague and uncertain methods we have of solving such a problem. In Chambers's "Mechanics." the rule for non-condensing engines is, Multiply the area of piston in inches by the pressure per square inch in cylinder, less 15 lbs. for the pressure of the atmosphere on waste-steam pipe. Then, by the velocity of the piston in feet per minute, divide by 33,000, and 4 of the quotient is the effective power. Templeton's rule for high pressure is, Multiply the area of piston in square inches by the average force of steam in lbs. and by the velocity of the piston in feet per minute. by 33,000, and $\frac{7}{10}$ of the quotient is the effective power. Bourne gives the following rule for high pressure: -- Square the diameter of the cylinder in inches, multiply by the pressure of the steam in the cylinder per square inch, less 1 lb., and by the piston's velocity in feet per minute. Divide by 42.017: the quotient is the effective power. The first-mentioned rule is merely given by way of illustration, as the pressure of the atmosphere is not generally taken into account, engines of this principle being supposed to work in a medium. The rules for ascertaining the nominal power are equally fallacious. condensing engines Bourne gives the same rule as for noncondensing, considering that the deduction of a 11 lb, is relatively much smaller where the pressure is high, than where \$ does not much exceed the pressure of the atmosphere. ner gives the following rule:—When the pressure in the cylinder does not exceed the atmosphere more than 4 lbs. or 5 lbs., with a good vacuum, and an average of 200 feet per minute for the velocity of the piston, square the diameter of the piston, and divide by 28: the quotient is the horse-The Admiralty rule is, Square the diameter of the cylinder in inches, and multiply by the speed of the piston in feet per minute. Divide by 6000: the quotient is the horsepower.

Safety-Valves.—Many and various are the plans that have been adopted and suggested for producing perfect safety-valves for steam engines. Without an effective and reliable safety-

alve, the use of a steam boiler must be constantly attended with the most imminent danger. Whatever care may be bestowed by the manufacturer on the construction of the safetyvalve, it may be rendered nugatory by the ignorance or temerity of the person in charge of the engine, since he may overload the valve, and thus create a pressure within the boiler which it was not constructed to endure, and which it may not be capable of bearing. The evil may, indeed, be prevented by the use of two safety-valves, one of which is beyond the power of the engineman. But ingenuity has devised a still more simple remedy; one that not only prevents the production of steam at too high a pressure, but which actually causes every attempt to produce it to be accompanied by a reduction of pressure, and thus removes all temptation to tamper with the valve. The new form of safety-valve differs little from the ordinary kind, and is extremely simple. In the ordinary kind the fulcrum of the lever is absolutely immovable, in the new kind it is fixed; in ordinary circumstances, being kept down by a spiral spring. But attempting to overload the valve brings the lever down on a stud, which is at the side of the valve most remote from the fulcrum, and which comes into action as a new fulcrum by supporting the lever, changing the latter from the third to the first order. The former fulcrum yields to the additional weight, the spiral spring being compressed, and is raised up, the safetyvalve being at the same time opened, or allowed to open; and thus the steam is permitted to escape, though at a pressure too small to raise the valve when weighted as it should be. In its normal state, the fulcrum of the lever is at one end, the weight at the other, and the power—that is, the tendency of the safety-valve to rise-between the fulcrum and weight. When the valve is overloaded, the weight—that is, the resistance of the spiral spring-is at one end, the power-that is, the weight with which the lever is loaded-is at the other, and the fultrum—that is, the stud on which the lever has been brought down by the overloading-is between the power and weight, the effect of the latter being aided by the tendency of the steam to raise the valve. A notice of some of the most recent, therefore, cannot but be interesting to mechanicians and engineers. First, we have

Mr Swann's Patent.—In this case, the apparatus is so arranged that undue weight applied to the lever of the valve, in

place of allowing an increase of pressure in the boile cause the steam to blow off at any pressure to which the ratus may be set. In place of arranging the valve le turn on a fixed centre as usual, the centre or axis is arin such a manner that it is kept down only by a spr



weight, which when undue sure is appl the other end lever: the arm of the then descer short distan it comes aga fulcrum arr for it between valve and weight, and the undue applied to the aids in taking sure from the The inner e the lever, w centre or as cased in so cannot be tam with. The arrangement plicable whe adjustable sp


applied to the outer end of the valve rod in place of a s

Fig. 1 is a side view, fig. 2 a plan, and fig. 3 is a visection of a safety-valve constructed according to this tion.

a a is a casting secured by bolts to the top of the chest; b is a bushing of brass fitted into it to form the seat; c is the valve, held down by the weight lever d, turns at one end of the pin, c, and at the other receive sliding weight f, and by sliding this weight on the lever


tre on the valve may be varied as desired. g is the fulto which the lever d is jointed by the pin e, and this m is made so as to yield when a heavy pressure is put it. Its stem, g^1 , drops into a socket bored to fit it in the g a, and in a space within this casting the stem, g^4 ,

es the spiral h, which is ed by the nut i e stem, so that, Il be seen, by ing up the nut fulcrum g may eld down in its t with any deforce. A connt way of adg the spring h place a suitable t, f, at the end e lever, and to up the spring l its tension is ufficient to hold the fulcrum g; a stud or stop in the casting such a position as soon as the im g commences



eld in consequence of an excessive weight being applied to ever d, the said lever may come down on to the stud, a then acts as a new fulcrum, and the excessive weight ed then assists the pressure of the steam in lifting the ; l is a cover with openings in it for the passage of the d, and for the escape of the steam; it is secured by so or otherwise to the casting a, so that the valve may be tampered with; m is a screw plug, which closes excess in the casting a, in which the spiral spring is con-

connection with safety-valves arranged according to this tion, apparatus may be applied to indicate when the water in the boiler is deficient by causing the steam to a from the valve. Fig. 4 shows, partly in section, apparat this purpose; n is a bushing screwed into the top of the l



and o is a plug pa freely through valve, o1, is form its lower end, and resting against a fa the lower end o bushing, prevents escape of steam; a spiral spring, tends constantly to the valve or up seat; q is a chain necting the upper of the plug o wit outer end of the v lever d of the value represents a heavy connected by a with the lower co the plug o, and should rest on the face of the water boiler; when, how the water falls too this float, being u ported, its weight down the plug o. by the chain weight of the flo transmitted to the d, and this addi


weight causes the pressure on the safety-valve to be reli

as already explained.

What is claimed is the arranging the parts of a safetyas hereinbefore described, and especially the combined ap tion to safety-valves of a yielding fulcrum for the valve and a stud or stop to receive and support the valve-lev soon as the fulcrum commences to yield. Peet's Invention.—The accompanying illustration represents a valve patented by Mr S. J. Peet, of New York, which is well spoken of on account of the simplicity of its construction and the ease with which it may be repaired.

From the engraving representing the valve in section, it will be seen that the two discs serving to close the valve are raised or depressed by means of the hand-wheel and upright stem B. These discs are suspended on the stem by its collar engaging with the semicircular recesses on their inner faces, and pre-


vented from separating from the stem by the walls of the passage in which they move. The lower face of the collar, B, and the lower portion of the recesses in the discs are made slightly conical, so that, after the discs have reached the bottom, any further pressure on them by the screw of the stem forces them apart and firmly against the walls of thevalve, thoroughly closing the apertures of the pipe. The conical collar, there-



fore, acts as a wedge aided by the pressure of the screw. It will be seen that both sides of the pipe are closed by this means, making this a back-pressure valve as well as a direct acting gate. When the discs are raised, a free passage, without change of direction, is made through the valve for the steam, water, or gas, of the full size of the pipe. The stem is packed in the usual manner by the screw gland D.

Safety-Valve Balance.—This is the safety-valve and balance used on the principal railways. The lever D, fig. 1, is affixed

to a spring balance A, graduated to the pressures per square inch due to the spring. By turning a nut B on the stem of the spring-balance, any required pressure can be thrown upon the valve, which is kept down by the spring acting on its lever. Should the pressure within the boiler exceed that to which the balance is adjusted, the valve is opened, and a portion of the steam escapes. The lock-up safety-valve, fig. 2, consists of a




valve presseddown by a set of strong springs C.the whole enclosed within a under lock box While and kev. the engine-driver has command over the spring-balance valve, so as to increase or diminish the load at pleasure, the lock-up valve is inaccessible to him, and

opens whenever he has loaded the open valve beyond the pressure to which the lock-up valve has been adjusted; thus serving as a check upon him in case of his working at a dangerous pressure.


Safety-Valve and Superheater.—The following is the arrangement of the safety-valve in general use in marine engines:—A is a handle with socket attached, the outside of which socket fits into the top of dome or upper part of valve-chest B, and internally fitting the valve-spindle E. D, D, &c., are the lead weights entirely enclosed in the valve-chest B, C, which is generally cut in two for the purpose of removing the weights on examining the valve and seat F, G. Now for its action through the sockets of A and the upper end of spindle E, a cotter is fitted loosely and bored in the point to receive a padlock, the key of which is given in charge to the captain of the vessel. It will be seen that the cotter hole in spindle is much longer than that of the socket A, which allows the valve and weights when counterbalanced by the pressure in the boiler to

ficient to allow a free escape of steam, independent of

ased by hand engine - room, an be effected n by the dotted As the cotter n the top of ection of B, it the valve to be freely on its any time, and ame time preany weight y be placed on taking effect valve. The ater is used for pose of drying m immediately generation in er, and to premuch as pose condensation same while on sage from the the cylinder.




Slide-Valve. - This equilibrium slide-valve is intended




ent the waste of steam in the ports of cylinders. C is

the face on the back of valve BB, the movable face and exhaust-pipe E is the set screw to screw down the packing





gland with crossbar A. Another modification of the valve is shown at No. 2; the ports in this valve are placed to one side



of the valve face, and the exhaust-pipe BB is cast to the back of the valve, which oscillates on the centre stud D and exhaust-pipe BB, covering alternately the top and bottom ports.


Safety-Valve.—This safety-valve is designed for a small cylindrical (model) boiler, 12 in. in diameter by 24 in. in length.

The valve, with its seat and dome, are of brass. The ball, may either be solid or hollow. Being a true sphere, it is perfectly free to move in its seat, without the possibility of sticking, whenever the pressure of steam in the boiler is beyond that for which the lever is weighted. The dome serves to protect and guide it in its seat.


A serious objection to many of the valves now in use, particularly those of the "mushroom" form with stem and guide, is their liability to stick, and disastrous results have often happened

from this defect. Perfect freedom of action and non-liability

ick, are therefore important features in the construction of fety-valve. The principle of the ball valve is not new.




New Safety-Valve.—The following is a design for a y-valve which will register the pressure of steam as well as



it to escape:—The valve, it will be perceived, ascends as ressure increases, and descends as the pressure decreases.


BB are two bars fixed for the valve-rod to slide through to guide. At the top of the valve-rod R, there will be perceived a small roller to make it run free under the lever L.

Slide-Valve Motion.—Many possessors of small cylinders—say $1\frac{1}{2}$ -in, bore and 3-in, stroke, with steam chest on top—are puzzled to know how to communicate motion to the slide-




valve, so as to be out of the way of the crank and the connecting-rod. The following plans will suffice:—a, the cylinder, b, brackets screwed on back of cylinder flange carrying shaft c, on which is fixed two arms d'd, one connected with the eccentric and the other to give motion to the valve. The arm d' has a slot for changing the length of stroke; the connecting-rod

wed into the eccentric strap for setting valve with the nut ightening when set, f is the support for valve-rod.




Another method is shown in this diagram, which sufficiently lains itself.

Another plan: A, Crankshaft; B, fly; C, eccentric; D, horizontal lever with eccentric-rod on one end, valve-rod on the other,




The following plan is generally adapted to cylinders with valve on top:—It is a spindle on brackets, with lever near the




middle, connected with the valve-spindle by two links. A n

a pin formed on each side, is taped and screwed on the spindle, in order that the valve may be set to a nicety to a d of the spindle, fig. 3. Another lever is fixed, with a hole at the end, and a pin is inserted on which hangs the




ntric-rod. By having a long hole and movable pin, the ce of the valve may be set to the desired length. Fig. 1 is a ; fig. 2, elevation; fig. 3 shows the rocking-shaft or spindle with the levers and links attached to the valve spindle. nother method is shown in next diagram:—A is sole plate, ylinder, C connecting-rod, D rocking-shaft, E levers on



ing-shaft, F pedestals to carry rocking-shaft, G eccentric-H connecting-rod for slide-valve,

eversing Motion in Engines.—The following is a simple ingement for altering an engine, so that you may reverse it will, which can be done according to this plan with one

eccentric, and doing away with eccentric-rod, and using a lo valve-rod and a link:—Fix a plate to the eccentric-strap, also a link (as will be seen in sketch) extending from D to




B is a rock-shaft working on a pin fixed to centre of plat and another pin fixed at F on a plate bolted to engine-st When the engine is at work the rock-shaft will give motio link as if using two eccentrics; and by moving the lever the dotted lines G^t , the sliding-block will be moved fron position at top of link (as seen in sketch) to the bottom of and so alter position of slide-valve and reverse the engine; by moving the lever G into some of the notches marked a the travel of valve will be short, and so allow the stear cylinder to expand by closing the ports sooner, and allow less steam to enter the cylinder. The parts G, H, J, K, at can be fixed to engine-frame or stand in any position suited to the plan of engine.

Setting the Slide-Valve.—First, the steam is to be

off a little before the end of the stroke by closing the aperture of the steam-port which causes the piston to be brought gradually to rest without jarring the engine. Secondly, the eduction-port or passage to condenser should be closed before the end of stroke, which is called "cushioning" the piston, because it then completes the stroke against an elastic air-cushion in consequence of a portion of uncondensed vapour being shut up between the piston and the top or bottom of cylinder. Thirdly, the steam-port on the same side of the piston should be opened a very little before the end of the stroke, so that the steam may have acquired its full pressure as soon as the crank shall have turned the centre; and lastly, the communication with condenser should also be opened on the opposite side of the piston a little before the end of stroke, so as to have a vacuum ready made in the cylinder before the return stroke begins.

Boiler Feeding.—Several modes of feeding a boiler without a pump have been suggested from time to time, but the follow-

ing will be found practicable:—A is the steam-boiler, and B a tank some distance above; is fed by a pipe F, with a flap-valve opening into the tank as shown. This tank is also connected with the boiler by two pipes C D, in




each of which is a cock C¹ D¹ connected by levers with slotted eyes to a pin, on the end of a rod of iron H; the other end of the rod is coupled to the float E inside the boiler.

The action is as follows:—Suppose the water in the boiler was to get low, then the float E would go down with it, bring down the slotted levers and open the cocks C^t D^t in the pipes C D, which would open two communications between the boiler A and the tank B; the pipe C letting steam into the tank and forcing the water down the pipe D till the water in the boiler regains its level when the float rises, shuts the two cocks, and

cuts off the communication with the tank, which then fills again through the pipe F. The flap-valve is to prevent the water returning down the pipe F.


Boiler Construction.—The fire tubes passing through the steam space of boiler would not heat the steam, but would construct the steam.




dense it, in proof of which an egg-shaped boiler work had the flues but 2 inches higher than the water-line, and was a consequence unable the keep up a constant supply of steam. But when the flues were lowere 2 inches below the water line, a sufficient supply was kept up. The upper tube plate, though

placed in a horizontal position, would not impede the rising of the steam. The dotted line in sketch shows where the flucwere lowered to.

Boiler Working .- An old rule for Cornish, and 2-flue



boilers, is to allow s square feet of water surface per horsepower of boiler; theres fore we make the total boiler horse-power from 1½ times to 2 times the nominal horse-power of engine



Steam_Propelled for Model Boats.— Various contrivances have been adopted from time to time for propelling small boats, Mr W. G.

Kemp suggested the following:—A, boiler; B, furnace; C,

es; D, safety-valve; E, guage tap. The steam-pipes made of indiarubber.

n examination and trial, proved to be a failure, as the idensed with propelling the boat; but it was found e end of the steam-pipe were brought to a point with mall hole in it, and inserted into another pipe, so to leave a space all round the entrance of the point of pipe, the rush of the steam drew in with it a quantity ich it forced out of the stern of the boat, and conserced it through the water at a very fair speed. It better when the keel of the boat was made wide at and two thin pieces of metal were fastened on the

to force ctastern, the pipe brought




es of thin ened each teel; B, eam-pipe

to the air-pipe; C, steam tap; D, D, water-level taps; safety-valve; G, pipe attached to valve to carry off m; F, water level; H, spirit lamp.

r method is described in the following diagram :- A,

ball; B, pe from ball; C, m ball ottom of l D, pipe through bat. To of steamattached hich pron the ball ts centre, line with



de of pipe C, as shown by dotted lines at E. The he steam in rushing through the nozzle tends to form

a vacuum within the ball; immediately the water rushes up the pipe C, and, being caught by the steam, is forced through the pipe, and so keeps up a continuous stream.

The general principle of the screw-propeller may be thus described:—If a thread be wound upon a cylinder equal distances apart, it will trace a single-threaded screw: if another thread be wound on the same cylinder between the first thread they will trace a double-threaded screw. Now, if the threads be supposed to be raised into a very deep and thin spiral feather, and the cylinder be supposed to become very small, then a screw of the proper kind will be obtained for propelling vessels, except that only a small piece of such screw must be employed. A two-bladed propeller is a short piece of a double threaded screw, a three-bladed propeller is a short piece of a triple-threaded screw. The diameter of the screw is the circle described by the extremities of the arms, the pitch is the distance in the line of the shaft from one convolution to the next Sometimes screws are made with an increasing pitch in the direction of their length, also from centre to circumference The original screw propellers were made with several convolutions, but are now reduced to about 1-6th of a convolution The term length indicates what portion of a convolution is employed. If a screw of 9 ft. pitch has 1-6th of a convolution, the length will be I ft. 6 in. The slip of the screw is the difference between the actual speed of the vessel and the speed should attain if the screw worked in a solid nut; this is called the positive slip. There is also the negative slip, where the velocity of the vessel is actually greater than if the screw worked in a solid nut, though the latter is not of very frequent occurrence.

Railway Signals.—All travellers by railway are familial with the ordinary mode of signalling by means of movable arms or semaphores and lights, and probably not a few of them are acquainted with the signalman's jingle—


"White for right, red for wrong, And green for gently go along!"

But the best system is that now adopted, first, we believe, on the South-Western system.

After the introduction of Mr Preece's plan of Block Signalling on the South-Western, these repeaters, which are similar in on to the block instruments, were fixed in one or two experiment, and the experiment was so successful, and so valuable, that they were gradually extended.


reat merit in these truments is the assif the indoor or blockthe outdoor, so that phore, disc, or other used on the line to engine-driver, the has that signal under ol is himself in the warned by a similar, ature, semaphore or de his box, so that is necessary that a ould be repeated and ble to the signalman, I in his box is made n form, but in miniathe outdoor signal every motion, therehe signal lever would corresponding result small signal, enabling Iman to see instantly all was right,

t will be seen a front a small semaphore; nows an elevation of or arrangements, both showing the semarm down, giving the ear" signal. A is a orse-shoe electro-magat the bottom of the is the armature pivot-, and weighted at W



hall weight, which is made to slide up or down the lever between G and C. At the end of this lever, at ached a long lever to the head of the semaphore arm. The armature has a limit to its movements by the stops and E.

It will be seen that any motion up or down of the an must exercise an opposite motion of the long lever CI exercise an influence upon the arm to raise or depress current of electricity passing through the electro-magnet



at once exercis netic effect, and the armature attracted: this have for effe immediate rai: the semaphon which would 1 in that positi long as a c flowed round magnet; imme on the cessat the current, th tro - magnet cease its actic armature won reason of the W, be restored original positic the arm woul and give the clear" signal, the diagram. be seen, the that by the and cessation current we car or depress a phore arm; an if there be cor


some automatic arrangement in connection with the or signal to effect this object, we have at once a faithful re in the signalman's box of the outdoor signal, however dis may be.

: Such an arrangement as the following has been adopted. At **he head of** the semaphore, close to where the arm is pivoted. the fixed, one on each side, and insulated from each other, two ings, the one in connection with a live wire to the signalmn's box, where it is attached to one end of the electrognet, the other spring is in direct communication with the with. Upon the arm itself is fixed a piece of brass, so that hen the arm is raised it presses up between the two springs **nd completes** the circuit, but only when the arm is almost by raised. In the signalman's hut is placed a battery, one of which is to earth, the other to the electro-magnet. The ttery circuit is, therefore, through the electro-magnet, insulan taking place at the spring of the semaphore. In this exition, therefore, the miniature semaphore is at "All clear" be same as the distant signal itself. Immediately the signalm moves his lever to alter the signal, the arm is raised, the piece on the arm completes the electric connection etween the insulated spring and the earth spring, the battery **at once brought** into play, the magnet acts, the armature is **Miracted**, and the small semaphore arm is raised to "Danger." presponding with the outdoor signal. The whole of this kes place in a far shorter time than it has taken us to The action is almost immediate; so long, therefore, the arm is raised to the position of "Danger," the miniature m faithfully reflects that position; but as soon as the lever restored to its original position, the distant signal is lowered, e circuit is broken, and the armature is at once released, the mall arm therefore falls, and shows the state of the distant Should the miniature arm remain down when the **Expalman** puts his lever over, he is at once aware that his wire part of the signal apparatus is out of order, and would con**requently** take immediate steps to put it right.

In order that the battery may not be wasted, it is arranged that the signal which is used less than the other should attract the armature: thus at a junction the "Danger" signal is contantly in use, the "All clear" only to admit a train. At a station the distant signal is generally at "All clear." So in the one case we want the armature when attracted to lower the term, and in the other to raise it. By referring to the sketch, the attraction of the armature will in this case raise the arm; but if the lever on the arm be fixed in front instead of behind

the pivot D, the attraction will raise it, and vice versa. What it is necessary that the "All clear" signal or the lowering of the arm should bring the battery into play, then the insulated springs must be placed at the back of the semaphore, and the brass connecting-piece at the back of the arm. When a placed, no current is passing when the arm is raised; the repeater, by gravity, has its arm up; but when the signal-arm is lowered, it makes connection, the electro-magnet is brought into play, and the small arm is lowered.

As semaphores are now being generally adopted everywhere we have described the arrangement adopted, but on various



lines there are diff ent signals in ac to which these peaters are equa applicable. South - Western t disc, on the Gre Western and North Western the disc an bar, as the following sketches, 3 and 4 show. Instead of up-and-down motion. these signals are altered by a circular movement is a miniature "disc." the interior arrangement of the electro - magnet

similar, but at the end of the armature is placed a rack which works into a pinion fixed on the rod that carries the disc. The attraction and release of the armature conveys a circular motion to the rod; the disc is consequently moved from the one position denoting "Danger" to the other denoting "All clear." As the motion of the disc outdoor is different to that of the semaphore, the connection necessary to put the live wire to earth is consequently different.

Upon the wooden upright that carries the disc-rod is placed a piece of brass, fitted with a spring to ensure contact; this is


erly connected, and is protected from wet by an iron roof.

In the rod which is in connection with the earth is fixed a
nd piece of brass with a spring; this is fixed at the same
ht, and is so connected that when the disc is turned these
ngs make a good rubbing contact.

he action is of course similar to that of the semaphore: ediately the lever is pulled, the disc turns round and the ags make connection, the armature of the miniature disc is

cted, and by the rack-andn movement the disc is ed into a position corresling with the outdoor signal. n the disc is turned the site way, or to "All clear," act is broken, the weighted ture falls back, and "All " is shown in the signals hut. The contact arranget on the outdoor signal is lar to what would be applied ignals such as are used on Great Western. To make miniature signal agree, it is necessary to fix, instead of disc, a disc and bar, as in


lany of the discs and semare repeaters have been fixed he South-Western and other is for some years; they give it satisfaction, and continue rork well. In places where, and fine weather, the signal is



ole, yet in consequence of the place being situated low, and g liable to fog, there are very many days in the year when signal is invisible. In such places some extra precaution his nature should be taken.

lectric Railway Signal.—The object of this new appas is to prevent the possibility of a signalman signalling that line is clear until the train which should control his movements has actually passed his box. There is applied to switch or lever of the railway-signal telegraph apparatus a m of locking the handle or lever after it has been used to at a signal, and of retaining it in a fixed position until release the action of a passing train, which will remove the cause retaining, say, the danger-signal in a fixed position.

Fig. 1 is a back view of the apparatus, fig. 2 an inverplan view, and fig. 3 a vertical section taken in the line



of fig. 2. The switch-lever apparatus is connected (as sl at A, fig. 4) with the railway by an arrangement of levers rods, which are set in action by the passing train for the pose of withdrawing a restraining bolt applied to the hand lever of the switch apparatus, and thereby leaving it free t set in action by the signalman.

a is the handle or lever of the switch apparatus mounted on eentre at b, the bearing for which is insulated by being let hto a table of wood c. Fitted to opposite sides of the switch handle are the spring-clips at at, which are intended to embrace the divided bridge or insulated segment-plates d d3, connected by clamping nuts e e3, to electric wires leading to the terminus The switch-lever is also in metallic contact with a wire eading to the terminal et. A pin at at the lower end of the witch-lever a projects into the forked end of a bell-crank ever f, mounted on the under side of the table, and fitted at s opposite end with a spring catch or tumber f. As this witch-lever a is moved it will give a rocking motion to the Ill-crank lever, for the purpose to be presently explained. The wer part of the switch-lever has a notch cut in its edge to neive a sliding bolt g, by which it is locked in its normal sition. This bolt is carried by a slotted guide-bar gt through e slots of which screws are passed for securing it to brackets tached to the under side of the table. This guide-bar is proided on its face with a pin gt, against which the spring-catch is intended to strike in one direction of its motion, for the urpose of driving that bar forward, but on its return motion he spring-catch slides over the pin. Upon the edge of the uide-bar is a second pin or projection g3, through which the ar receives an endway motion in the opposite direction to that mparted by the bell-crank. This pin g3 is acted upon by a pendant-lever h, which is itself acted upon by a vertical rockever i, fig. 4, connected at its lower end to a sliding-rod h; his rod k is caused to bear against a horizontal-lever or switch applied to the railway track, as shown at fig. 4; and in plan riew at fig. 5, a spring m, or a weight, being used to keep the od up to its bearing. Supposing now a train to be passing long a line fitted with the locking apparatus above described n the direction of the arrow, fig. 5, the switch or lever / will, by the lateral pressure it will receive from the flange-wheels bassing between it and the fixed rail, be rocked, and it will thus give an endway motion to the rod or tracker k, which will in ts turn rock the levers i and h, and the latter, striking against he pin on the bar g2, will drive it and the bolt which it carries nto the dotted position of fig. 2. The switch-lever will, thereore, be free to be moved from the drawn to the dotted position of fig. 3, for the purpose of operating a distant signal.

As this apparatus is specially adapted for use with Mr Preece's block-signal telegraph apparatus, in which the semphore arm is maintained by a weight and depressed by the action of the electric current, it is used in the following manner, viz.:—The terminal e is connected with the earth, the terminal e3 with the battery, and the terminal e4 with the line wire. When, therefore, the hand-lever is in the drawn position of fig. 3, which is its normal position, there is no current passing through the distant signal apparatus which the switch apparatus is intended to control, and the block-signal is consequently us; on the other hand, when the hand-lever is in the dotted posttion, the current will pass through the distant signal apparatus, and retain the semaphore arm at the depressed position, thereby indicating "line open." If now the signalman at the distant station A signals to the man at station B, that a train has started from A in the direction of station B, the duty of the receiver of this signal will be immediately to raise the block signal at station A; this he will do by throwing over the switch-lever B into the drawn position; but in the act of doing this he will cause the bell-crank lever f to strike the pin g a the sliding-bar g', and throw the bolt g into the notch of the switch-lever; the lever will therefore remain fixed, and be beyond the control of the signalman at station B. however, as the advancing train passes the switch or lever l, and sets the rod k and lever i k in motion, as above explained, the guide-bar g' and bolt g will be returned to the dotted position of fig. 2, and the signalman will then be able to set his switch apparatus in action. If, however, he should delay in communicating the proper signal to station A that the line is open, no casualty can arise, the only inconvenience being the undue blocking of the line.


This apparatus is in practical operation on the London and South-Western Railway, and is spoken of very highly.

Fog Signals.—The following plan, if capable of being reduced to practice, would displace the explosive fog signals now in use. It also acts as a distant signal. The original part of the proposal is the adaptation of the bell-crank lever H, so as to strike a bell F in a passing train by means of a lever G, or similar contrivance placed outside the guard's van and engine. It will be seen by looking at the dotted lines that

when the semaphore L is down, the lever B is lowered, and causes H to fall below the level of the lever G, attached to the train. Therefore, only when the semaphore is at danger is the

the guard and driver. The lever is put so far down the line as to enable the driver to stop the train on arriving at the aemaphore post.


A, signal-post;
B, lever, with
weight; C, wheel
at the signal-box or
station; D, railway
line; E, hammer;
F, bell; G, lever,
with weight; H,
bell-crank lever; I,



chain to connect H with B; K, chain to connect C with B; L, semaphore.

Self-Acting Railway Signals.—1. Below is a self-acting signal, said to possess advantages over previously-invented

plans of self-acting signalling. Fig. 1 is an elevation; fig. 2 a plan. The same figures refer to both drawings. On the train passing the post, A strikes the lever B, and causes the signal C, which is provided with a lamp for night sig-



nals, to turn to danger, the lever B on being struck causes the wire or rod D to move in a forward position, so that when the

train reaches the lever E the signal is put to "All right." F are the rails.

2. The next self-acting apparatus we shall describe is intended to be fixed on the side of the permanent way.




Fig. 1 is a front view, showing all ready for the first wheel of the engine or carriage to press it down on the lever D. Fig. 2 is an end view, showing other working parts of the appa-

ratus, with the signal, fig. 4, attached to the lever P. Fig. 3 is a top view.

Suppose a train coming up to where a signal is placed. The wheel L in fig. I comes on the lever D, passing down which is a slide-bar, having a square or round hole K in the middle, a little lower down a cross-pin or the eye-lever, and at the bottom a joint for lever P. At S is a powerful spring to lift up the slide-bar C. When C is brought down, peg F is forced by the spring G under the hole K, and working the lever P brings the signal up for the next train, N is a strong elastic, fitted to take the sudden jerk which the engine would make. H is the eye-bolt for the peg to work in, I is to fasten wire, and I to plug or peg F. Suppose the train has passed over the lever D, down goes the bar C, in goes the peg F to the hole K, which is a great deal larger. The first signal is up, and now we come to the second, just similar to fig. 1; the wire II is attached to the wire I in the first one, and by passing over the second one works the lever M, withdraws plug F, and by the action of the powerful spring at the bottom, up comes the bar C on lever D. and down goes the signals, the one that we commenced with reacting for the next train to come to the second signal; and the signalman can tell whether the first train has passed over the third apparatus by seeing whether the signal is down or not. The latter train cannot run into the other unless the signals are neglected. [There is considerable ingenuity in this idea,]

Railway Brakes.—The following is perhaps more suited for goods than for passenger trains. It should be fixed on

both sides of every truck of the train.

a is the cill of the truck, bb the irons connected with the wheels, c the rail to tie in wheels, d is a




on the brake of which ec swings, f is a lever in the centre the truck, g is a spring to keep off the brake. In case of oger, the driver would tighten the wire-rope hh. This would raise the lever f, which would bring the ends of the brakes in contact with the rim of the wheels. These would lay hold of

the brake, and force it on so tightly that the wheels must skid. [This idea has not, we believe, been investigated with any practical result.]

Communication between Passenger and Guard.—Among the suggested means of arresting the attention of railway guards by passengers in the carriages, the following crude ideas have some claim to attention:—

1. This consists of a circular tube, which is fastened in the interior of the panel which divides the compartments to the side of the carriage.

AA is the side of the carriage; B is a metal tube fastened to its inside, a spiral steel spring is contained in this tube, and fastened to a rod I. This rod has a metal plate D on one end,




which secures it at C. and holds the spring On the other end of the rod a hammer head is fixed. When the knob E is pressed, it shoves the plate D from its place, when the force of the spring will send forward the hammer. which, striking on the bell F, placed on the outside of the carriage. would attract the attention of the guard. The hammer would

remain outside, and the carriage where assistance was wanted be seen immediately. If any passenger used this "facetiously," the trick could at once be discovered, as the only part of the apparatus under the control of the passenger is the knob on the outside of the panel, as shown at G, and the spring could not be placed in its former position except by opening a small door in the panel, which would be kept locked.

2. In the following plan, there would be the necessity of the guard's van being higher than the other carriages. There are other evident objections to the details.

ing the handle B you not only ring the bell, but also alarm signal C to the position shown by the dotted


the alarm ere is a red glass, is painted er of the which, ised, exon the



the lamp howing a red light. By this means the guard would ed to discover, either by day or night, the carriage

ch the signal is made.


every carve a loud :hed, with id handle, ind handle ery com-



;, so that the pulling of the handle would cause the bell


and so attract d's notice. 'd's van be built higher than the rriages, so that l always have a of the train, and n all was right. this scheme the done away with, :plosive signals ted.

is the side view. are four common fog signals; each oated, and made y air-tight (glass answer the purst), so as to pro-



shaped as shown in fig. 3, and made about the size of a small oyster. BB represent the sides of box in which the signals A are enclosed. CC are two square spouts or channels, leading down, one to each wheel—on the side of the carriage, on which the machine is fixed—as shown in fig. 2. These channels are just large enough to admit of the free passage through them of the signals A. DD is a self-acting guide, placed at the junction of the two channels CC, and works on its hinge B. The upper portion of the guide DD is just weighty enough to cause it to rest in the position seen in the sketch, or in that of the dotted line.

The lower part of the guide is a light square board hanging beneath the flooring of the carriage, and is acted upon by the



rush of air when the train is in motion. Thus it will be seen that the channel on the right or left hand side will be opened as the direction of the train may require. F consists of a lever. slide and spring, the working of which will shortly be explained. E is a wire, and may be connected with ordinary bell handles in each compartment or to each seat if thought

proper. The apparatus may be placed under the seat, or any part of the floor, but is best about midway between the two wheels. The box BB and the channels CC may be made of thin sheet metal.


The working is as follows:—The bell handle G being touched, the lever F is operated upon; the small slide N is withdrawn, thus releasing the bottom signal A, at the same time the spring M presses against the second signal A, and holds it in its place until the slide returns, when the second signal takes up the position of the first. The first signal A being now at liberty, passes down the left-hand channel C, and

is delivered under the wheel, fig. 2, which runs over it and causes it to explode. This, as in the case of an ordinary fog signal, is accompanied by a loud report, which would call the attention of the guard and the whole train. In the foregoing description the train is supposed to be proceeding in the direction of the arrow in fig. 1. Should the train be going the opposite way, the guide DD would be reversed by the pressure of the current of air on the lower part of it, and would then lie in the position of the dotted line, thus opening the channel C on the right-hand side, down which the signal A would slide, and be delivered between the wheel and the rail as before described. The alarm may be repeated as long as there are

any signals A in the box, which may be constructed to contain any number.


One advantage to be claimed for this scheme is that no connection between one carriage and another, along the whole length of the train, is necessary to effect a communication with the guard.

5. The following plan suggests oral communication between passengers and guard. It is proposed to place beneath the floor of each carriage a metal speaking tube, connected between the carriages by a continuation of indiarubber tubing, coupled as shown in the annexed drawing, forming a line of communication between the guard



and driver at either end of the train. The pipe to be supplied at each end with an alarm whistle.

Each compartment of the carriages should be furnished with an intercommunicator, which would enable the passengers to communicate with the guard or driver through the same pipe. Across the mouthpiece in each carriage it is also proposed to place a small clasp, secured by a seal (that must be broken before the apparatus can be used), which, by being the means of detection of, is therefore a security against, improper use.



A, communicator, as seen in the carriage; B, intercommunicator under the floor of ditto; C, screw coupler between the carriages.

To communicate, break the seal, pull out the pipe as far as it will come, and hold it so till your communication is complete, tell the guard the number of the carriage, then let the pipe return to its place by the action of the spring.

Tramway Locomotives. — The introduction of the tramway in the London streets will eventually, we have no doubt, lead to the

employment of the locomotive instead of horses. Messrs Aveling & Porter have adapted one of the road locomotives for a tramway at Mr Gray's Chalk Works, Essex, for the purpose of hauling up the excavated chalk to the docks. This engine we now describe. On the top of the boiler, easily accessible, is arranged the gearing. A pinion on the crank-shaft gears into a spur-wheel on a second shaft, from which motion is transmitted to the driving-wheels, four in number, by an endless chain. The engine is of ten-horse nominal; cylinder, 10 in diameter, 12-in. stroke; grate surface in fire-box, $7\frac{1}{2}$ square feet; number of tubes in boiler 60, each $2\frac{1}{4}$ in. external diameter. There are two feed-water tanks, one under the coal

tender, and the other under the front part of the boiler, holding collectively 350 gallons. The wheels are 4 feet diameter, with short tyres, coupled, as shown, with an endless chain, which can be tightened by an apparatus consisting of a slot in the main bracket, in which the bearings of the shaft can be raised and lowered. The cylinder is jacketed, steam being carried around it to the valve-chest. The boiler is fed by a pump worked by an eccentric on the crank-shaft. The fuel is carried in a coal-bunker formed on the foot-plate behind the fire-box. sufficient space being provided to accommodate from 10 cwt. to 20 cwt. of coal, according to the mode of packing. Gray's the line leading from the quarries to the wharves is about a mile in length, and is laid to the 4-ft. 81-in. gauge. At the quarries it divides into two branches, one having an incline of 1 in 36 to 1 in 41 against the traffic, the incline being, moreover, situated where the line makes a series of reverse curves. The other branch has a steep incline where it leaves the pit. On the former branch the load of the engine consists of 15 waggons, weighing about 11 tons each, and each containing 12 tons of chalk, the total load being thus 45 tons, in addition to the weight of the engine. But the engine can take 20 loaded waggons up the bank, and a still heavier load has been hauled. On the latter branch the load of the engine consists of 15 waggons, weighing 11 tons each, and each loaded with 21 tons of chalk. Thus the load, exclusive of engine, is 561 tons. As to economy, we learn that during one week the 2 engines formerly employed conveyed 3138 tons of material from the quarries to the wharves, with a consumption of 1411 cwt. of coal, the fuel consumed being thus equal to 5 lbs. per ton drawn. On the other hand, two of Messrs Aveling & Porter's engines transported during corresponding week 5100 tons of material, with a consumption of 125 cwt. of coal, the expenditure of fuel being in this case equal to about 2\frac{3}{2} lbs. of coal per ton hauled. It is estimated that this difference in the quantity of coal required to perform a given work will save the company upwards of £260 per annum. Altogether, these engines have given abundant evidence of being well adapted for use in quarries, and wherever heavy loads have to be moved at slow speeds-doing the work at about half the cost of horse-power. The engines can also be employed to drive portable or fixed machinery. All the wheels being coupled, the whole weight is available for producing adhesion to the rails, which is sufficient for the requirements of such lines.

Wheel Grease.—Nothing is equal to tallow for large cogwheels; but a good grease may be made of tallow 25 pounds, tar 25 pounds, soda 15 pounds, and water 3 or 4 gallons. Boil the soda and water till the former is dissolved, then add the other ingredients, and boil till thoroughly mixed.

Rifle Stadia for Judging Distances.—An apparatus of the kind, for rifle practice, patented by Mr D. M'Callum, has been approved and extensively used in some districts.



900 yards.

- Place the butt of the rifle on the ground, with the toe of it towards the right.
- 2. Then place the piece of metal in muzzle with end marked 'Foot' upwards, if the distance of a man be required.
- If the distance of a man on horseback be required, place the end marked 'Horse' upwards.

Steady rifle with left hand, and with the finger and thumb
of the other hold the tape closely to the eye on the cheek-bone.



100 yards.

- 5. Then look at the object through the aperture, and slide the face along the tape until the eye definitely and completely covers the feet of the man and the top of his cap, or the hoof of the horse and the cap of its rider.
- 6. Now observe the mark on the tape where the finger is, and it will show the number of yards distant. Thus: Should the finger appear at the first subdivision beyond 100, the distance would be 110; if at the second subdivision, it would be 120 yards, &c.
- Should the object be more than 350 yards off, it will be necessary to screw the ramrod in the centre of the piece of metal.

and steady the rifle with the ramrod by holding it securely and keeping the tape at its full tension; then proceed as before.

Gun Cotton.—The following is stated to be the best and implest process for making gun cotton. Saturate some cotton rool in a solution of equal volumes of the strongest oil of itriol and nitric acid for a few minutes, then express the uperabundant liquid out of the cotton, and wash it in cold rater until all taste of acidity has gone; lastly, dry at a gentle reat, about 120° or 130°.

Force of Gunpowder.—When gunpowder is heated nearly up to the point of decomposition, previously to ignition, the orce of its explosion is greatly increased. It is stated that a temperature of 160° Fahr, increases the force of the explosion 1-5th, while a temperature of 400° nearly doubles it. This may in some measure account for the fact that highly-heated guns are liable to burst if the charge has been allowed to remain in the chamber a sufficient time before firing.

Gun Barrels.—To Bore.—Take a piece of rod, cast steel. in, smaller than the interior of the barrel and a few inches longer, beat one end up something larger than the size of bore, then turn or file it the shape of an egg, leaving the swell or centring part 1-20th of an inch larger than the bore. With a saw-file, cut longitudinal cuts & in. apart, laying them the same angle as a rose-bit countersink, taking care not to injure the periphery of the tool; harden, and temper to straw colour. Staining.—Spirits of wine I oz., tincture of steel I oz., muriate of mercury $\frac{1}{2}$ oz., nitric acid $\frac{1}{2}$ oz., and water 1 quart. The above mixture must be well incorporated before use. *Process.*—I. The grease to be removed by coating the gun with lime, put on in a thin paste, and allowed to dry, then brushed off with a clean hard brush. 2. The mixture to be laid evenly on the gun with a sponge, and allowed to stand till dry. This operation to be repeated as frequently as the gun dries, for the first ten hours, then the rust to be thoroughly scratched off with wire cord. 3. Coat with mixture, and let it stand till dry; if the gun rusts freely, no more mixture need be applied, but that already applied may be scratched off with wire cord at the end of ten hours if dry; but if it should rust slowly, then one or two extra coatings of the mixture may be laid within the ten hours, taking care that the old rust is dry before again applying the mixture. 4. As soon as the barrel is dark enough, it must be immersed in boiling water to kill


the acid, and then oiled with olive oil while warm; then remove the oil with turpentine, and varnish with copal varnish.

Browning.—Equal parts of butter of antimony and olive oil to be rubbed on while the barrel is hot, expose to the air till sufficiently brown, clean carefully, and coat with a thin shellar varnish. Butter of antimony is a powerfully corrosive poison, and must therefore be handled with care.

Colouring.—First clean the barrel perfectly, but do not touch it with the hands. To avoid this, put a stick or plug into the end of the barrel to hold it with, then apply the following mixture with a rag (not too much at a time, if a twisted barrel, as you will not be able to get the twist to show properly). After the colour-matter gets dry, it must be rubbed off with a steelwire brush. For a plain barrel—\frac{1}{2} oz, nitric acid, \frac{1}{2} oz, spirits of nitre, 2 oz. sulphate of copper, I oz. tincture of steel, 8 gills of water. For a twisted barrel—\frac{1}{2} oz, spirits of nitre, \frac{1}{4} oz, sulphate of copper, I 5 grains of mercury, \frac{1}{2} pint of water. After having stained the barrel apply the following polish:—2 oz, spirits of wine, \frac{1}{4} oz, gum Benjamin. Put it on with a soft rag or camel-hair brush: use it quickly, or it will dry very fast.


The Verge Escapement.—Every one who wears a watch should know something of its mechanism. He would then be better enabled to take care of it, and set it right when it went There are three kinds of escapements used in modern watches—the Verge, the Horizontal, and the Lever. is the oldest, and in some few respects the best. The parts of a verge are the cock and foot pallets, also cock and foot pivots, and the "collet," or piece of brass soldered on to the top, and to which the balance is riveted. The parts of a pinion are the leaves or head, the arbor, and the pivots or bearings. The parts of a wheel are the teeth, the rim, and the cross; if the wheel is not riveted on to the head of a pinion, a "collet" is driven on to the arbor, and to which the wheel is riveted The escapement is the term used to illustrate the action of the pallets in connection with the last or scape wheel, one tooth of which escapes at each vibration of the balance. wheel or verge escapement was the first invented. shows how it is arranged in a watch. B is the balance, the axis of which is the verge; P' is the cock pallet, and P is the not pallet; the top or cock pivot runs in the cock C, and the nottom or foot pivot in the potance X. S is the hair-spring and stud. The scape-wheel O, also called the balance-wheel, s riveted on to the head of the pinion; the pivot inside the wheel runs in a dovetail fitted into the nose of the potance at N, this dovetail is made to slide in and out, so as to get the hole opposite the body of the verge, or the escapement equal;

the pivot at the other end of the pinion runs in a hole in the follower F, which is fitted into the counter - potance. The contrate-wheel W is not riveted on the pinion, but has a "collet" on the arbor to enable it to work into the scape-pinion. The




teeth and rim are contrary to those of other wheels, whence it takes its name. Fig. 2 shows the details. X is the potance; T is the counter-potance, which is riveted into the top plate, and into the hole of which the follower F is fitted; V is the verge with the "collet" turned down to fit the balance; Z is the hair-spring "collet;" B is the balance; S is the hair-spring stud, the outer coil of the hair-spring is pinned into

the stud, and the inner coil is pinned into the "collet," which fits springtight on to the verge collet and close up to the balance, and can be set to any place by turning it round on the verge with a



screw-driver put into the notch; D is the regulator, fitted into a slide so that it can move in a circle having the verge as a centre, the end of the regulator projects under the outer coil of the spring, and has two small pins rising up from it, and between which the spring plays. The effective length of the spring can thus be altered by moving the index to fast if the

watch loses, and to slow if it gains. If the regulator is at fast or slow, and the watch continues to gain or lose, the spring must be altered from the stud, that is, more spring let out if gaining, and if losing more spring taken up. To do this, put a bristle into the cross of the contrate-wheel to prevent it running down; then take off the cock C (Fig. 1) and unpin the spring out of the stud with a pair of tweezers, take out the verge and turn the collet round with a screw-driver in the direction to bring more or less spring through the stud as the case requires; having done this, replace the verge, join in the spring, and put on the cock again. Then try if the watch is in




beat: thus, supposing the balance is at rest and the banking pin at B, if the contrate-wheel is pushed round slowly and steadily with the thumb, the pin will be drawn first to A and then to C if the watch is in beat: if it is not, the "draw" will be more to one side than the other: if C has most draw the spring must be let out a little. and if A has most the spring must be taken up a little. We must now ex-

plain the action of the escapement. The verge pallets are nearly at right angles; the scape-wheel has always an odd number of teeth, so that a tooth on one side is opposite a space on the other, and when one pallet is in action the other is out of action. Fig. 3 is a sketch of two escapements, the teeth of the wheel and the pallets are enlarged. The wheel must be supposed to be turning on its axis with the teeth I and 2, and the cock-pallets P I at the top, and the dotted teeth and the foot-pallets P P at the bottom. Tooth I has just escaped from and given impulse to the pallet PI, and the dotted tooth has

dropped on to the pallet P, the balance B is "vibrating" or turning in the direction of the arrow, and will continue to do so until the impulse is exhausted by the bending up of the hairspring and the "recoil" or backward movement of the wheel produced by the dotted tooth opposing the pallet P; the balance will now be brought back by the tension of the hair-spring; the dotted tooth will then give impulse to and escape from pallet P, the next tooth dropping on to pallet Pr, as shown by tooth 2; the balance B' is vibrating in the direction of the arrow, tooth 2, opposing pallet P', producing the recoil as before. will thus be seen that two contrary vibrations of the balance take place before a tooth has completely escaped. The banking is to prevent the balance turning round too far, in which case the pallet would be turned away from the wheel, which would of course run down with great force, and break its teeth by striking against the pallets when they turned round again. The best banking is a pin in the balance at B, and therefore moving in a circle round the edge of the cock C, fig. 1, which covers the balance. The extent of the banking is determined by the pin meeting two projecting parts of the cock which reach beyond the circle the banking-pin moves in. The bankings are made as wide as possible, and for the teeth to have a fair hold on to the pallets. Thus, supposing the banking-pin is turned by an accidental jerk to B, fig. 4, the dotted tooth I will act on pallet P, and bring the balance round again; and if the banking-pin is at B1, the tooth 2 will act on pallet P1, and bring the pallets into action again. The great defect in the verge escapement is the "recoil," the wheels being carried half as far back as they have advanced, consequently the verge and dovetail holes wear very wide, and when so worn the watch cannot go well; the constant rubbing of the wheel-teeth on the pallets wears the verge out, and also the tops off the wheel-teeth, not all alike, but very irregular; hence the wheel often requires topping or recutting. The nose of the potance must be filed to let the wheel up closer, and then the counterpotance filed away to let the follower up, or, what is much better, a new follower must be made. The verge escapement could be constructed much better, but as it is now nearly superseded by the lever escapement, no improvements are likely to be adopted; but as there are a great many verge watches in use, a knowledge of the escapement is still required to keep them in repair.

Four-Legged Clock Escapement.—The following are the particulars of Mr Denison's Four-legged Gravity Escapement for regulating clocks:—

Fig. 1 is a view of the escapement, looking at the back of the clock. Fig. 2 is a section of the escapement and part of the train of wheelwork. The letters refer to the same parts in



both figures. EF is the scapewheel of a diameter of three inches, the acting faces of the four teeth being at right angles to each adjacent one. On the central disc of the scape-wheel are set eight pins, four pointing one way and four the other. These pins are \(\frac{1}{8}\) of an inch from the centre of the wheel, and one set of four are to be placed on a line with the acting faces of the teeth, and the remaining four equidistant between them.

A,B,C,D are the pallets which are lifted by the pins of the scape-wheel acting on the arms The stops on the pallets are shown at GH, and the proper placing them requires a little attention. In drawing out the escapement, the scapewheel should be placed within both as at E, and the next look will show the proper place for the stop H to be screwed to the pallet CD. The stop G must be placed a little higher than the stop H. The distance of the pallet

arbors from the scape-wheel centre is 3.5 inches, the arbors being placed as near the vertical line as possible, to avoid friction. The pallets are prolonged until they meet the pendulum-rod, as shown at B and D. The whole of this escapement

made such as to cause the pendulum to swing an arc of 4 detrees. A very material feature in this escapement is the fly in the usual manner. The object of this is to prevent what is called tripping, that is, the pallets A, B, C, D is the fly is large, measuring in total length 4 in. by I in. broad. It will be seen by fig. 2 that the pallets are not in the same plane, but that the scape-wheel turns between them. One stop is placed on the front of one pallet, and the other on the back of the other pallet. We will note the numbers of the teeth of the wheels and pinions, which will, we think, be found most desirable.

Wheel No. 1. 120 teeth drives pinion of 10 teeth or leaves.

"	2.	80	"	10	,,
"	3.	75	,,	10	,,
••	4.	75	,,	10	,,

The great wheel No. I had better be at least § of an inch broad on the edge, because these clocks take a heavier weight, about 25 lbs., for a regulator. These clocks have only been made with second pendulums so far as we know, and it may be convenient to state the times of revolution of the various wheels.

The scape-wheel turns once in 8 seconds.

Wheel No. 4 ,, 60 seconds.

,, 3 ,, 7½ minutes.


,, 2 ,, 1 hour.

1.2 hours.

It is perhaps hardly necessary to remark that the acting surfaces of the various parts of the escapement must be left as hard as they safely can be. It is essential that the fork-pins of the pallets B and D should be so adjusted, that as the pendulum-rod comes into contact with one it just leaves the other. For the reason of this, and for a great variety of information respecting gravity escapement, we refer our readers to Mr Denison's book, certainly one of the most scientific and valuable yet produced on its special subject.

But for the information of those to whom the book is not

accessible, we may explain the action of the escapement present one leg of the scape wheel is resting on the sto the pendulum P is swinging, as shown by the arrow,




right, and carry with pallet CD. soon as the H is lifted the way (scapewheel the wheel on by the weight will until the to is arrested stop G, and ing this mo the scapethe pallet A be lifted 1 pin in the wheel a litt wards to th and it is 1 weight pallet AB through th pin at Bont dulum - roc that point to the pallet i by the scap to that poin the penc leaves it th the impulse pendulum plied. The

CD on the other side contributes the other half in a manner. It will be observed from fig. 2 that the great No. 1, on the arbor of which is placed the barrel for the

is at the top of the frame. This arrangement was almost bidable with some of the early forms of the gravity escape, but it will be much more desirable to have the great I at the bottom of the frame, and with this form of the ement there is no difficulty about it. We recommend one before commencing the actual construction to make working drawings of the clock.

mpensating Pendulum.—The followsuggested by a practical watchmaker as od plan for a compensation pendulum. he back cock attached to the clock frame. 4 is the pendulum-rod of flat iron, the le rod riveted fast to it at 4, and the de rod riveted to the middle one at 5. the crutch that works the pendulum. a screw fast to the pendulum-rod to ly the middle rod, but loose in the le rod to allow it to expand. 7 is a fast to the middle rod to steady the de rod, but loose on outside to allow it pand, 8 is the pendulum ball of iron e outside rod. As the rod from 2 to ands downwards, the middle rod from s expands upwards, and keeps the penn-ball in the same position.



is undoubtedly the best timekeeper, the reasons for which

1. The "impulse" is given to the balance "directly" by
cape-wheel without the intervention of a lever or other
ucting mechanism. 2. The impulse is given in the most
rable manner, "across the line of centres," and will thus
a heavier balance. 3. The escapement is more completely
hed, hence the isochronism of the balance vibrations are
is much disturbed. The chronometer escapement is thus
rably suited for marine timekeepers, or box chronometers,
ey are called, and which are hung in gimbals in a square
like a mariner's compass. The dial is thus kept always
ontal, and the balance is also kept in one position, that is,
ing on the cock pivot. The movement is also kept very

The case is very different with a pocket-watch, which has to go in every position, lying up or lying down, and is also subjected to jerks and shakes by the most careful wearer in pulling it out of the pocket to see the time, to say nothing of the shakes and changes of position while it is in the pocket, and the trestment it may get from a careless wearer. A chronometer escapement, therefore, with its heavy balance, is not suited for a pocket-watch. Another objection is that the impulse is given in the one direction only, the unlocking taking place on the return vibration, which receives no impulse; hence if the watch gets a sudden shake in a contrary direction to the way the balance is vibrating, the unlocking will be prevented, and the watch will stop, and will require a good shake to start it again. •and also if it is let run down must be shook after winding to The escapement also requires great accuracy of construction, and is otherwise unsuited for rough use.

In the lever escapement the impulse is given at every vibration by the scape-wheel to the lever, and by the lever to the balance. If the escapement is made in the proportions it will not "set," hence will not be affected materially by a sudden shake, neither will it require to be shook to start it on winding it up after being run down. The ordinary lever escapement does not require such extreme accuracy of construction, and is therefore cheaper and better suited for rough use, and will keep time to within a minute a week, which is near enough.


The two-pin lever escapement is considered the best form of lever escapement, but it is thought by many to be not so good as a timekeeper.

A watch, like a steam engine, must be kept in good order. A steam engine cannot be let run long without oil, but will report its sure wants in a manner "not to be mistaken," and a labourer using a wheelbarrow must for his own comfort attend to the "screeching" of the wheel. The trains given to lever and other good watches showing seconds are 14,400, 16,200, or 80,000 vibrations or beats in an hour: each "vibration" means a "revolution" of the balance. Now, either of these sums × 24 × 365 will give the number of beats or work done in a year. The slowest—14,000—gives 126,144,000 beats in a year. A moment's attention to this fact will convince readers that, although the oil used for watches is the best we can get, and may not congeal, yet it

must be all used up in a year or eighteen months; and then if the mainspring and great wheels are powerful enough to keep the watch going, the pivots and other actional parts must and will wear out—in silence, of course, for watches do not "screech" like wheelbarrows.

Double-Roller Escapement.—The lever-watch double-roller escapement is very similar to the ordinary kind of lever escapement with the table-roller, but may be distinguished by its having an additional, though small, roller below that which holds the ruby-pin. The ruby-pin is fixed in the main-roller in the usual way, and serves the same office as that generally known; but as the guard-pin has no connection with it, the piece carrying the ruby-pin is frequently formed of the shape of an arm, the steel disc being for the most part filed away, leaving only sufficient to secure it to the balance-staff, and to hold the ruby-pin. Thus, then, this part might be called an

arm, carrying the rubypin. Underneath this is fixed another roller, rather small, having a hollow fled out similar to that which is generally noticed in the ordinary table-roller, the object of which is to allow the guardpiece to pass as the passing hollow



in the table-roller admits the passing of the upright guard-pin in the lever. Looking at the two rollers together when properly fixed, a person acquainted with the crank-roller might think that one and the same object only was achieved; but it is not so.

Without referring to the crank-roller further, let it be understood that the only purpose of the second-roller in the double-roller escapement is to serve the purpose of the safety action. This is accomplished by having a pin bent at right angles from the under side of the lever, so as to reach sufficiently far to resure a sound guard-pin depth. So that, in reality, the main-roller is a radial arm carrying the ruby-pin; then to secure a round guard-pin depth the small roller is placed below, and the bent guard-pin projects sufficiently long to ensure safety of the escapement.

The annexed diagram will assist in the description:—A, main-roller, carrying the ruby-pin; B, the lever; C, the best guard-pin; D, the second or safety roller. The balance staff, of course, passes through both.

To Restore Watch Dials.—If the dial be painted, clean the figures off with spirit of wine, or anything else that will render the dial perfectly clean; then heat it to a bright red heat, and plunge it into a strong solution of cyanide of potassium; then wash in soap and water, and dry in box-dust. Repeat if not a good colour. Indian ink ground with gumwater will do for the figures.

Bright's Perpetual Motion Electric Clocks.—Several of these clocks have been in use for four or five years without An account of them will, therefore, be interest-Presuming that our readers are acquainted with the general principle of electric clocks, the following account will be understood by referring to the engravings:—In fig. I WW are the wires leading to the two poles of the battery. wire W is attached to the bracket b, and the current passes down the suspension of the pendulum, and by a wire, shown by a dotted line, down the wooden stem of the pendulum, then round the coil of wire in the bob of the pendulum, and up the wire on the other side, also shown by a dotted line, to the touching-plate P, and through the leg L of the brake, and off by the wire W to the other pole of the battery, thus completing the circuit when the pendulum is in the position shown in fig. 1.


The bob of the pendulum is thus for the instant converted into an electro-magnet. The tube M is fixed to the clock-case, and contains permanent magnets, which of course attract the electro-magnet in the bob of the pendulum, which thus receives a little additional impulse at every alternate stroke. By the time the pendulum arrives at the other side, as in fig. 2, it has in its journey moved the break B, so that the little balance-weight T has fallen a little past the centre on the other side, and so has brought the leg L' in contact with the piece of glass G on the stem of the pendulum, and has thrown the leg L clear of the touching-plate P, and has thus broken the circuit. The pendulum them makes the return stroke by its own

weight, when contact is again made, and so on.

fitting a double break to the pendulum it receives an se at every stroke, instead of every alternate stroke, will be observed that the break consists of the two long r legs L, L^t, and the balance-weight T, all mounted on a ular piece of ivory which moves on the pivot ϕ . The

r legs L, L^t, and the balance-weight T, all mounted on a ular piece of ivory which moves on the pivot p. The n of moving this break is obviously very little; it is, in so little that

piece of zinc one piece of buried in the d afford a curof electricity ent to drive or ten or more ese clocks for ime. other feature break is that gs move in an of a different from that in the contactmove; conselyat each time ching, the conplate receives ht rub, which off any dust, nsures a perontact. e wires W and on their way poles of the




y, may communicate with and work other clock-dials.

affiliated clocks are by preference made with pendulums, see if the current misses its errand once or twice, no harm ne, as each pendulum has sufficient momentum to work wn clock for three minutes without assistance from the

the Continental system of electric clocks the affiliated s have no pendulums, but are actuated by a powerful cur-

rent from an acid battery once in a minute. Thus, if by any mischance a clock "misses a peg," it is a minute slow at once,



Under Mr Bright's system the pendulums of all clocks in connection are vibrating together, and are in fact always parallel to each other.

A set of four clocks, worked from one piece of zinc 2 ft. square and one piece of coke, have been at work at Leamington for two years; and though they were only a trial set, not over well made, they have never deviated from mean time more than a few seconds per week, and have never deviated from each other at all. The said piece of zinc and coke have been in use during the twenty years in which Mr Bright has been engaged in perfecting his invention, and on the occasion of a visit from a gentleman from Greenwich Observatory for the purpose of inspecting these clocks, the zinc and coke were dug up and found to be apparently as serviceable as ever.

An interesting fact, in connection with this part of the subject, is that a set of three clocks are at work with no other battery than one wire attached to a gas-pipe and the other to a piece of coke.

Also another pair of clocks are at work with one wire attached to a water-pipe and the other to a piece of coke. A set of five clocks may be seen at work at the Gun Cotton Office, 173 Fenchurch Street.

require very little power to keep them in motion, and have very little friction, and it may be expected that the liability to

error will be proportionally diminished; and therefore much may be hoped for them in the direction of good time-keeping, as well as uniformity, both great desiderata for railway and commercial purposes.


Several years ago Mr Gammage invented a mercurial pendulum with the rod passing entirely through the mercury. This pendulum is used for timing compensation work, so that accuracy is indispensable. The springing of a pendulum is a matter that requires much greater attention than it generally receives. Many well-made pendulums are badly sprung, and give off unsteady rates when put to first-rate movements. The following is the description of the instrument:—

A, steel rod passing through tube; B, tube to which lower cap is attached; C, glass jar to hold mercury; D, regulating

nut, working on screw cut on lower end of rod.

The jar has a hole cut through the bottom rather larger than the tube, the outer edge is carefully ground into the cap, and when the pendulum is finished it is set with cement.

Mercurial Pendulum.—Fig. I represents a pendulum, with a stirrup to support the glass jar. The rod is steel, and about 4-10ths wide by 2-10ths thick. The spring at the top is 1 in, wide, and 2 in, long. The sides of the stirrup are steel, the same size as the rod, and are joined at the top with two steel plates. There are also two short pieces of the rod steel put between the plates and close up to the rod, to form a groove for the rod to slide in, the whole being pinned and screwed up together as shown. The bottom of the stirrup is a circular plate of brass, hollowed out to fit the bottom of the jar, and has two forks to fit the steel sides, and through which the screws are put, as shown at D. There is also a brass cap fitted to the top of the jar, and with forks to fit on the steel sides; but it is not screwed to them, so that it can be lifted up to put more in, or to take the jar out of the stirrup. The glass jar C is 2 in. inside, and 21 in. outside diameter, and 71 or 8 in, long. The height of mercury has to be about 61 in.; but can only be got right by experiment; no two pendulums are alike in this respect, as a great deal depends on the kind of steel used. One great advantage of the mercurial pendulum is, that it can be very readily adjusted. The length of the pendulum from the point of suspension A to the bottom of the brass B is about 43 in. The bottom of the rod is made into a screw, and has a large milled and divided nut screwed on for regulating the clock. There is also an index screwed on



to the plate to show how much the nut is turned The screw may be 20 to the inch, and the nut divided into 50, so that if the nut is turned round one division, it will raise or lower the stirrup one-thousandth of an inch. Having tried the clock to see how much it gains or loses, the following rule is given to ascertain how much to alter the nut, to bring the clock to time at once :-- Multiply the theoretical length of the pendulum by 2, and by the number of seconds gained or lost in a day, and divide the result by the number of seconds in a day; the quotient will give the parts of an inch by which the pendulum must be lengthened or shortened. theoretical length of a seconds pendulum is 30.2 in., and the seconds in a day 86.400. Now suppose the gain of a seconds pendulum to be three minutes per day, we have 39.2 x 2 $= 784 \times 180'' = 141120 \div 86400 = \cdot 163$ parts of an inch, that is, three turns and 13 divisions of the nut by which the pendulum is to be lengthened; if the clock had been losing, of course the pendulum would require to be short-Mr Denison says, in his work on "Clockmaking," if the screw is 16 to the inch. and the rod 43 in. long, one turn of the nut will

alter the clock one minute per day; so that if the nut is divided into 60, one division will alter the clock a second a day. Cold weather is the best for adjusting compensated pendulums, as



the temperature of the clock-room can be raised by fire or gas, and lowered by letting the fire out. To adjust the mercury, let there be only 6 in. in the jar, and regulated the clock in the cold room, so that it has a losing rate of say five seconds a day; now raise the temperature, and note if the clock lose

still more, if so, more mercury is required: put in a little: now see what the rate is, and then lower the temperature, and see

if the rate is the same. If the rate is less when the temperature is lowered, put in some more mercury, and again note the rate and raise the temperature, and see if the rate is altered, thus repeating the process until the rate is the same, as near as can be, in heat and cold. The final adjustments had better be left perhaps for summer and winter, as long-continued experiments and observations are required to obtain satisfactory results. Adding to the mercury will reduce the original rate five seconds a day, so that the clock will be brought to time without altering the nut at the bottom of the rod; of course, if the nut has to be altered, the compensation will have to be adjusted again. Unless the clock is a good one, perfect in all other respects, it is not worth a compensated pendulum.

Reducing Hair-Springs.—Hair-springs may be reduced by rubbing them down on a flat oil-stone with spirits of wine instead of oil. Use the middle finger, giving a circular motion to the hand while rubbing, and let the pressure be even, but not too hard, or the spring may get injured. If the watch gains more than five minutes a day, it will be less trouble to put in another spring. The strength of the springs can be tried by weighing the balance with the spring, thus: Lay hold of the outer coil of the spring in the tweezers, and "hook" the inner coil on to the foot of the verge or cylinder, and lift the balance up, the spring will thus be pulled down into a "taper spiral; " the weak springs will, of course, have longer spirals than the strong ones. Lever staffs must have a bit of wax or pegwood stuck on to the foot pivot, and to which the spring can be hooked. The strength of spring required depends on the diameter and weight of the balance, and the number of beats or vibrations per hour, technically called the "train." The only way to tell if a spring is the proper strength is to put it on the watch and try it. The springs are sold sized in diameters and strengths, and if we could get the balances sized in diameters and weights, after a few experiments we should be able to select the proper spring at once. The results of experiments should be entered in a book for future reference thus:-


Train. 16,200	BALANCE,		Spring.	
	Weight.	Size.	Strength.	Size.

This method is proposed for plain balances only; for superior watches, with compensated balances, the isochronism of the hair-spring has to be ascertained.

Strength of Mainsprings.—The reason a verge watch gains when the strength of spring is increased is that the balance is always connected with and influenced by the mainspring or maintaining power. Thus, when a tooth of the scape-wheel has given impulse and escaped from one pallet, another tooth drops into the other, and by the "recoil" exerts the full force of the spring to shorten the vibration, and thus makes the watch go faster. The horizontal escapement is used in Geneva watches, and to this escapement the impulse is given by the oblique faces of the table acting on the edges of the cylinder as they pass out. The teeth, after giving impulse, drop on to the outside and into the inside of the cylinder alternately, and remain "dead" during the vibration. The impulse is given when the balance is near the quiescent point, and the balance is then left to finish the vibration by the combined action of the hair-spring and its own momentum, without being influenced by the maintaining power. If a stronger spring is put in, the impulse will be more intense, and would cause the balance to vibrate quicker; but the "friction" of the teeth on the inside and outside of the cylinder is also increased, and thus counteracts the extra strength of the mainspring. thus be seen that a fusee is not required to equalise the power of the mainspring, as the watch will keep the same time within moderate limits whether the spring be weak or strong. verge watches, on the contrary, a fusee is an absolute necessity. and the spring must also be "set up," so that it is as strong at the bottom as it is at the top. For this purpose watchmakers use an "adjusting rod," which is a steel rod with sliding weights upon it, and a pair of jaws to secure on to the fusee square. The rod can be bought at the tool-shops for about To adjust the mainspring the watch is put together without the third wheel, and is held in the left hand edgeways with the fusee and barrel at the top. The rod is secured to the fusee square with the weights at the bottom. The watch must now be wound up, and the weights moved along the rod until the spring will just pull the rod "over." The right hand must be kept in "front" of the rod, and thus ease it over, for if it is

let go over too sudden it will break the chain. Having set the weights so that 'their "leverage" and the strength of spring when wound up are counterpoised, the watch is let down and the spring "set up" until it will pull the rod over with the same force as it did when wound up, or as near as can be, for if the fusee is not long enough and of the right shape, it will not be possible to get it exact. In marine chronometers the shape of the fusee is altered until the force is equal in every turn, but such extreme accuracy is of course unnecessary in pocket watches. The strength of spring required depends on the size of the watch, and also whether it is in perfect repair or not. When the holes and pivots are worn, the wheels often rub each other, especially in thin movements; and if new holes are put in, it is seldom the wheels are so free or the depths (pitchings) so good as they might be, hence a stronger mainspring is required to pull the watch along. The strength of the springs depends on their breadth and thickness taken together, but should be as wide as the barrel will allow without rubbing the cover, and must not be too thick, or they will not make turns enough in the barrel. To ascertain the number

of turns required, wind the chain on the barrel and count the turns, allowing half a turn for the spare end, which is not wound on the fusee. In verge and Geneva



watches four effective turns are required; and if we allow half a turn for "setting up," the spring must make at least $4\frac{3}{4}$ turns in the barrel. To do this, the spring should occupy one-third of the barrel, the arbor one-third, and one-third space. In lever watches the barrels are smaller, and the spring should make $3\frac{1}{2}$ turns in the barrel. Most lever watches have a fusee, but do not require adjusting; in fact, the fusee is too short to be correct. Above is a sketch of a mainspring punch made in a pair of common pliers thus: Drill a hole through both jaws from C to D; tap a screw into C with the bottom end turned down for the punch; chamfer the hole D with a taper-drill to free the punchings; fit a bridge over the hole D between the

jaws, and file away the sides, so that when the spring is put through the bridge and pressed obliquely against the sides, the punch will punch the hole in the middle of the spring, as shown by the dotted lines at BA. This punch answers well, and the pliers can be used for putting in pins as usual without any inconvenience. A smaller punch in a pair of long-nosed follower pliers without the bridge is also useful. With these a hole can be punched in the inner coil of a spring for the barrel arbor without uncoiling the spring. The above punch can be also recommended on the score of cheapness, as the pliers cost only is, and the old-fashioned punch to screw in the vice costs is, 9d., and the clumsy Swiss mainspring nippers cost 6s.6d.

Geneva Cylinders.—The length of a cylinder can be obtained by the following method: Take off both jewel covers, screw on the cock, and take the distance outside the jewel holes with a pair of pinion gauges-this is the entire length, pivots and all. The diameter is obtained from the scape-wheel thus: If the foot of the cylinder is held between two teeth and against the point of one, the heel of the next must be quite free of the cylinder. With a depthing tool, the watchmaker can put the scape-wheel and cylinder into it, and see if the cylinder has the same freedom inside and outside, that is, the tooth should have equal "drop" into the inside and on to the outside of the cylinder; but the point of the tooth should not drop too far into the cylinder—just enough to be safe is all that is required. There are three dots, one on the plate close to the edge of the balance, and another on the rim of the balance to mark the place for the hair-spring stud, and when the balance is at rest, the dot on it is close to the middle one on the plate. In new watches these dots mark the extent of the balance and of impulse, that is, a tooth escapes when the dot on the balance reaches the outside dots on the plate. Before the balance is riveted too tight the cylinder should be put in and tried, and the balance turned round on the cylinder until the teeth escape at the dots; you will thus get the banking, and also the escapement, right at once.


Silver Dial Cleaning.—Take about a teaspoonful of saltpetre, and mix it with about two dessert-spoonfuls of finelypowdered charcoal—willow coal is the best. Let these be ground together with a little water on a piece of slate, with the plade of a knife, then, by the aid of a camel's-hair pencil, apread a portion of the mixture evenly over the surface of the lial, which must then be laid on a piece of charcoal, and with a blow-pipe, and the clear flame of a lamp or gas jet, it must be made just red hot, and kept so till the wet powder has ceased to fly about; it must be then thrown from the charcoal, not as it is, into a mixture of sulphuric acid and water (in the proportion of about one fluid ounce of acid to three half-pints of water); it will then have a snow-white appearance, and must be washed with a brush and soap in clean soft water, and put into fine sawdust till quite dry, or, what is better, rosewood raspings.

To Make a Chronometer Oven.—A box suitable for testing watches with compensation balances, or even the effect of high temperatures upon aneroids, may be very efficiently constructed as follows:—

Make an outer box, either of mahogany or oak, and line it with sheet-iron or block tin; let it have an aperture in front large enough to admit of lighting the gas jets, which must be placed in the apparatus to obtain the required internal heat, the pipe for which should lie at the bottom of the box bent in the form of a circle. At about four inches from the bottom a diaphragm of perforated sheet-iron should be fitted. It need not be made a fixture, but should be supported by brackets at the corners. This diaphragm will receive the principal heat from the jets. and tend to distribute it more equally. In the interior space a sheet-iron trough, with overlapping edges, should be placed so as to rest upon the rim of the outer box. Its dimensions should be such as to allow a space of two or three inches in clearance at the sides and bottom between it, the outer box, and the diaphragm. Lastly, a light lattice-work cradle, made of wood, should be placed inside the inner iron box, for the purpose of holding the chronometers, watches, or aneroids to be tested. The lid to the whole apparatus should have a panel of plate-glass through which the contents of the cradle will be visible always. The lid should fit closely at the edges, so as to retain the heated air in the cradle. Apertures must, of course, be provided at the upper portion of the outer box to permit the products of combustion to escape. These apertures should be provided with sliding shutters or covers, to admit of them being entirely or partially opened so as to regulate the draught, and thereby the temperature of the interior. The dimensions of the various parts are not given, as the size of the box must depend upon the various requirements of different individuals.

Gauge for Measuring Watch-Hands,—The following engraving and description of a gauge for measuring watch-hands is forwarded by Mr David Meek of Edinburgh:—

The gauge stands upon three pillars $\frac{1}{2}$ in. long, and consists of a disc of brass $2\frac{1}{2}$ in, in diameter. In the centre of this disc is a steel-pumping centre, while around it are engraved 21



circles. circles are to show the lengths of the hands, and are sufficiently varied for hour and minute hands of every kind, On the outside of the 21st circle are placed 40 steel studs about 3-16 of an inch long, and slightly tapering, and of different sizes, No. 1 being the smallest, and 40 the largest The object of these studs is to gauge

the size of the hour-hand sockets, and like the circles for the lengths are so varied that they embrace every size of socket from the smallest Geneva up to the largest English one.


As few watchmakers would feel inclined to purchase a handgauge, owing to its expense, the inventor has, to remove this difficulty, engraved a steel-plate with circles on it, corresponding in size and number to those upon the real gauge, and with small rings, corresponding exactly in size with the steel-studs, by which the hour sockets are sized. From this plate cards have been printed, which serve nearly as well as a real gauge, without its expense.

To ascertain the length of a hand by this gauge-card, place the socket or square exactly over the small dot in the centre, and see which circle the point reaches to. To obtain an hourhand with a particular size of socket, take the size of the hourwheel socket with a pinion-gauge or spring callipers, and then see with the callipers what ring corresponds in size. The white space within the rings denote the size of hole in the hour-hand.

As there are at least 400 different sizes of hands in general use amongst the various kinds of watches, the watchmaker cannot fail to see the value of a gauge which enables him to

obtain any size of hand he is in want of, or those sizes most suitable for his trade, besides its other advantages, such as the saving of time, surplus stock, &c.

Another arrangement which renders the gauge-card still more efficient is by placing the watch - hands




on a gauge similar to the second one. The gauge has the size of sockets as well as length of hand marked opposite each. As the spaces get empty, they can again be replaced by merely referring to the numbers marked within the empty spaces, the hands being fixed on the card so as they can be taken off and again replaced with little trouble.

Watch Oil, to Purify.—Fill a phial three parts with olive oil, and hang it up in a window for six months, where it is exposed to every change in the weather. The impurities will then be precipitated.


Horizontal Sun-Dial.—This sun-dial does not require the assistance in making it of a dialling scale—an instrument not

always to be readily obtained. On the centre E describe a circle. Through E draw the line DE, also HL, for the 12 line, at right angles to DE. Choose a point, say L, on the line HL,



below E; through L draw a line parallel to DE. Draw from L a line LB, making with the line LH an angle equal to the height of the pole, or latitude of the place. Set one leg of your compasses at E, and take the nearest distance to the line LB, which will

be found at K. Then turn your compasses, and mark the point H on the line LH; through H draw a line GH parallel



to DE. From H. with the distance HE, draw the arc HEG. Divide this arc into six equal parts: then from H draw lines through the points of division in the arc to the line DE; then from the point L draw lines for the hours through the line DE, at the points where the lines which divide the arc meet the line DE.

Another method.

—Proceed as di-

rected below, and you will obtain an accurate dial. Draw the lines AB and CD at right angles to each other, and at the

Intersection of which as a centre, describe the concentric circles, the size of the dial required. The line AB is the six o'clock line, and the line CD the meridian or twelve o'clock line. To fill up the intermediate hour lines, 7, 8, 9, 10, and 11 in the quarter CB should be measured by degrees from the meridian line; that is, from 12 to 11 the distance should be 11 degrees and 55 minutes; from 12 to 10, 24 degrees and 26 minutes; from 12 to 9, 28 degrees and 13 minutes; from 12 to 8, 53 degrees


and 44 minutes; and from 12 to 7, 71 degrees and 9 minutes. The quarter AC must be the same, and the hours 4, 5, 7, and 8, on the south side of the six o'clock line, should be diametrically opposite the same hours on the north side. The gnomon, as shown in dotted lines, should be an angle of 52 degrees, and raised directly over the meridian, or twelve o'clock line.

Inexpensive
Sun-Dial. — The
sketch shows the
upper part of a
cubical stone, hollowed out on three
sides, and set up
in a slanting position. The hollows
form half a circle.




The western side cannot be shown in the sketch, but it is the same as the east with the figures reversed. The dark angles

of the sketch throw the shadow on the hollow part. It is set in the usual manner.



Pinion and Rack -To strike out a pinion and rack proceed as follows: We presume you have your diameter of pitch-line Divide it out A. for the teeth at A. and strike them out as shown at B' and C'. in both struck from à dropline D, as shown by the dotted lines, and CI are struck from the pitch-line alone. There are many variations, ac-

cording to strength, the kind of work, and different speeds.




same as if we measure from B to E.

Diameter of Circle. -To get at the diameter of the pitchcircle, let AC and DF be the top and bottom of the teeth of a wheel, then B and E will represent the pitch-circle. will be clear that if we measure the diameter of C, the bottom of the teeth on one side, to F, the top of the teeth on the other side, it will be the

Epicycloidal Wheel.—A method of converting circular nto alternate motion, or alternate into circular, is shown in the accompanying sketch. A is a fixed internal-toothed annular

wheel: the pinion B s attached upon a rank arm CE, which las its centre of moion at E, and carries he centre C; the rod D being attached to he pinion B (which s half the size of the annular wheel) at F. the circumference of revolution of the D pinion is thereby made to describe the right line DG, coinciding with a diameter of the annular wheel. which is therefore equal to the length of the stroke of the engine to which it may be applied. This arrangement admits,




in small engines, of a very elegant application known as White's parallel motion.

Glass, to Cut without a Diamond.—This operation unites utility with amusement. Take a bit of walnut-tree, cut one end to a point, put that end into the fire till it is red hot; while the stick is burning, draw on the glass with ink the form you mean to cut; then take a file, or a bit of glass, and scratch the place you intend to begin your section; then take the wood red hot from the fire, and lay the point of it about the 1-20th part of an inch from the marked place, taking care to blow always on that point, in order to keep it red; tallow the drawing traced on the glass, leaving the same interval as before. The pieces, with slight pressure, will then divide.

Another method.—Take any vessel you want cut, and, having

heated a poker in the fire till it is almost red hot, but not quit, apply it to the part you wish the crack to begin. Having held it to the part for about a minute, remove the poker, and we the place; the glass will immediately crack. Having now begun the crack, you may lead it in any direction by merely drawing the hot poker in the direction you want. This is extremely useful in many chemical experiments, where you are in want of proper apparatus. Glass tubes may be cut with a file.

To Out Oircular Pieces of Glass.—If the amateur has a turn-table on which he mounts his objects, and a writing diamond, he has all that is required to cut the circular pieces of glass. It is only necessary to fix the square pieces of glass



on the centre of the table, and hold the diamond with the right hand while he turns the table with the left.

The following diagram will illustrate all that is required:—A is the stand for table; T, table; P, pole fixed into stand of table; C, arm to hold the diamond; K, K, K, keys to tighten the aim C and the diamond D; G, the

square piece of glass fixed to table by the two pieces of brass B, B, which each have two holes, so as to tighten the piece of glass G. The pieces of brass are fixed by two screws, as can be seen. These two pieces of brass will do to hold the slide on the table when required for mounting objects.

To Cut a Circular Hole in a Sheet of Glass.—Drill a number of small holes close together to form a circle as large as the hole is required to be, then join the holes with a small file. The drill must be quite hard, and both drill and file wetted with spirits of turpentine and oil of lavender.

Designs on Glass.—A mode of effecting this, which is a modification of the process by which copperplate engravings on paper are transferred to porcelain, has been invented in France. As fine-lined copperplate engravings would not adhere to glass, others having considerable depths are used; also, to impart to the enamels that thickness which the glass requires, stearates and oleates are added to the silicates and borosilicates, which serve to support or to fuse the coloured and colouring oxides; and, for a vehicle, a solution of resin in ether or benzine is added to the mixture. Impressions, taken mechanically on paper with this ink from engraved rollers, are transferred to the glass, which is then treated as in similar processes with porcelain, and is finally placed in the furnace. Effects of great artistic merit are thus obtained at a trifling cost.

To Transfer Engravings on Glass.—Metallic colours prepared and mixed with fat oil are applied to the stamp on the engraved brass or copper. Wipe with the hand in the manner of the printers of coloured plates; take a proof on a sheet of silver paper, which is immediately transferred on the tablet of the glass destined to be painted, being careful to turn the coloured side against the glass. It adheres to it, and so soon as the copy is quite dry, take off the superfluous paper by washing it with a sponge; there will remain only the colour transferred to the glass, which will remain fixed by passing the glass through the ovens. The basis of all the colour employed in painting on glass are oxidated metallic substances. In painting on glass it is necessary that the matter should be very transparent.

To Draw on Glass.—Grind lampblack with gum-water, and some common salt. Draw the design with a pen or hair-pencil.

To Paint Glass Gold Colour.—Take silver 1 oz., antimony ½ oz. Mix them in a crucible, then pound the mass to powder, and grind it on a copper plate; add to it yellow ochre or brickdust, calcined again, 15 oz., and grind them well together with water.

To Paint Glass Red.—Take jet 4 oz., litharge of silver 2 oz., red chalk 1 oz., powder them fine, and mix them.

Materials for Opaque Enamels.—Calcine 30 parts of lead with 33 of tin, with the usual precautions; then take of this calcined mixed oxide 50 lbs., and as much of powdered flints (prepared by being thrown into water when red hot, and then ground to powder), and 8 oz of salt of tartar; melt the mixture in a strong fire kept up for ten hours, after which reduce the mass to powder.

Micagraphy.—This is the name given to a new process of producing ornamental effects on sheets of mica. The use made of this new process has been as yet confined to the ornamentation of lamps and shop-windows, but it may be used as a cheap substitute for stained glass. The sheets of mica can be painted in any required manner, and the work preserved, it is said, by means of a varnish, or the painting may be fixed like enamel on the mica by the use of different pigments and the aid of a furnace, the pieces of painted mica being afterwards fixed, with the coloured side within, on the glass of the windows. This is the mode of proceeding:—After the mica is split into laminæ and trimmed into shape, it is glued down upon cardboard to be polished and printed. The former operation is performed by means of a soft rubber moistened with a solution of soap or sulphuric acid extremely diluted with gum-water: the printing is performed in the ordinary manner or by transfer, in order to present the design in the natural position so as to be seen by transparency. Opaqueness is produced by a previous coat of varnish or a metallic ground obtained by means of leaf or powder. The colours are laid on as in illuminated works, and the ordinary pigments may be employed, and afterwards covered with a transparent spirit varnish, or, as before stated, enamel colours may be used and the sheets passed through the fire. It is admitted, however, that in the latter case one great advantage of the process, namely, cheapness, is in a great measure sacrificed. When the ornamentation is completed, the mica is removed from the card and fixed on glass, or any other substance, by means of a solution of gum sandarac and mastic in potash and alcohol. It is said that, with ordinary care, the junction of the pieces of mica in 2 mosaic or other work is quite imperceptible, so that, in the case of a painted window, there is no other limit but the size of the glass on which the mica is fixed.

Soluble Glass.—A covering for decayed wood and other practical purposes. Fifteen parts of powdered quartz, 10 of potash, and 1 of charcoal. These are melted together, worked in cold water, and then boiled with 5 parts of water, in which they entirely dissolve. It is then applied to wood-work, or any other required substances. As it cools it gelatinizes, and dries up into a transparent colourless glass on any surface to which it has been applied. It renders wood nearly incombustible.


Woods, Strength of.—The strength of different woods to resist a compressive strain depends upon the value of the absolute force or weight which has been found by experiment to crush them, and which has a very wide range. The annexed table shows the crushing weight for all the woods which are used in the various branches of constructive art, and from these numbers and simple rules it will be easy to calculate the strength of pillars of different lengths and sizes.

Description of Timber.	Crushing Weight in cwts. per square inch.	Safe Load in cwts. per square inch.	Timber, where Grown.
Alder	61.20	15.40	England.
Ash	8o	20	•••
Birch	104	26	America.
Beach	83	21	
Box	92	23	•••
Elm	92	23	•••
Ebony	170	42.25	West Indies.
Hornbeam	65	16.52	America.
Larch	50	12 50	England.
Mahogany	73	18.25	Honduras.
Oak	89.25	22.25	England.
•••	53.20	13'40	Canada.
•••	68·75	17.20	Dantzig.
Pine (Red)	51.75	13	America.
Pine	48	12	The Baltic.
Sycamore	63.25	15.80	England.
Spruce		15.25	America.
Teak		27	Africa.
Watergum	90	22.20	East Indies.

Warped Wood.—The best method of straightening warped wood is to wet it well on the hollow side, and clamp a piece of hot wood top and bottom with hand-screws, such as cabinet-

makers use, until cold; then, if convenient, screw a piece of hard wood on the under side, and let it remain on. Another plan is to cut down the middle, shoot the edges, glue together again, and plane flat.

Dovetailing.—In plate I several ways of working are shown, but as much depends upon the parts being properly proportioned which are to fit into each other, so that the pin or socket, partly represented in fig. I, called the pin of the dovetail, and that in fig. 2, called the socket, shall be as nearly as possible of equal strength, we lay down some rules for the guidance of the workman, and here refer to the pin only in fig. I, for the socket is made to correspond to it. Let ABCD be a scantling required to be joined to another by means of a single dovetail. Now as much will depend on the form of the dovetail as the proportion it bears to the parts cut away, we will endeavour to lay down the principle on which the greatest strength is maintained. Having squared the ends of the scantling, and gauged it to the required thickness AIKLM.




divide IM into three equal parts at KL Let KL be the small end of the dovetail, and make the angles IKG and MLH equal about 75 or 80 degrees. Now make GE and FH

parallel to AN and BO. Here introduce the saw, and cut away the pieces AIKGEN, and BMLH FO; and having cut fig. 2 to correspond by making the form of the dovetail on the top of the piece ABCD, it will fit together, as shown in fig. 3.

According to the texture of the wood, we may make the bevel of the dovetail or angle IKG, fig. 1, either more or less. Hard, close-grained wood, not apt to rive or split, will admit of a greater bevel than that which is soft or subject to chip: thus the dovetail in deal must be beveled less than that in hard oak. It is a fault in many workmen that they give the dove tails too much bevel, which, instead of holding the joint firml together, weakens it. This may be observed if we compar the dovetailing of the cabinetmaker and the joiner; the former


ery little bevel, while the latter has very much. Even espect to the appearance of the work, the one looks neat, at the same time strong; while the other, appearing to it great strength, looks clumsy, and is in reality the r. Fig. 4 represents the dovetail in common use for fronts, &c., when it is wished to hide the appearance of int in front. The board ABCD is cut with the pin, and is with the socket; the pins in this sort of dovetail are in

I placed one part. Fig. 5 ents the pin of tap dovewhich when gether shows a joint, as if pieces were




I together, as shown in fig. 6; the part ABCD reprethe pin, and the part EFGH the socket dovetail, and put together only shows the line HG as a joint; and if rner AB is rounded to the joint GHT, it will appear as y mitred together. This kind of dovetail is very useful any purposes where neatness is required. Fig. 7 is a still dovetail. Instead of the square shoulder or rebate in

t is cut into re, and the piece is made respond. Anvery neat way wn in fig. 8, the joints are ormed into a mitre, and eyed together by making a



erf in a slanting direction, as shown at AB, or by cutting piece as at CD in the form of a dovetail, and fitting a a of the required form. The first method, as AB, is set workmen called keying together; the second, as CD, dovetailing; the last method is shown at fig. 9, and may med mitre dovetail grooving, the part AB being formed houlders cut to the required bevel, and a piece left for

the pin dovetail, which is inserted into the socket do made to correspond to it in the piece CD, which has




previously for into a mitre. method, though much employed may be used great advanta many cases, cularly when wish to join pieces togethelengthway of grain.

Annexed are other illustra of dovetailing

ficiently shown in the engravings as to need no fi

Wood Staining.—To Stain Wood a Mahogany (
before Polishing.—Make a strong or weak solution of log
according to shade required, to which add a few dro



hydrochloric
then stain the
ticle. When
give a coat of
seed oil, and
ready for polic
If boiled or s
drying oil is u
much darker
is obtained;
the latter it be
almost black,
Another m

- Boil log

ing a little soda or potash to bring out the colour. Appl a brush, and use French polish when dry.


Rosewood Stain,-A stronger decoction of logwood m

used, and the process must be repeated several times. To produce the fibres, put some iron-filings or turnings in strong vinegar; let it stand for some years, and then brush the wood

over with the solution. When dry, polish with beeswax and turpentine.

Another method.

-Dissolve half a pound of potash in 2 gallons of water, and add to it half a pound of red sander-wood. When all the colour is extracted from the wood, add 5 pounds of gum shellac, and dissolve it over a



quick fire. This stain should be used on a ground previously with logwood stain.

Another method.—If with a brush dipped in the brightening liquid you draw veins on wood prepared with the black stain, a very good effect is produced.

Red Stain for Bedsteads and Common Chairs.—Lay on one or two coats of common archil, and when dry brush over with a hot solution of pearl-ash in water.

To improve the Colour of Stains,—With 2 oz. of nitric acid diluted with 4 oz. of water, mix a teaspoonful of muriatic acid and $\frac{1}{2}$ oz. of grain tin. Keep in a bottle well corked, and use after it has stood two days.

To Stain Beech a Mahogany Colour.—In a pint of rectified spirits of wine put an ounce of dragon's blood. Shake the bottle which contains it frequently until the dragon's blood is dissolved. When this is the case, the stain is ready for use.

Black Stain for immediate use.—Take 1 lb. of logwood chips and boil in 4 quarts of water, and lay it on the work while hot. Make a similar decoction of logwood to the last, and add to it 1 oz. copperas and 2 oz. verdigris; strain and put into it 1 lb. of rusty steel filings, and with this go over the work a second time.

Protection of Wood Carvings.—Worm-eaten wood may be saved from further ravages by fumigating it with benzine, whereby the worm is destroyed. Another way is to saturate the wood with a strong solution of corrosive sublimate—a process which may be advantageously employed to protect carvings in wood. But as sublimate destroys its colour, it will be necessary to restore the latter by ammonia, and then by a very dilute solution of hydrochloric acid. The holes made by the worm may then be injected with gum and gelatine, and a varnish of resin dissolved in spirits of wine should afterwards be applied to the surface.

Shooting Boards for Joiners.—This plan brings the two edges of boards true for glueing together, and possesses evident advantages over those in general use. a, bed of some hard wood; bb, table supported by blocks ccc; d, a block carefully

5 d at the thi

planed and fitted at right angles to the table. With this board the whole of the plane-iron

is brought into use, instead of one part only, as in the board usually adopted. Of course the plane-iron would have to be perfectly straight on its edge, otherwise it would bring the edges of the board false.

Waterproof Mortar.—The admixture of coal-dust with mortar renders it impervious to water. This waterproof mortar may be made by mixing two parts of fine cement with one part coal-dust reduced to a very fine powder, and one and a half parts slacked lime; then adding water, so as to produce the desired consistence. Mortar thus made possesses great solidity; but the darkness of its colour is often an obstacle to its use.

Damp on Walls.—A complete cure from damp exuding from a brick wall upon which no plaster, much less paper, would adhere, on account of its having been several times saturated with sea-water, has been effected by using "Italian plaster." The cost is but little more than that of Portland cement, and may be papered upon forty-eight hours after being used, without any risk of damp or discolouration.

ning Paint.—Dissolve 2 oz. of soda in a quart of hot which will make a ready and useful solution for cleaning nted work preparatory to repainting. The mixture in ove proportions should be used when warm, and the

ork be afls washed ater to reneremains soda.

-Spring. following gested as ole spring door. It s of half of c-and-eye fixed in ices on the ile, and in lace, near p, on the or archi-A piece e, 3 of an diameter, from the ye straight h the cenne, and is ent out, so pass into per eye on architrave. action of



g the door strains the wire, and the spring acts by its ng to its former position.

ble, Imitating.—How to make a stucco mantelpiece ke black marble. Make a mould of wood and line it with lass; and mix stucco with size, to keep it from setting too fast. The colour ought to be put in among the stucco before mixing; then spread a thin coat on the glass, rub it well to take out the air-bubbles, and fill the mould up with clean stucco before the first sets. After it has set, dip the mould in water, and it will come out easy. So soon as it is dry, dip it into size mixed with black, and then cover with black varnish. Do not touch it with the fingers after it has come out of the mould. Use mineral colours, and be certain that there is no oil in them. Any other kind of marble may, by a little ingenuity, be imitated when the first coat is laid on. A better kind of mould can be made by taking an original and covering it with clean glass, and then pouring wax, such as plasterers use, over the glass.

Architectural Ornaments in Relief.—For making architectural ornaments in relief, a moulding composition is formed of chalk, glue, and paper paste. Even statues have been made with it, the paper aiding the cohesion of the mass.


To Take out Iron Stains.—Mix in a bottle equal quantities of fresh spirit of vitriol and lemon juice, wet the spots, and in a few minutes rub them off with a piece of soft linen.

Anti-Pestilential Vinegar.—Take acetic acid (5°) 900 grammes, camphor in powder 5 grammes, crystallised phenic acid 100 grammes. This combination of three antiputrescents is said to be extremely useful, and for hygienic purposes far superior to "vinegar of the four thieves," as tollet vinegar was once called. It has been used on board ship to keep cabins sweet.

Preparation of Walls in Tempera.—When it is wished to colour a wall, not retaining the plaster or stone as a ground, the following order must be observed. First mend any broken parts with a mixture of putty and plaster-of-Paris neatly put on with a spatula or palette knife, and smoothed down; then brush over the walls with a size, composed of 1 lb. of good glue dissolved in 1 gallon of hot water, thickened with some red lead, or else with Young's patent size. Give this sufficient time to dry. Now proceed to make your ground colour, which we will suppose to be what is usually called vellum tint, as follows:— In a large double-sized paint-pot put 3 lbs. of

gilder's whiting, cover it with water, and let it be until it be perfectly broken up and saturated, and the effervescence has subsided. Then pour off the water, and stir with a thick stick until the mass has attained the consistency of dough. Melt Young's patent size not diluted, and pour upon the whiting, stirring well up, and then straining while warm to free from

impurities. Let this stand several days in a cool place until it is formed into a weak trembling jelly, so as to be worked with ease with a stiff brush. Before the size is added it may be stained to any tint which is desired by the addition of the proper colour ground in water. should be observed that all colours in distemper dry lighter than when first applied, so that the only way to secure the requisite tint is to make experiments upon a piece of paper or card until the proper tint is reached. The colour must then be applied to the walls in its cold and jellied state. For this purpose, use a large hog's-hair brush, and work with decision and freedom, taking care not to retouch any portion of the work, but to cover the ground well as you proceed. The wall should be divided by your eye into squares, advancing from one to another in regular succession, and, of course, beginning from above. Unless for some special purpose, your ground




should never be pure white, but be stained, however little, with black, blue, ochre, or chrome yellow, to take off the raw appearance; where a coloured ground is needed, proceed in the same way as above described, commencing with a larger or smaller quantity of whiting, and tempering it in the colour to the degree required.

Chimney Cowls.—The above simple arrangement of cowls,

constructed on the principle of the air blowing through, draws up the smoke. They have been largely tried, and have perfectly succeeded.

Cowl for Smoky Chimneys.— Let O be a tube of any length, 9 in. diameter; S also is a tube, and base to O, being 14×9 in.; N is a tube $16 \times 10\frac{1}{2}$ in., upon which is fixed another tube M, at XE; M is a tube through which air passes




to carry off the smoke. In M ab is 20 in., cd is 17 in., ac is 10 in. diameter, at is 3 in., ed is 4 in. V is a funnel-shaped piece of iron, which is fixed at AC, being from the line ACto the opening K, 4 in., of which K, being a tube, is 2 in, long by 11 in. diameter, which passes over the mouth of N, 11 in.; BD is the outlet; O is a rod of iron fixed at the top of O, upon which turns M at the point T. Z is a piece of sheet-iron fixed on M, from T to B, which turns M against the wind, bringing the cone V open to it, by which

the wind, having to pass through it, carries off the smoke at BD.

Stains on Marble, to Remove.—Various plans are adopted for taking iron and ink stains from marble—such as chimneypieces and wash-hand stands, &c., but the following will be found most practical:—Mix unslacked lime in very fine powder with strong soap ley; make it thick, and leave on the marble for more than a week. Then wash off with a thick lather of soft soap, boiled in soft water. Clear off the soap, and brush with a little lime powder, and a fine polish will be the result.

Closet Construction.—Dry earth is no doubt a great deodoriser, and the principle has been adopted with considerable success. It answers under two conditions, that the earth should be thrown down perfectly dry, and kept dry; but is it so? How many receptacles are commonly emptied into the waste, or, if not, down some open sink? We may suppose that in a town there will be a greater adaptability of water than in the country, whilst in the latter there will probably be attached to the dwelling a strip of garden



ground into which the manure may be deposited, as in the earth closets. The annexed sketch will illustrate the principle:—a, closet pan; b, wall of house; c, a wooden waterspout for carrying down any spare water from the roof, or for letting gases pass away into the open air; c, water-tight tank with flag top, calculated to require emptying of solid contents once in three years; d, an 18-in, drain, running into a second tank e, which holds the liquid manure at the bottom of the garden; f, a smaller waste-pipe of some length connected with a drain. The pan is a simply-made affair of sheet zinc painted, with a rim turned over at the top, and a bottom on hinge to balance about a quart of water or so. Over the rim comes a false seat, and all is air-tight. The rim is embedded


in putty. After use a small quantity of water is poured with a can; but where water from the main can b



cured, there be no diffic adjusting a mon pipe side of the with an otap inserted length of pi in reach, this princip

is not the slightest unpleasantness.

Ventilation.—A simple way of ventilating a room to a chimney in it is the following:—Make an opening chimney over the fireplace, and as near the ceiling as I about 9 in, by $2\frac{1}{2}$ in, then procure a piece of perforation, by $3\frac{1}{6}$ in, and a piece of oiled silk or calico 9.



in.; fasten or calico edge of the sewing it the holes; then hang! the zinc a hinge, but not reach t or bottom half an inc

fix the zinc over the hole, with the flap inside, not in the and with the edge that is secured uppermost. A strip-bordering may be posted on the wall, and partly on the to hold it. The up-draft will blow the silk back, but the draft of the chimney will close it.

Cheap and Effective Filter.—Procure one small, broad tree-pot, and two very large ones, both of a size large deep water-pot or tub, and a supply-cask or tu get five or six feet of gutta-percha piping, and two sma of the best and finest sponge, and close up the hole

large tree-pots tightly with the sponges. Place one of the treepots within the other, so that the sponges do not touch each other; this being done, and all in readiness prepared, the sand, pounded glass, or charcoal being thoroughly washed clean from dirt or dust, first put the small tree-pot into the water-pot (it being previously raised upon some bricks), and fill up the space between the sides of each, to the tree-pot brim, with sand, pounded glass, or charcoal broken small. Now put the two large tree-pots together into the water-pot also, to rest upon the small tree-pot, and again fill up with sand between the outer tree-pot and the water-pot; then pour water on the sand all round, so that it may find its bed or level, and repeat the sand and water until the level of the sand be near the top of the water-pot. You may now put one end of the tube or pipe through a hole made in the upper part of the

supply-cask, so as to nearly reach the bottom; then draw up the water into the pipe with the mouth, keeping the end depressed, and the syphon will be in action, placing the other end in the water-pot. Your filter being now made,



you will soon obtain clear water from the upper tree-pot, which you can lead out or draw off, which is preferable, with another

short syphon, into a receiver.

Having once had need of a filter we adopted a similar plan, with charcoal between the two large tree-pots, with a piece of flannel surrounding the sides and bottom of the upper tree-pot. minus the small pot and sand; but in time the flannel is apt to rot and become unwholesome.

C, the supply-cask; SS, the supply-syphon; Z, the stool of elevation for syphon action; A, the water-pot; UV, the large tree-pots; FW, filtered water; W, water; SS, sand; R, receiver of filtered water; DS, discharge syphon; LLL, lids and sponges; KK, bricks; N, notch made in tree-pot for pipe; U, upper tree-pot; V, the lower one. As the filtered water has

to ascend, the action of this filter is preferable to those wherein it has to descend.


Hat and Cloak Peg Frames.—Here is a portable hat and cloak peg frame, made either of mahogany or deal, framed together, about 3 feet long by 6 in. wide; the framing is 1 in. wide, by $\frac{3}{2}$ in. thick; the pegs or hooks, hinged between on wire



pins, are of the same thickness as framing; the letters A show the rails of framing, and it is hung with two rings

as shown. It is suitable for either halls, backs of doors, or tents, and can be removed at pleasure. It can be made of any length, and the hooks fold flat as shown.

Alarums.—From among the many ingenious contrivances




known as "Early Risers' Friends," "Mechanics' Friends," &c., we select the above :—

1. A is the kitchen, B the bedroom, and C the clock. It

does not matter if your clock has only one weight; when the clock is in action, watch it for one hour; notice how much the weight lowers in that time; then divide it into a scale of halves and quarters; after which, mark on the wall the hours, as shown at D. When going to bed, consider how many hours you wish to sleep. Example: Supposing it to be half-past ten, and you wish to rise at five o'clock, raise the weight E to half-past six. At five o'clock in the morning the weight E will press on lever F, down drops weight G, pulling string HHH, and down drops a heavy parcel on the legs of the sleeper. At the same time that weight I is lowering, round goes the cogwheel K, pressing against the tin-spring L, which makes a great noise. Where there may chance to be a cupboard, as at MM, the string can go into it out of sight. NN is a short piece of elastic placed to keep the string on pulleys, when the weight G is suspended at 1, 2, 3, 4, 5, 6, 7, 8. Use round nails for wires to work on, No. 9 screw to slack or press the tin on wheel, OO nails to secure alarum to wall, P balanceweight for I, and to keep string on pulley Q. In addition to

the above, turn the light nearly out of the lamp at night, so that weight (I) can put full light on in the morning by lowering lever T.


2. A, lamp; B, spring holding socket for match; C, centre tumbler, connecting the spring to the match holder; D, lever; E, pinion holding the spring, having a rough surface for the purpose of ig-



niting the match; F, whistle; G, coffee can.

3. The following is an apparatus attached to an ordinary alarum clock. It has been practically tried, and found satisfactory. It is enclosed in a frame or case, and suspended

against a wall, just below the ceiling, so as to give the weight plenty of room to run down. AB, arbor, bearing a fly-wheel C, in which are inserted, in a radial direction, two hammers DE; these impinge on the inner edge of a gong F, suspended



by a rod G. Round the arbor is rolled the cord H, which is acted upon by the weight I. This weight is suspended in the bight of a cord N, and is released on the running down of the alarum-weight J, as will be seen by the engraving.



Water-Tight Cisterns.

—Construct your cistern in the usual mode—viz., the sides nailed to the ends. It can scarcely be made tight by any paint or cement where the grain of the wood

of end and side, or end and bottom, of the tank have a differ-

tion, and are fixed together with nails. The pieces so e constantly sliding one on the other, the one swelling racting, and the other not—in fact, they cannot agree, wing arrangement will obviate this:—Secure sides to which should both have the grain of wood in direction row. Fit the end (the edges of which should be like a cask-head) into groove G, and nail the bottom only to the lower edge of the end-pieces, the end-piece the grain up and down. The ends of sides to be drawn by two or more screw bolts and nuts SS. Thus when the sides swell, they have liberty by sliding on of ends to expand or contract. If a tank thus made some pitch be melted into the seams with a heated are, or any convenient piece of iron, the wood being oughly dry.


wed Way of Storing Rain-Water.—When casks are eatch rain-water, holes are often cut in the higher ones

water fall lower. A ly would be a piece of e, bend it shape of er U, and ith water. de the air. end into o, the one I, the other They will ome to a n this way r of vessels set all upon el, without or boring



en Engine.—BCEFH is a force-pump together with essel; BB is a barrel about 2 in. diameter by 10 in. de of copper or brass (a piece of telescope tube would

answer very well) screwed into the stand (iron) CDEF an air-vessel; I and J are the suction and delivery valvis the delivery-pipe, to which should be attached a pindiarubber hose about $\frac{5}{8}$ ths of an inch in diameter, at t of which is a jet or nose. The piston is formed of two



cups, the top verted, which held in their position by ty lars to the rod &c., is pre from enterin pump by mea piece of iron represented b beneath the no As soon as the is raised, the enters the through the v which closes the lever is sed. The wa then forced in air - vessel t the valve I, prevents its The air in H being compres soon as the p removed, force water very through the de pipe, &c. the pail AAA be required,


of stand must be larger, a piece of hose being attached and a stuffing-box placed at the top of the pump, to prevescape of any water that might pass the plunger.

Double-Action Pump for Garden Engine.-By the

below, it will be seen that the water is kept constantly in a stream both with the ascent and descent of the piston. The sketch is so simple as to require

no further explanation.

Transfer Paper.—Transfer paper may be prepared thus:—Make a mucilage with ½ oz. of gum tragacanth; strain; add 1 oz. of glue and ½ oz. of gamboge. Mix French chalk 4 oz., old Paris plaster ½ oz., starch 1 oz.; run them through a sieve, grind with the mixed mucilage, add water to reduce to the consistence of oil, and apply it with a brush to thinsized paper. The drawing made on this prepared side of the paper is wetted at the back and



placed on the stone, which is warmed to 125° Fahr.; the whole is then strongly pressed in the lithographic press, and the stone receives the impression, which may be printed from as usual, When two impressions are required, a red composition is made of wax 2 parts, soap I part, and vermillion to colour, all melted in a saucepan, and ground with water to the consistence of This is spread thinly on the second stone, an impression from the first stone is next applied, and the second drawing is thus made to correspond with the first exactly. If in printing the drawing becomes smutty, mix equal parts of water, olive oil, and oil of turpentine; shake till they froth, wet the stone, throw this froth on it, and rub it with a soft sponge. The printing ink will be dissolved, and the drawing will almost disappear; but, on rolling it, it reappears as clear as at first, When the stone is laid by for future use, a preserving ink is applied, to prevent the surface printing ink becoming too hard. Thick varnish of linseed oil 2 parts, tallow 4 parts, wax and Venice turpentine, of each I part; melt; add by degrees lampblack 4 parts, mix thoroughly, and preserve in a tin case. This must be rolled on the stone each time before laying it aside for future use. When the whole of the impressions are completed, and the stones required for other drawings, two of the s are laid face to face, and ground with sand and water unt surfaces are clear. They are, finally, more or less pol with pumicestone, according to the required fineness, and then prepared to receive other drawings.

Tracing-Paper.—Having prepared a mixture of equal of turpentine and gum-mastic, spread out a number of sof crown tissue-paper, one over the other; then brush the sheet over with the above mixture, and hang it up to Proceed with the rest in same manner. As the under sabsorb some of the varnish laid on those above them, les be used than if each was brushed separately. This varnitracing-paper leaves the paper quite light and transparent may readily be written on, and drawings traced with a permanently visible. It is used by learners to draw out The paper is placed on the drawing, which is clearly seer an outline is made, taking care to hold the tracing-paper stan this way elaborate drawings are easily copied.

Oiling Tissue-Paper.—Lay it on a flat surface, an linseed oil over it with a piece of cotton wool or a brush hang it up to dry.

Stencil-Plates.—For cutting stencil-plates use a m of 3 parts nitric acid and 1 part water. After heatin plate slightly, prepare the ground for etching by rubbing i with common heel-ball. The back of the plate should be so that the cutting may be clean.

Drawing-Board, to Black.—Take ½ lb. of lampblack put it on a fire-shovel over a clear fire until it is red hot take it off, and, when cool, pound it very fine, and mix i a pint of turpentine. This should be laid on with a size-If the board is new, before using the above it will be nec to give it one or two coats of lampblack mixed with boile

Map Colouring. — Ordinary water-colour paints mused, preferring the moist variety, and those not opaque as gamboge, carmine, indigo, or Prussian blue. With all the colours required may be formed. Wet the sheet clean water first, and as soon as the moisture has disapp from the surface, apply a thin wash of the colour with a ably full brush, passing over the surface quickly. Com

at the top and at his left hand, coming down to the bottom right hand. Use blotting-paper to dry any superabundance of colour.

. Pencil Drawings, to Preserve.—Apply a thin wash of isinglass, which will prevent rubbing off either of black lead, or of hard black chalk.

Pencil Writing, Indelible.—Some years ago the Society of Arts offered a premium for an indelible pencil to write on common paper, but nothing satisfactory was produced. Any pencil writing or drawing may, however, be rendered as indelible as if performed with ink by the following simple process:—Lay the writing or drawing in a shallow dish, and pour skimmed milk upon it. Any spots not wet at first may have the milk placed over them lightly with a feather. When the paper is all wet over with the milk, take it up and let the milk drain off, and whip off with the feather the drops which collect on the lower edge. Dry carefully, and it will be found to be so perfectly indelible as not to be removed even with indiarubber.

Picture - Cleaning.—The most simple application for oil pictures is water and plenty of it. If the coats of varnish are very thick the scraper may remove a good deal. wine and turpentine may be applied; but the scraper, spirits of wine and turpentine, will attack the paint as well as varnish, and the art of picture-cleaning is to stop action before you arrive at the paint. Water will stop further action of the spirits. Experimentalize only on a corner or an unimportant part of a picture. Many good and valuable pictures have been rendered worthless by the process of what is usually called cleaning, particularly under the infliction of spirits of wine. turpentine, home-made varnish, &c. If the picture be an old one, it is usual to begin by rubbing off the old varnish, which is done with the fingers, rubbing gently and evenly in small circles over the whole picture, beginning with a little dust on the fingers, after which the light powder—the remains of the gum of the old varnish—will soon appear. Care must be taken not to touch the colour of the picture. Then wash with clear water, and when quite dry, varnish. It is preferable in all respects to buy varnish at the artist's colour-shops. If there is not any old varnish on the old picture, first wash the picture

with warm rain-water, using a soft sponge, and then carefully with a lukewarm solution of a quarter pound of soft soap in a quart of rain-water.

Varnishes for Prints and Water-Colour Drawings.—The printing must be thoroughly dry. Size made by boiling an ounce of best isinglass in a pint of water should then be applied quickly to the surface. This may be done in two ways, the latter being preferable. First brush the size over the surface of the picture rapidly with a broad camel's-hair brush; second, having poured the solution into a flat dish, pass the drawing quickly through the fluid, so that the whole of both surfaces may be thoroughly wetted. Lay the drawing carefully upon a flat board to dry; any colourless varnish may then be applied. If isinglass cannot be procured, clear gum-water will answer almost as well.

A good and cheap Varnish for general use, and one which dries in a very short time, may be made of the best wood naphtha I pint, gum shellac 2 oz., gum sandarac 2 oz.; pound the ingredients in a mortar, and pour on the naphtha, shaking it up often. When dissolved, filter through fine muslin, and the varnish will then be fit for use. If too thick, add more

naphtha.

Another Varnish, fitted for prints or drawings, is the following:—Give the article one or two coats of gum arabic, dissolved in water, about 2 oz. to a pint; a coat of crystal varnish will complete the operation. The crystal varnish may be purchased at any of the oil and colour shops. Turpentine varnish is often used in lieu of crystal, and is much cheaper. Fine parchment size, or isinglass, will be found preferable to gumwater. The best varnish is clear pale copal, dissolved in rectified spirit, which is easily done by heat. A small quantity of shellac will harden the varnish, but it communicates a brownish tinge. A varnish composed of shellac alone, dissolved in spirit, is so hard, that if a coat of it be laid upon a card, it may be written upon with a pen and ink, and rubbed out again with a sponge, without leaving any perceptible trace.

Another Varnish.—Balsam of copaiba 4 parts, powdered copal 1 part. Mix, and keep it in a close vessel at a heat of 150° Fahr., until the gum is dissolved; then thin it with tur-

pentine.

Size for Prints or Drawings before Colouring.—Best pale

nd white soap, of each 2 oz., hot water 30 oz.; dissolve, dd powdered alum 1 oz.

nters' Cream.—Painters who have long intervals between periods of labour are accustomed to cover the portions d with a preparation which preserves the freshness of the s, and which can be removed when they resume their This is the preparation:—Take of clear nut oil 3 oz.; in tears, pulverized, ½ oz.; sal saturni, in powder, acef lead, ¾ oz. Dissolve the mastic in oil over a steady nd pour the mixture into a marble mortar over the ed salt of lead; stir it with a wooden pestle, and add in small quantities till the matter assumes the appearand consistence of cream, and refuses to admit more

delling.—Rice flour, mixed thick with a little cold water, armed over a fire, may be moulded into busts, figures, iefs, ornaments, &c., very readily. When dry and hard, thus formed may be polished, and will be found very e.

sum — Plaster of Paris. — This substance possesses peculiar properties. It consists of sulphuric acid, lime, ater; its composition, or rather the proportion of its nent parts, being similar to that of alabaster. Its abundant the tertiary basins around Paris has given it the name ter of Paris. It is found in Nova Scotia in profusion in wer carboniferous rocks. It is produced by the decomn of iron pyrites and limestone in juxtaposition. It is I wherever sulphuric acid is generated, and comes in t with carbonate of lime. Crystallized gypsum is called e, and the ancient Romans are said to have used it as It is often coloured by oxide of iron to grey, brown, ellow, and even black. It is used extensively for making

ellow, and even black. It is used extensively for making casts, and for stucco. It is prepared for these purposes cining, which is simply heating it in kilns or kettles until ater is expelled. It is then a fine powder, like wheat and to be used, must have the water which it previously turned to it. To preserve it from contracting the moisthe atmosphere, it should be kept as nearly air tight as e. Much of the plaster or gypsum sold in the market

is deteriorated by careless handling and packing. When mixed with water, it "sets" quickly, and no time should be lost be tween the mixture of the gypsum and the taking of the cast. Of late years it has been a favourite substance with dentist in taking casts of mouths to which teeth were to be fitted. We know of no way by which this substance, being once used, can be brought to its original state. It is used to some extent is glazing porcelain; but it is more largely used as a fertilizer of soils than for any other purpose. Containing a large proportion of sulphate of lime, it is extensively used as a manure. It is excellent for grass of all kinds, furnishing just the nutriment needed.

Pictile Ivory.—This ivory is prepared by intimately mixing and passing through a fine sieve superfine plaster of Paris and Italian yellow ochres—half an ounce of the latter to every pound of the former, and then forming a plaster cast of these inguitients in the usual way. This cast is first dried in the open air, and then carefully in an oven; after which it is soaked for 15 minutes in a mixture consisting of equal parts white way, spermacetti, and stearine, heated a little above the melting-point. When removed from this, the cast is allowed to drain, and before it is cold any excess of the wax, &c., which may remain in the crevices, is brushed off by means of a painter's sash-tool; and as soon as it is quite cold, it is polished with a tuft of cotton wool.

Plastic Moulding (Parkes' Patent).—To make about 1 h of this compo, melt together 1 lb. each of wax and deer's flat; then dissolve 19 or 20 grains of phosphorus in 300 grains of bisulphide of carbon. Keep the wax mixture barely melted, and add the phosphorus solution slowly to it. Briskly stir the fat while pouring it in at the bottom of the melted mixture by means of a vessel with a long spout to prevent it inflaming. It is highly dangerous to spill the phosphorus compo where 2 can come in contact with wood, paper, rags, &c., as after 2 lapse of even many hours they will often burst into flame.

Vegetables, Insects, Small Birds, Frogs, Fish, &c., Online Plaster Moulds.—Provide a trough of boards, nailed to gether so as not to let the water run through the joints; suppend in the trough, by thread or Holland twine, in several

the vegetable, plant, insect, &c., which you would cast, being performed, mix 4 parts of plaster of Paris, and of fine brick-dust with common water, to the consist-f cream, and with this cover the thing intended to be bserving not to distort it by any means from its natural n. When you have filled your trough, let it harden by it near the fire by degrees till you can make it red hot; t it cool, and with a pair of bellows blow and shake as of the ashes out of the mould as you can. You must a small quantity of quicksilver into the mould, and it, in order to loosen every part of the ashes therein; make a passage through where the strings were tied, in o let the air out when you pour in your metal.

al for the above Work.—Take of grain tin 6 oz., bismuth and lead 3 oz. Melt them together in an iron ladle, and ay cast in the above mould to your satisfaction. You ombine the above ingredients in such proportions as to se a metal that will melt in boiling water, thus—Sir Newton's fusible metal is composed of 8 parts bismuth, a lead, and 3 parts tin; this alloy melts at 212°. Rose's still more fusible; it is 2 parts bismuth, I part lead, tin, and melts at 201°. Dr Dalton's fusible alloy—3 tin, 5 parts lead, 10½ parts bismuth—melts at 197°. Idition of a little mercury makes it more fusible, and fits a used as a coating to the insides of glass globes.

nishing Plaster Casts.—Plaster casts can be varnished ixture of soap and white wax in boiling water. A \(\frac{1}{4} \) oz. p is dissolved in a pint of water, and an equal quantity afterwards incorporated. The cast is dipped in this and, after drying a week, is polished by rubbing with then, producing a polish like marble. If to be exposed to eather, saturate the casts with linseed oil, mixed with r resin may be combined. In casting the plaster, use water and gum arabic.

Print on Canvas.—Prepare the canvas by washing it it is evenly wet. Wash with water to remove the soda, en lay a piece of albumen paper, of the size you wish to the print, face down upon it, and rub it well to secure it all over. Lift up the paper and remove the bubbles,

if there should be any, with a brush. After drying, coagulate the albumen by pouring on some strong alcohol; dry again, silver with a 40-grain silver solution, slightly acid; print, and fix in hypo.

Cyanide of Silver.—Break up an old silver coin, say 6d.; put it into a porcelain cup, and cover it with nitric acid undiluted; set it on a fire-shovel over a slow fire, or make it warm by any convenient means, and the silver will soon dissolve; add acid occasionally, if necessary; when dissolved, fill the cup nearly full with clean rain-water, and let it settle for a few Pour off the clear liquor into a pint glass tumbler or jug, add a tablespoonful of clean common salt, chloride of silver Pour off the clear liquor (which may be will be the result. thrown away), add water to the precipitate, and agitate it well with a glass rod, but by no means with a metal one; pour away the liquor as before; wash again; by these means the salt will be washed out. Now dissolve 1 oz. of cyanide potassium in a half gill of rain-water warm; when dissolved and the liquor cold, add it gradually to the dissolved silver, and a good plating liquid, consisting of the double cyanides of silver and potassium, will be the result. To use the solution, clean the article well, immerse in the solution in contact with a small piece of clean zinc. With nitrate of silver he can proceed thus: Dissolve the crystals in water, add to the solution gradually the solution of potassium, till a precipitate has fallen, then add more cyanide until that precipitate is redissolved a much cleaner way than the others, and something purer too, but not so cheap.

Instantaneous Photography.—Herr Metzger is of opinion that success in instantaneous photographs depends more upon the excellence of the apparatus and chemicals employed, and rapidity of manipulation, than on the practice of any particular theory or process. Of the many descriptions of collodion, that prepared according to Dr Liesegang's formula appears to him best suited for instantaneous photography; for although (he says), I have been successful in obtaining good results with mixed collodions, I prefer to use a material freshly prepared, together with a neutral 10 per cent, silver bath. For developing I employ the following formula, adding as much alcohol as

y be necessary to make the solution flow evenly over the

Water, .	(6)	-	 40	100 grains.
Sulphate of iron,	*	(M)		5 ,,
Acetic acid,	-	S. a.d.		3 "

negatives are intensified with pyrogallic acid, which is used y carefully, in order that the harmony of the pictures may be destroyed. The plate should be exposed as soon as sible after its exit from the silver bath, and developed nediately after exposure; the object to be photographed at be lighted as strongly as possible; and if direct sunlight not present, all false lights and reflections are to be carefully ided. March and October are the most favourable months instantaneous photography.

instantaneous Pictures by Artificial Light.—Mr Thomas ife has patented a process to obtain an instantaneous flash artificial light for the production of small portraits. The cification is as follows: - These improvements relate to the struction of an apparatus for igniting and burning any der or other composition either in a solid or liquid state, the ne or flash of which, being sufficiently actinic, is applied for production of photographic pictures. For this purpose the apparatus consists of a platform of metal or other incomtible substance perforated with one or more touch-holes d, attached to, or supported by, a spring or springs in such nanner as to permit of its being easily vibrated or thrown a tremulous motion by the touch of the finger or other liance. Connected with or attached to the platform is a abolic or other reflector pierced with a groove, through ch communication is made with one end of the platform, which it may be touched or struck, so that by means of the esaid springs it may suddenly vibrate. The deflagrating der or other explosive actinic substance, being placed or wn upon the perforated platform, is suddenly brought into tact with a light from an ordinary spirit-lamp, or such like stance, preferably placed underneath it; at the same instant platform, being thrown into vibration, communicates this tion to the particles of the powder or other substance to be ited, the result of which action is that every particle explodes

or is ignited simultaneously, and producing a flash of light which, acting upon a sensitized plate in an ordinary camera, produces the picture of any object placed before it. picture of a near object is required, the powder may be placed over a touch-hole; if the picture of a distant object is to be taken, then the powder may be distributed over the platform and over several touch-holes, to all of which the light may be Having now described the nature of my invention, and the principles by which it is carried out in practice. I wish it understood that what I claim and desire secured to me by. the before in part recited letters patent is, the use of a vibrating platform or table with or without a reflecting mirror, for the purpose of producing, by means of vibration among its particles, an instantaneous combustion of any actinic powder or other deflagrating or easily flammable substance, when used for the purpose of obtaining photographic pictures substantially as herewithin described and set forth.

Photographometer.—This apparatus is intended to record the angular position of objects situated around a given point. It is automative, and very simple. The record is made by photography, and the camera used, with the exception of certain additions, does not differ much from the ordinary kind. The objective, which is that usually employed by photographers, is mounted vertically on a circular platform capable of rotating, by means of clockwork, in a horizontal plane, The picture is formed, not in a vertical plane, as in ordinary cases, but in a horizontal; and therefore the rays, passing in through the objective, are deflected 90° by means of a reflecting prism, so as to fall on the sensitive surface, which is collodionized glass, and is placed in such a way that its centre corresponds with the point at which the centre point of the diaphragm would be To prevent a number of confused images, superrepresented. imposed on each other, being formed during the rotation of the objective, an opaque screen, having a narrow oblong opening, the medial line of which passes through the axis of rotation, is placed over the whole of the sensitized surface, and revolves along with the objective. The result of this arrangement is the production on the sensitized plate of images of the different points that lie around the observer; the angles formed by lines joining the centre of the plate, and the different objects being exactly the same as those formed by lines joining the centre of the instrument and the objects themselves. The position of the objects thus accurately obtained may be transferred to paper, &c., in the ordinary way. As different velocities of rotation may be suited to different purposes, three different velocities may be obtained by means of a regulator. And as it may be wished to mark down only certain points of the panorama, an arrangement is made which secures the attainment of this object. Should it be desired to observe not different points, but successive changes at the same point, the objective and the screen are disconnected, so that only the latter revolves; the successive appearances at the same point are then recorded in succession in a circle round the sensitized plate.

Hyposulphite of Ammonia for Fixing.—The question has repeatedly been asked as to whether the use of hyposulphite of ammonia might not be found more efficient in fixing than that of the soda salt. In some of Sir John Herschel's earliest experiments with the hyposulphites as solvents for silver salts, he used hyposulphite of ammonia, but we have no record of its use for photographic purposes. Mr T. H. Redin, a skilful amateur photographer, has made some good prints fixed with hyposulphite of ammonia. It was used in the same manner as the soda salt. There is good reason to believe it will be valuable in securing more perfect fixation than has hitherto been secured, and will so be conducive to permanency. Hyposul-Phite of soda does not perfectly dissolve albuminate of silver, but leaves some portion of the silver salt in the whites of the print. The new salt effects the perfect removal of the silver.

Recovering Silver.—Let the amateur put his powder, sand and all, into a glass or earthenware jar, and pour over it some aquafortis, diluted with seven times its bulk of water, considerably more than enough to cover the sand, &c. Stir well with a glass rod or piece of charcoal or wood, so long as any fumes are given off. Allow it to settle, and pour off the clear; what remains as sediment may be thrown out, as it is only sand and dirt, the silver and copper being dissolved out. To the blue liquid portion add muriatic acid (spirit of salt) so long as a white curdy precipitate is formed and falls. Pour off the liquid portion, and throw it away as useless. Wash the precipitate

frequently with water until it is tasteless, or is in no way acid without losing any. Then dry it at a low temperature unexposed to light. The remaining powder is tolerably pure chloride of silver. If it is desired to obtain metallic silver from this, the chloride, the following process is both elegant and extremely simple :--Put the chloride of silver into a glass tumbler with some slips or chippings of thin sheet zinc. Then add some oil of vitriol diluted with seven times its bulk of water, sufficient to saturate and cover the contents of the glass, stir with a slip of sheet zinc until the contents assume a home geneous grey colour. Remove the clippings of zinc, and wash the remaining powder with water until it ceases to be acid; dry it, and what remains is chemically pure metallic silver. If wanted in a solid condition, fuse it in a crucible with a little. powdered charcoal, when it will assume the brilliant white metallic lustre characteristic of the pure metal. If he wishes for the alloyed metal he has lost, he may get it in a much simpler way. Let him precipitate the powder into a shallow glass or earthenware vessel full of water. The metal being the heaviest will fall to the bottom first. By removing the superficial layer of sand and dirt, and repeating the process several times, he will obtain the lost metal composed most likely of a mixture of silver and copper.

Silver, How to Save. - The waste silver is an item of considerable importance to every photographer, and an apparatus for saving it must therefore be useful. A "Practical Photographer" thus explains his plan :—I made my sink with more dip or inclination from horizontal than is usual, in order to have the water flow off more rapidly; then in the lowest corner I inserted two lead pipes close together, one of them leading into the waste drain, the other into a tank or barrel under the sink, which should be of sufficient size to contain the washings of one day's work. These vents can be opened or closed at pleasure, by moving a lever attached in such a manner as to close one while it opens the other, and vice versa; or the pipe may be simply closed with a cork, which can be shifted from one to the other as is desired. This is not so convenient a method as the other. Whenever the washings contain silver or gold. I allow them to pass into my tank: but when worthless, by shifting my lever I let them run to waste. I have a

aucet inserted into the tank about one foot from the bottom, and after the day's work is over, I draw off two or three gallons of the contents of the tank, and add to it sufficient cream of lime or whitewash to neutralise the whole, and pour it back, If this operation is rightly managed, the water can be drawn from the tank perfectly clear after standing over night. The cream of lime is best prepared by selecting the purest lumps of quicklime, and slacking them carefully with boiling water (sufficient water should be added, and the mass constantly stirred, to prevent its getting too hot or dry in spots, in which case it will be lumpy and coarse); after cooling, it should be of the consistence of thick cream, and may be kept in an earthen or stone jar for a long time, if properly covered, so as to protect it from the carbonic acid of the air. It will be found very convenient for many purposes. As fast as the tank fills up with sediment to the faucet, I dip it out and dry it, and reduce the silver by any method that may be preferred. The operations are easy and economical, and the saving of silver considerable.

To use Old Baths, and Save the Silver.—A correspondent of the American Journal of Photography says—" For several months past I have been using an old silver bath for silvering albumen paper. It had been used a long time, and was in such a condition that it would not work without considerable trouble, so I added pure water sufficient to precipitate the lodide; then, after filtering, I added silver in crystals until the solution was strong enough for silvering paper; then a sufficient quantity of aqua ammonia. It seems to give as good results as to use the crystals. There is more economy in this process than in 'doctoring up' an old bath; for any one who makes photographs uses more silver for silvering paper than for any other purpose, and by this process old baths that 'will not work' can be used up."

Nitrate of Silver Bath for Negatives, Preparation and Management of.—This bath, which exercises such an important influence on the quality of photographs, is simply composed of nitrate of silver dissolved in water. When dissolved, it should be nearly neutral, the deviation from neutrality being in favour of acidity. In much of the nitrate of silver of commerce there is imprisoned a certain quantity of nitric acid, which,

when the crystals are dissolved in distilled water, renders the solution acid in too great a degree. If the ordinary commercial crystals be employed, crush them into a coarse powder and apply heat, which drives off the excess of nitric acid. Then dissolve them in distilled water, in the proportion of 35 grains of the crystals to I oz, of water. Use only half of the water intended to be added, and then add (previously dissolved in a small quantity of water) about 3 grains of iodide of potassium. The iodide of silver formed by this addition will be dissolved. after which add the remaining half of the water, and then filter. With most of the samples of nitrate of silver no other preparation is required. If, however, the picture taken prove deficient in clearness, add one or two drops of a very diluted solution of nitric acid, composed of half a drachm of the acid in an ounce of distilled water. This for a bath of 12 or 14 ounces will, in most instances, prove sufficient. An efficient method of making a neutral bath is to dissolve 11 oz. of crystals of nitrate of silver in 4 oz, of distilled water, and, when dissolved, to add to it 4 grains of iodide of potassium dissolved in a drachm of water; shake, and add 16 oz, of distilled water. Now add to this a small quantity of oxide of silver (prepared by pouring a solution of caustic potash into a solution of nitrate of silver, and washing well the precipitated oxide) until the solution, already turbid from iodide of silver, is of a dirty brown colour. The quantity of oxide added is of no consequence. When the solution is filtered, it will be found very slightly alkaline, in which condition it would yield foggy pictures. Previous, however, to using it, 5 minims of the following diluted acid should be added :---

Nitric acid (1.50), . . . 6 minims. Distilled water, . . . 1 ounce.

The bath is now ready for use, and will prove to be in the most perfect condition. When, from repeated use, a bath becomes disordered, and produces foggy pictures, it should be tested for acidity by immersing in it a slip of litmus paper. If it do not turn red after being immersed for some time, add some of the dilute acid, given above, until it do so. Fogging in an old bath is easily cured by rendering it slightly alkaline (with diluted ammonia, for example), and exposing to sunlight for some time. By this means all organic matter is precipitated.

After filtration, one or more drops of the diluted nitric acid will be found necessary to restore the requisite acidity. Some baths, which from use or abuse have failed to yield clean pictures, have had their working qualities restored by adding a few drops of a solution of cyanide of potassium, which in the precipitation of the cyanide of silver formed carries down the offending organic matter. Each photographer seems to have his own favourite method of restoring the bath when disorganised; but as the restoration occasionally involves a loss of time, it is desirable that two baths be kept in stock, one relieving the other.

Cheap Collodion Filter. — Procure two new stoppered bottles, wide-mouthed, so that one neck will fit, after grinding with sand and water, into the other, inverted; then knock out the bottom of the inverted bottle, and grind the edges; then fit a bung, air-tight, to act as stopper; cut a funnel-shaped cork to fit in the neck of the inverted bottle, and run a quill up one side of the cork to allow the air to pass through; cement it tight with sealing-wax inside the bottle; put your cotton wool into the bottle, and commence to filter, which will answer the same as those sold at 7s. 6d.

Burnt-in Photographs.—Take saturated solution of bichromate of ammonia, 5 parts; albumen, 3 parts; honey, 3 parts; and dilute with 20 parts of water. Pour this over a glass or enamelled plate, and, after drying, expose for a few seconds under a glass transparency. Now remove to a damp room, and brush over the surface some enamel colour until the image appear. Fix with alcohol, to which a little acetic acid has been added, and when dry rinse in water, dry again, and place in a muffle to burn in.

Fixing Prints.—In various scientific journals it is stated that, if toned prints be placed in a five per cent, solution of common salt, which is then to be raised to the boiling-point, and left ten minutes, they will be perfectly fixed, and merely require washing. A very careful washing is necessary, for any trace of a chloride left in the print tends to destroy it.

Photography on Silk.—Immerse the silk in water, 1 oz.; gelatine, 5 grains; chloride of sodium, 5 grains. Hang it up

to dry; then float for half a minute on a fifty-grain solution of nitrate of silver; dry, print, tone, and fix as usual.

Waterproof Enamel for Card Photographs.—The following is a good substitute for the collodion transfer process, and much easier of application:—First apply with a brush to the surface of the card a solution of gum arabic, of sufficient strength to give considerable gloss when dry. As soon as dry, apply a coating of plain collodion as in coating a plate. If the collodion is not very tough, two or three coatings may be applied to advantage. Finish by passing the card through a roller, and you have a fine gloss. Take care not to have the gum solution too thick, or the surface will crack when dry, though there is but little danger if the collodion is applied soon after the gum is dry. Gelatine, instead of gum arabic, will answer, though it gives hardly as much gloss.

To Remove Nitrate of Silver Stains from the Skin.—Cyanate of potassium is dangerous, but the following may be safely employed:—Make a pretty strong mixture of solutions of bichromate of potash and sulphuric acid.—say two parts saturated solution of bichromate, three of water, or one of sulphuric acid. Wash the hands well with this, then rinse them off, and have at hand some Lugol's solution, which for this purpose may be made as follows:—Iodide of potassium, \(\frac{1}{4} \text{ oz.} \) iodine, 40 or 50 grains; water, 10 oz. After rinsing off the bichromate, wash the stains with this solution. Under its action they rapidly lighten in colour; but the hands become stained deep orange colour by Lugol's solution. Finish them with some negative hyposulphite, which clears off all the colour that remains.

Washing Apparatus.—Attach the prints to a surface of perforated or woven material arranged round a drum, which revolves in a trough containing water, only a portion of the drum being, however, submerged. On communicating a rapid motion to the drum, the prints are alternately immersed in water, and then whirled round with sufficient force to drive of the moisture, thus securing an effectual application to the alternate washing and draining principle which, on the principle of centrifugal force, is recognised as desirable in getting rid of moisture.

Cleaning Glass Plates. - (1.) Soak them in a solution made by dissolving an ounce and a half of bichromate of potash in a pint of water, and adding about 6 drachms of sulphuric acid. Plates soaked in this solution for a few days, and then well washed, will be almost as good as new. (2.) Soak them all night in a strong solution of potash and water. Then place a plate on a flat piece of washing cloth, and with a tuft of the same rub each side and the edges with a saturated mixture of common salt and tripoli. Set the plates up to dry, and clean with a first and second towel kept for the purpose, or wash the plates, adding at first a little nitric acid. The following mixture on a cloth and tuft of its own, giving a final rub wherever the fingers have touched, is recommended :- Old collodion, I oz.; spirit of wine, 2 oz.; water, oz.; tripoli, I oz.; iodine, 15 gr. Shake and leave on plate till wanted. (3.) Make a solution of nitric acid, I part; distilled water, 3 parts. Let the plates stand in this for three days, then rub them well with a cork while wet, and swill them in several clean waters.

To Clean Silver Plates.—Dr C. Calvert gives the following as a good plan:—Plunge the plate for half an hour in a solution of 1 gallon of water, 1 lb. hyposulphite of soda, 8 oz. muriate of ammonia, 4 oz. liquid ammonia, and 4 oz. cyanide of potassium; but as the latter substance is poisonous, it can be dispensed with if necessary. The plate being taken out of the solution is washed, and rubbed with a wash-leather. The same plan may be adopted for all kinds of silver articles or thickly-plated table-ware.

To Copy Cartes without Reduction of Size.—Place the carte or other object to be copied at a distance from the lens of twice its equivalent focus, the sensitized plate being placed at an equal distance. Thus, if the lens be of six inches equivalent focus, the distance between the picture being copied and the sensitive plate on which its image is received will be 24 inches, the lens occupying a place midway between, thus having its centre 12 inches from both the object being copied and the surface on which it is copied.

Double Photographs,—These may be taken with an ordinary camera in the following way:—Against a perfectly black background, take a photograph of the person, only a little to

one side of the plate. After it has had the proper exposure, put the cap on the lens, but do not shut down the slide; then pose the person again according to taste—taking care that his image on the plate shall not overlap the previous image—and expose again, and the double photograph is taken. The first picture will not suffer from a second exposure by reason of the dark background being a negation of light. To insure a good picture the background must be perfectly black, and the object well illuminated. An acid developer is preferable.

New Filtering Apparatus.—An economic filter and percolator has been devised by an ingenious combination of syphon tube and filtering medium. Any test liquid may be drawn from a bottle in a state of limpidity, and if necessary, returned again turbid to the stock for refiltration. By slight modifications the apparatus is used for filtering alcoholic ethereal or caustic alkaline solutions out of contact with the air, and it can be adapted to a water-bath so as to admit of the filtration of gelatinous liquids. The apparatus is specially contrived for use amongst photographers; but it is evident that there are many uses in chemical, pharmaceutical, and manufacturing laboratories to which this apparatus can be economically applied.

Transferring Photographs to Metals for Printing.—Mr Woodbury of Manchester has discovered that gelatine, when dissolved in hot water, if mixed with bichromate of potash or ammonia, dried and exposed to the action of light, becomes insoluble—a result due to the decomposition of the alkaline bichromate and the liberation of chromic acid. It will be seen that a coat of the bichromated gelatine on a glass or metal plate placed under a negative and exposed to light, would, when subjected to the action of hot water, be dissolved away in some parts, and in other parts unaffected, thus producing a photographic positive in relief. Acting on these facts, Mr Woodbury takes the image in relief so produced, and either by mechanical pressure with some soft metal, such as type metal, or by the usual process of electrotyping, produces an intaglio impression therefrom. A properly-prepared ink. formed with gelatine and some black or other coloured pigment, is then passed over the plate, with which the impression is filled up even to the surface. The gradations of relief in the bichromatic gelatine print forms gradations of depth in the metal intaglio, in which again the ink, being transparent, forms gradations of blackness proportioned to its varying thicknesses. A modification of this plan is, in fact, the "Woodbury Process."

The Magnesium Light.—In reference to this wonderful mode of illumination, Professor Schrotter, of the Vienna Academy of Sciences, has obtained some important results, of which the following may be taken as an epitome: -The magnesium light promptly and powerfully produces fluorescent as well as photographic effects. This light contains an extraordinary quantity of ultra-violet rays, the spectrum of which is at least six times as long as that of the luminous portion. Crystallized platino-cyanide of barium, finely powdered or made into a paste with gum, so that it can be fixed on paper, gives a powerful fluorescence when exposed to this light. All substances which become luminous by isolation acquire this property in the highest degree by a few seconds' exposure to burning magnesium, whilst with the sun it takes five to ten minutes to produce the same effect. The light re-emitted by these bodies has no photographic power, the absorbed chemical rays being degraded to purely luminous ones. If a piece of burning magnesium wire is brought near to the sides of a white glass cylinder, filled with equal parts of hydrogen and chlorine gases, drops of hydrochloric acid will be seen to condense on the portion of the cylinder nearest the wire. If now a second piece of wire is burnt on the opposite side of the glass, an explosion takes place almost instantaneously. By means of the magnesium light instantaneous photographs may be taken.

Artificial Light for Photographers.—Professor Falkland recommends peroxide of nitrogen, which may be thus produced:—A light bottle is taken, of about a pint capacity; it is fitted with a cork, through which passes a glass tube, bent to a right angle a little above the top, and the end drawn out so as to form a jet, the tube being bent like the letter U, so that the jet looks upward. The only other essential vessel is a test-tube, or narrow beaker, into which the U tube can easily lip. Fragments of copper, either plate or wire, are placed in the bottle, with a mixture of one part strong nitric acid and two of water. The cork, with its tube, is replaced; the little beaker

is placed in a vessel of warm water, and the bottle is placed so that the bent portion of the tube dips into the beaker. As soon as the gas comes freely through the jet, some bisulphide of carbon is poured into the beaker. The hot water with which the latter is surrounded quickly vaporises the bisulphide, which, when set fire to, burns at the mouth of the beaker with its usual blue lambent flame; but from the gas jet upwards for an inch or more, according to pressure, arises a brilliant cone of flame, giving intense light, and possessing great actinic power. The current of gas should be tolerably rapid, and the bisulphide well heated to ensure the best effect, and it should not be forgotten that the burning bisulphide gives off abundance of deleterious fumes of sulphurous acid.

Easily-prepared Photographic Varnishes.—Procure some good gum benzoin; place it in an earthenware or metal capsule, and apply moderate heat until it is perfectly fluid. Then pour it upon the bottom of a cold plate, and, when it has been quite cold, it may be broken off in pieces. To form the varnish, the following recipes are good. The second is more expensive than the first, but a little better:—

(1.) Dissolve in 8 oz. of methylated alcohol 1 oz. of the fused benzoin and 20 grains of sandarac; then add 20 drops of mastic varnish, made by melting gum mastic, and adding turpentine to it whilst in a fluid state. The impurities will soon settle, and the varnish is ready for use.

(2.)	Fused benzoin,	•	½ ounce.
	Sandarac, .		10 grains.
	Jalap resin, .		d ounce.
	Methylated alcohol		8 fluid ounces.
	Mastic varnish.		20 drops.

Should either of these varnishes be too thick, or become so by use, they may be diluted with a little more spirit. Should the spirit be too strong, which may be known by its partially dissolving the collodion film, a very few drops of water may be added. When using either of the above preparations, the negative may be varnished twice without any danger. This enables us to touch out any spots, &c., on the negative, and then revarnish.

(3.) M. Bussi first brushes the prints over with a solution of

abic, and when this is dry, applies a coating of collodion. lowing are the proportions recommended:—1. Clear rent gum arabic, 25 grammes; distilled water, 100 ents; dissolve and strain. 2. Gun cotton, 3 grammes; 60 grammes; ether, 50 grammes. By this double the preservation of the proofs is insured.

ig Solution.—A good fixing solution should consist of hyposulphite of soda in a pint of water, and should be used fresh. The number of prints of a given size nay be safely fixed in a definite quantity of hypo-solution. be absolutely stated. Theoretically, about three parts sulphite of soda will be required to dissolve one of of silver. One whole sheet of sensitive paper has ilculated to contain about from 25 to 30 grains of of silver. On this theory about half a dozen sheets of night be fixed by I oz, of hyposulphite of soda, , however, so many other circumstances interfere that not more than one-fourth of that number ought to be the quantity. In very cold weather, the solution is atively inactive: it is well, therefore, to raise the temto about 60° Fahr. Thin Saxe paper will generally 1 in new hypo, of the strength named, in about ten ; thick Saxe will require fifteen minutes; thin Rive about fifteen minutes, and thick Rive about twenty A slightly albumenized paper will be fixed more than a highly albumenized sample; the principle being, more horny and repellent the surface, the longer the immersion. Complete immersion and constantly moving re imperative.

sing Screen.—Take a piece of patent plate-glass, the uired, lay it down on a perfectly flat bench or board, small tin tack or two on each side of the glass to keep ice; then take a pinch of the Wellington knife-powder, vill be enough to grind a score of screens. Apply the to your glass with a few drops of water, and mix till s thick as cream; then take a piece of thick plate-glass inch square, and grind the surface of your glass with ir motion of the hand slightly bearing on till you get a ce, which will take from half an hour to one and a half ccording to the size of screen. Apply fresh powder and

water at times, and to see how you are getting on with it, wash in clean water, and dry very steadily before a fire or in the sun; and if the screen has not a nice regular clean face apply the same means over and over again if required, till you get it to your mind, but do not put on any fresh powder in the finishing for the last quarter of an hour, as it will give a finer surface.

A Good Developer.—Mr Carey Lea recommends the following:—Dissolve 10 grains of Nelson's gelatine in an ounce of Beaufoy's acetic acid—that at 10d per lb. Make your new developer of the strength you are accustomed to use, of course without any acid; and to each ounce of it add one drachm of the gelatinised acetic acid. You will be pleased with the result, and with its cleanliness and ease of preparation. This developer will be found to bring out the images with unusual vigour and brilliancy, and may be retained on the plate for a long time without "fogging." Where from unavoidable difficulties under-exposure has arisen, this quality alone will render it invaluable.

Sensitizing Paper.—Albumen, I oz.; water, I oz.; chloride of ammonia, Io grains. The paper is first floated on this and then ironed. It is then again floated on a bath of nitrate of silver, of the strength of 40 grains to 60 grains to an ounce of water.

Purple Staining.—Take a moderate-sized cigar-box, with lid to fit close. Half-way up the box bore half a dozen holes large enough to admit thread each side. Strain tightly, from side to side, a half dozen pieces of thread; fasten with wooden plugs. After the prints are "toned," "washed," and "fixed" in the usual way, dry them well, then lay them faces down on the thread. Underneath place a small saucer containing some carbonate of ammonia. Shut the lid of the box tightly. Expose the prints to the fumes from five to ten minutes, or longer if required. Examine occasionally until the desired effect is produced.

Glass Globes for Magnifying Glasses.—A small piece of very fine glass sticking to the wet point of a steel needle is to be applied to the extreme bluish part of the flame of a lamp; (a spirit lamp is best;) being there melted and run

tle round drop, it is to be removed, upon which it ceases to be fluid; folding then a thin plate of brass, ng very small, smooth perforations, so as not to leave mess on the surface, fit the spherule between the ainst the apertures. The same may be inserted in vory tubes for the photo-micro objects.


ig Mixtures.—The following table of frigerific mixnout ice, may be useful to many photographers in hot or our own country, to keep cool their baths or other by immersing their bottles, &c.:—

Mixtures.		Thermometer Sinks.	Deg. of Cold produced.
lt	parts.	From + 50° to + 10°	40
monia	,,	From + 50° to + 4°	46
nonia	part.	From + 50° to + 4°	46
nonia	••	From + 50° to - 7°	57
.cid	parts.	From + 50° to — 3°	53
monia	parts.	From + 50° to 10°	60
nonia	5 parts.	From + 50° to 14°	64
	parts.	From + 50° to - 12°	62
nonia	parts.	From + 50° to - 21°	71
	parts.	From + 50° to 0°	50
• •	parts.	From + 50° to + 3°	47

re mixed at a warmer temperature than that expressed sle, the effects will be proportionately greater; thus,

if the most powerful of these mixtures be made when the air is $+85^{\circ}$, it will sink the thermometer to $+2^{\circ}$.

Plate-Holder.—In most plate-holders the glass is fixed with screws, which take some time to adjust. In this little



instrument the adjustment is instantaneous, besides the advantage of more accurately fitting the edges of the glass, and thereby lessening the chance of breaking. It can also be used as a holder for exhibiting a portrait before dry. It is easily made, and amateur photographers will find it of service.

H, H, handles; S, S, screws allowing the wood W, W, to form themselves pa-

rallel by the pressure of the glass edges; H, H, holes in the lathe; P, pin; F, fixed pin.

Magic Lantern Photography.—Photographs may be produced with a camera made in the following way:—A is an ordinary 1-plate lens, B the focusing screen, C a slide for



holding negative. It will be observed from this sketch that transparencies may be produced from negatives of the same size, or larger or smaller.

While being used it may be tilted so as to allow the light of the sky to pass through the negative, or it may be used horizontally with a white screen to reflect light through the negative. The chemicals are the same as are used for negatives. Care nust be taken that the silver bath and developer are sufficiently upplied with acid to prevent the slightest appearance of foging. Or you may print from the negative by contact on glass r mica by the collodio-chloride process, which gives very fine esults.

Black for Retouching Photos. - Indian ink consists of the harcoal of fish bones, or a vegetable substance, mixed with singlass size, and probably honey or sugar to prevent its racking. A substance much of the same nature, and appliable to tinting those enlargements denoted black and white, nay be made thus :- Take 3 oz. of isinglass, form it into a ize by gentle heat in double its weight of water; then take alf an ounce of Spanish liquorice, dissolve it also in double its reight of water, and grind it up with half an ounce of fine vory black; add this to the size while hot, and stir well ogether till thoroughly incorporated; finally evaporate away he water, and cast the remaining composition into leaden or ther greased moulds. The colour of this composition will be qual to the finest Indian ink; the liquorice will render it easily lissolvable on rubbing up, and prevent its cracking or peeling rom the ground on which it is laid.

Retouching.—Many photographs need to be retouched. Retouching is undoubtedly more practised on the Continent than it is in this country, and is occasionally used in the whole of the three possible forms :- Retouching on the model, such as strengthening eyebrows, deepening eyelashes with coloured "cosmetic," or the use of violet powder to red hair; retouching the negative with pigment or blacklead pencil; and retouching the print with a suitable water-colour. The darkening of eyebrows or eyelashes merely for securing an improved effect in the portrait is of course unjustifiable, inasmuch as it would alter nature and spoil the likeness, unless the sitters are in the habit of defacing nature by appliances of powder, paint, and dyes. The use of violet powder to modify the effect of red hair requires great skill not to produce an unnatural effect, but it is at times useful and effective. Retouching the negative requirse much skill to produce a good effect, but if done with judgment and skill is very valuable. It is effected with a lead pencil, to soften harsh lines in the face, and strengthen the detail in a few shadows. It in nowise interferes with the truth of nature, but modifies and ameliorates the inherent defects of photography, or of the photographic negative. In retouching a print, the great aim should be to do the least possible to effect the end in view, and especially to let the addition be in strict harmony with the peculiar characteristics of the photograph. For instance, any attempt to stipple upon a face in a formal way will generally issue in the necessity of covering the whole face with such stippling or hatching; whilst a few skilful touches imitating the quality of texture or kind of detail in the print might have produced a really better and more pleasing result with one-tenth of the labour.

Composition Pictures.—In the Exhibition of 1871, many photographs that were much admired were, in fact, simply "compositions" from several negatives. Composition pictures -says Mr E. Dunmore, the well-known amateur photographer -are certainly the most daring attempts to burst the bounds of what is considered the limits of a process, and are attempts worthy of imitation by all. Light and shadow are our sheet anchors. A clever arrangement of the chiaroscuro, and a few touches, will make a picture, when myriads of touches and bad lighting will make a photograph the derision of every one who knows anything about art, perfect, perhaps, in its chemical. aspect, but horrible in its pictorial one. When we see a beartiful result, we are apt to overlook the time, care, skill, energy, and battling with almost insuperable difficulties necessary to its production. The result is all we know, if it be good or bad If good, no one can imitate it without undergoing the same ordeal to procure the negatives.


Reproducing Negatives.—When it is desired to duplicate a negative, the following plan is to be adopted:—Spread on a glass the same size as the negative a mixture of bichromate solution, gum, and honey, to expose under the negative, and, after exposure, dust over with a pigment, which adheres to the unexposed parts, and forms a negative. This is to be washed with a mixture of alcohol and glacial acetic acid, which removes the bichromate without dissolving off the gum. Negatives obtained in this way are reversed, and give reversed positives. They are useful for photolithographic transfers. Instead of dusting the exposed plate with pigment, enamel powder may be used, and the plate may then be burned in, and a negative

of absolute permanence be obtained. (It seems doubtful if such a burned-in negative could have the fulness of detail of a sollodion negative, from the tendency of colours to run a little when fused.)

To Photograph Drawings, Manuscripts, &c,-The usual method is to copy them by reflected light, but Professor Fowler adopts the following:—The paper suitable is very thin, homogeneous in texture, and machine-ruled or lined in the pulp or mass of the paper itself. Upon these lines the manuscript is carefully and boldly written, and so that not a single stroke is wanting. As soon as the page is complete, and the ink quite dry, make the paper transparent with a mixture of olive oil and turpentine, applied by means of a fine sponge to the back. The sheets are then hung up to dry. To obtain a negative of the manuscript, use dry tannin plates, and print by contact. In the printing-frame place first a clean flat glass: upon this lay the manuscript, the back in contact with the glass; and, last of all, press the tannin plate into close apposition with the writing of the manuscript. The door is then This operation is performed, of course, in the dark The front of the printing-frame is covered with a thin room. board, slate, or tin plate; and having brought it in this condiinto the light, the board is removed from the front, and the manuscript is exposed for a few seconds. Replace the board, and carry the printing-frame back into the dark room. Here the negative is developed with pyrogallic acid and silver, and then fixed. The parts beneath the ink-marks are naturally transparent, whilst all the rest is uniformly opaque to the rays This opacity is much more dense and uniform than that which is obtained by copying by means of reflected light. After washing, the plate is dried and varnished. A dozen similar negatives are soon taken in this way; and it is then an easy task to print several hundred facsimile copies of the manuscript or drawing.

Photographic Prints on Linen and Cotton.—Handkerchiefs, &c., are often ornamented with photographs, and, as a matter of curiosity, it may be as well to describe the process. The linen or cotton cloth is first freed from its "dressing," and hen coated with the following preparation:—Distilled water, 125 cubic centimetres; chloride of ammonium, I gramme; the white of one egg. The surface of the fabric is allowed to remain for five minutes in contact with the albumen mixture, then dried, and afterwards rendered sensitive by floating it on a ten per cent, solution of nitrate of silver. The latter operation takes five or six minutes, and requires to be conducted with great care, as spots will inevitably occur in places where the silver solution touches an unalbumenized portion of the fabric. The printing should take place on the same day as the sensitizing, the remaining operations being proceeded with in the ordinary manner. Photographs produced by this method are very permanent, and may be washed with soap without sustaining injury.

Design for a Photographic Studio.—Here we have the ground-plan of a photographic studio which has been found very effective. It is of what has been called the tunnel class, but differs from the kind recommended in the photographic journals in the larger amount of light it admits. Indeed it is probable



that, in an open situation, too much light would find its way to the sitter, and some would therefore have to be shut off; but of two evils, too much and too little light, the former is certainly the smaller, and is moreover advantageous, inasmuch as when decreased the shut out portion serves as a kind of reserve force for dull weather. It is based upon a design of admitted excellence, but the proportions differ considerably, so as to fit it for the use of amateur photographers.

Dark Box for Field-work.—When set up for work, the dimensions of the box herewith described are:—Length, 18 in.; width, 14 in.; height, 13 in.; outside measure when packed, 5½ in. thick, or about the size of a soldier's knapsack. It is

made of very thin deal covered with oil-cloth, and has round each corner pieces of sheetcopper riveted. At each corner, also, inside, there is a light ash upright, hinged by passing a screw through the longest side of the box, and riveting it in the upright, which can then fold down between the edges of the sides, top and bottom. There are three thicknesses of black calico tacked, and in the top of the box there is a lid of sufficient size through which the bottles of chemicals. &c., handed. To set up the box for working it is fastened on its tripod stand, the screwbolt of which, by



a simple contrivance, slips into a groove in the box, and the straps which go quite round being undone, the lid is raised; and the top being supported with one hand, the uprights are

lifted with the other, and entering into small blocks in the top, stretch the calico sides, and the whole thing is quite firm. In the side of the calico, next the operator, there are sleeves through which he passes his hands to enable him to see what he is about. There is a large plate of yellow glass in the lid, and when his eyes are shaded he can see perfectly. The shade is made of stiff oil-cloth covered with black velvet; it has pieces of sheet-iron riveted on to it at right angles, which slip into grooves in the lid. Anything to cover the head would do as well, but the other plan is the most convenient to admit light into the box. There is a yellow-glass window in the side farthest from the operator, made by glueing a light wooden frame to the calico, the glass resting in a rabbet, and having a



metal frame screwed over There is another small light in the lid which can be shut out by a revolving metal cover from the inside: but it is only needed in a very dull light. In the floor of the box there is a vellow glass, so that in developing it can be seen when all the half tones are out by looking through the negative, a point of great importance. The bath is sunk through an

opening in a bag, also the dark slide when done with. These bags have strong wire frames at top to prevent their slipping through the openings. Keep the bath always covered. The holes in the floor of the box have sheet-iron frames riveted over them to support the wood. The water-can is placed on the top, and the water is conducted on to the plate by an elastic tube, a patent slip cutting off the stream. The waste water from the dish is carried off by a tube passing through the bag in which the bath is placed. There is a wooden rack for bottles which contains everything for a long day's work, including chemicals for extra developing and fixing solutions, and bottle of bath solution for filling up; the gutta percha or glass


bath is made water-tight by a strap of wide hoop-iron passing under it, and the ends being turned up the clamp catches them und presses the piece of wood and the indiarubber down on the top of the bath. When the box is packed for travelling, the bath lies inside the tin water-tray or dish; and it rests on the lark slide. The bottle-rack and the water can fill up the remaining space; the cleaning cloths keeping all snug. The plate-box hooks on the lid, protecting the yellow glass; it will hold six plates, either half plates $(6\frac{1}{6} \times 4\frac{3}{6})$, or 4×5 plates; they rest at two corners in grooves, and at the other corners in movable slips of wood, so that both sizes can be carried together, and cannot possibly get rubbed; of course the smaller plates must be the upper ones. The folding tripod-stand is instened to the top above the plate-box. Carry the pack like a

knapsack, and you can go six or eight miles without fatigue; the weight is only about 20 lbs.

Dark Tent.—Mr Wilson, of Aberdeen, recommends the following plan: — The tent is composed of a light tripod of the

usual height for the framework, and a covering of three folds of twilled calico, two black and one yellow. The cloth is first cut into lengths, about a foot more than the length of the tripod

frame, then folded from opposite corners, so that each piece may be cut along the diagonal of the parallelogram into two triangles A, which are afterwards sewn together so as to form, when laid flat on the floor, about three-quarters of a circle B. The edges are cut evenly




round, and bound with tape, and when a square hole has been cut out of the two outer folds of black calico and two folds of yellow cotton to act as a window have been substituted, the tent

A board must next be cut to fit the top of the box, with enings A for sound, and be glued down. Take two as B, and glue across, as shown in C; these are to act ges for the strings.

strings are next to be placed across from one end to the passing over the top of the sounding-board, and resting two bridges; the strings must be fastened by placing one end to attach them, and screws at the other, the


to be used to slacken hten as re-Over these must be another is A, withincisions: to rest on all pegs, 3 igth, placed h corner. dowisthen shut down top of this as in fig. 2. e wind will rough the causing a delightful y, especia door or in an oppart of the ent be left cause an lraught or



of air. The strings must be of small catgut, and must made too tight, or they may be stretched simply between n boards, about I in. or $I_{\frac{1}{2}}$ in. apart, and made to fit dow.

her method.—The annexed sketches will explain:—
2 ft. 6 in. long, 5 in. wide, 1 in. thick. 2. Bottom,


the same length, &c., as top, with two bits of wood aa, 2 in. by 5 in. long, $\frac{1}{4}$ in, thick at each end, bb two bridges for the strings to rest on. The strings must not be tightened too much, but be regulated so as to be moved by the wind; ac four screws to hold the box firm. The strings must be in the centre of the opening ac. You must obtain four catgut strings, two of



the smallest size, to put in the front side, that is the side which the wind first acts on, and the other two at the back. The four strings are fastened to the four holes at each end, as seen in fig. 2, and the top must be plain, with two holes at

each end to screw to the bottom. When you wish to hear it play, fix it under the bottom sash of the window, taking care to put two pegs in the top to keep it from falling. One made on the above plan played for six or seven years.

Home-made Violins.—The more simple the form of the instrument the better will be the tone. The backs and sides



of the Cremons
violins were made
of maple, and the
bellies of pine wood
well seasoned and
dry. A plain deal
box, with a violin
neck glued to one


of its ends, and fitted up with strings, bridge, &c., will be found far superior in point of tone to the ordinary run of violins. The back and belly are of soft pine wood (the grain very strong and equidistant) 14 in. in length; width at bottom end 8½ in.; width at top end 6 in. Of course the back and belly are made of two parts each, glued straight up the middle, and the thickness of each is 1-5th of an inch in the middle (where the pieces

are joined together), diminishing gradually right and left to I-12th of an inch at the edges; the depth of sides is 2 in., and the sound-holes are straight instead of being curved like an f. The neck and pegs are the same as other violins, If the instrument is to be varnished, the best varnish is shellac, dissolved in spirits of wine. Any druggist will give it the proper It does not signify what the colour is. The wood must not be stained before varnishing, as it will close up the pores, and so prevent a free and energetic vibration. The prefixed is a rough sketch of the home-made violin; the dotted lines show the blocks in the inside for strengthening the instrument. Its internal capacity is greater than ordinary violins. The young musician, who wants an eloquent violin of the ordinary shape, will find full directions for striking out and making entirely in Otto's "Treatise on the Violin,"

The tone of a violin depends chiefly upon the form, size, thickness, and quality of the wood. The size of the body of a violin is about 14 in. long, 4\frac{3}{2} in. wide across the "waist," or narrowest, and 8\frac{1}{2} in. over the widest part of the back and belly. If the length, 14 in., be divided into 72 parts, it will form a convenient scale for measurement, and will accordingly be so made use of in this short account.

The form, taking the violin as seen flatways, is best obtained from some violin of good pattern. But as power and brilliancy of tone are, in a great degree, due to the reflection of the vibrations (passing from the bow down the bridge and sound-post into the body of the violin), from the ribs as the containing boundary, back to the centre of the body (a fact not noticed by Otto or others), the form of the sides or ribs is a matter of some consequence. That a square violin reflects these vibrations only from side to side and end to end, and does not concentrate, or focus them anywhere, must be obvious. And that such a form has power, is due only to its greater capacity, it being well known that large violins are most powerful in tone, and, therefore, in most request with skilled concert-players. As to the form taken, as the violin is seen sideways, it should be even more particularly adapted for the reflection of vibrations noticed, and is evidently so in all good instruments. section of the back and belly of these, taken at the narrowest part or waist, will be found (outwards) concave near the side and convex in the centre, and this plan prevails more or less all round the body. Old violins are, however, constantly seen with a wholly different model, convex in almost every part, high, and bulging towards the ribs; but they have always a dull, hollow, tubby sound, which appears as if it could not get out, owing, doubtless, to the form inclining the reflection of vibration towards the ribs, instead of to the centre of the body. It would be difficult to give an exact section of back or belly of a violin, as it must depend upon the eye (bearing in mind the principle of reflection of sound) to model out these curved forms into flowing gradations from concave to convex.

One mistake into which a beginner is likely to fall may here be pointed out. As the edges of the back and belly are a trifle thicker where they are glued to the sides, and as the outside is



formed before hollowing out the inner, allowance must be made for this extrathickness, or the inner side of the back or belly will be concave where is should be convex as at A, the prope form being as at B

Violin-making is an art requiring ex

perience and skill, and those wishing to succeed should, as in other arts, study what has been done by the most skilful; and in this department Straduarius and Joseph Guanerius stand foremost, and have left the finest specimens of their particular skill, which should form the model for a good-toned violin.

Dimensions of various parts of Violin.

Sides or ribs, $\frac{1}{3}$ of a part thick.

Sides or ribs, 64 parts wide, diminishing gradually to 6 parts at the neck.

Side linings, $\frac{1}{2}$ part thick, $1\frac{1}{2}$ parts broad. Upper block, 10 parts broad, 4 thick,

Lower ,, 8 ,, ,, 4 ,, Corner ,, 8 ,, ,, 4 ,,


Belly under the bridge two-thirds of a part thick, diminishing

gradually to one-third at the edges. Back under the bridge one part thick, diminishing to half a part at the edges. The external edges of back and belly should be left rather thicker for strength. Bass bar, an inside piece glued to the belly and standing under and supporting the left foot of the bridge, thirty-six parts long, one and one-fifth parts broad, two parts thick in the centre, diminishing to two-thirds of a part at each end. In fig. 1, a half section, these parts are shown.

Wood.—In good violins the back, ribs, and neck, with keybox, are made of a species of foreign sycamore or maple, called harewood, the belly and sound-post of Swiss deal: for the former, English sycamore is too soft; maple would probably be the best English wood; and the best substitute for Swiss would be Finland deal, selected free from turpentine, light in weight, and of fine and regular bate or grain, from a centre plank, which should show the grain on the edge as well as the surface. All wood used should be thoroughly seasoned. It is said that wood, if often baked for the purpose of more completely freeing it from turpentine, &c., a certain crispness in the tone may be thus acquired. It should have been stated that the small blocks are made of sallow, but deal may be used.

Tools.—In making this violin, it is necessary to have 20 or more small wooden cramps made of close-grained wood, like the sketch; of beech

or birch, 3 inches or more in length, I in. wide at each end, and half an inch thick, with a notch dd 13 in. long, to receive the edge of the violin, which we



get tight by two thin wedges, $1\frac{1}{4}$ in. long, $\frac{1}{2}$ in. broad, and $\frac{1}{8}$ in thick, entering one at each side, as at c, the wedges being placed on the back and belly, but not on the ribs. If in the event of being often wanted, wire-tapped screws wormed into the ends of the cramps as shown might be used made of about No. 10, or 1-10th of an inch wire, and got tight against wooden hooks, as at c, b being the violin. In commencing, let the amateur first cramp the back to the sides, exactly where

it requires to be, with five or six cramps on each side; therelease one side, which will spring off sufficiently to be glued. When glued, nip close together with ten or twelve cramps. This done, release the other side, glue and cramp it in the same manner. Then set it to dry and harden for a day or twelve before repeating the same process with nothing on the belly. When thoroughly dry, scrape off any superfluous glue from the edges. If any crevices appear, trace a little hot thinish glue, with the small end of a skewer, round the edges, so as to smooth or fill up every crevice.

Musical Vibration.—The tones of violins being so various. it is almost difficult to judge the difference, or best, from the various tastes of players. Some like a fine or firm tone, some a loud tone, some a hard, sharp, or leading tone, some a crisp or wiry tone. Each may be deemed best in the estimation of such a variety of advocates. A violin with back, belly, and sides, all of pine, is not likely, as a general rule, to produce & fine clear tone, save from the spontaneous harmonizing vibrations, perchance, of back and belly. It is impossible for any manufacturer of violins, however defined his rule for construction may be, to produce two or more consecutive violins that will possess an equal number of free vibrations of back and belly (minus the sounding-post), that is to say, the backs and bellies of each violin would not be in union with each other in their vibrations; nor equal in power, tone, or quality. doubt, the finest-toned violins would be those whose natural free vibrations of backs and bellies are in unison, or in octaves to each other. But such occurring by chance is a mere lotter. Even those whose spontaneous free vibrations closely harmonise together will have an especial superiority over other whose free vibrations class amongst the wide-spread intervals of discord.

Preserving Skins.—Small skins may be preserved in the following manner. They are first cleaned and scraped; they are then rubbed over with arsenical soap, prepared thus:—To four pounds of white curd soap add one pound of arsenic and one ounce of camphor; cut the soap into thin slices, and dissolve it in one pint of water. When melted, add the arsenic and camphor, stirring them well together, and boil again, until the substance of a thick paste is attained, and pour it into jars

while hot. When cold, tie it up carefully with bladder, and it will retain its qualities for years.

Rabbit skins, and indeed any moderately small skins, may be made white and the coat preserved, by first taking a blunt knife and scraping the skin on a piece of circular wood, so as to get off as much of the flesh and fat as possible; then make a solution of alum, salt, and water, four to one of alum, as much as the water will contain. Dissolve the alum in hot water, when cold immerse the skin in it, and in about forty-eight hours the skins will be cured. Wash in a weak solution of soda and water, to carry off any fat that may remain. If for sheep, or other skins that are thicker, a longer time will be required. The skins should be pulled about before thoroughly dry to stretch them. This plan is a very fair one, but is, of course, not perfect.

Bird-Stuffing.—First dissect your specimen. In dissecting. three things only are necessary to ensure success, viz., a penknife, a hand not coarse and clumsy, and practice. In stuffing, you require cotton, a needle and thread, a little stick, glass cres, a solution of corrosive sublimate, and any kind of temporary box to hold the specimens. Wire is worse than useless, as it gives a stiff appearance to the object stuffed. small proportion of the skull-bone, say from the fore-part of the eye to the bill, is to be left in, part of the wing-bones, the jaw-bones, and half of the thigh-bones remain. Everything else—flesh, fat, eyes, bones, brain, and tendons—are all to be taken away. In taking off the skin from the body, it will be well to keep in mind that you must try to shove in lieu of pulling it, lest you stretch it. Throughout the whole operation. as fast as you detach the skin from the body, you must put cotton immediately betwixt the body and it; this will prevent the plumage getting dirty. Let us now proceed to dissect a bird. Have close by you a little bottle of corrosive sublimate, also a little stick, and a handful or two of cotton. fill the mouth and nostrils with cotton, and place it on your knee on its back, with its head pointed to your left shoulder. Take hold of the knife with your two first fingers and thumb, the edge upward; you must not keep the point of the knife perpendicular to the body of the bird, because, were you to hold it so, you would cut the inner skin of the belly, and thus let the

To avoid this, let your knife be parallel to the bowels out. body, and then you can divide the outer skin with great ease, Begin on the belly below the breast-bone, and cut down the middle, quite to the vent. This done, put the bird in any comvenient position, and separate the skin from the body, till you get at the middle joint of the thigh. Cut it through, and de nothing more there at present, except introduce cotton all the way on that side, from the vent to the breast-bone. the same on the opposite side. Now place the bird perperdicular, its breast resting on your knee, with its back towards Separate the skin from the body on each side of the vent, and never mind at present the part at the vent to the root of Bend the tail gently down to the back, and while your finger and thumb are keeping down the detached parts of the skin on each side of the vent, cut quite across and deep, until you see the backbone near the oil-gland at the root of the Sever the backbone at the joint, and then you have all the root of the tail, together with the oil-gland, dissected from Apply plenty of cotton. After this, by shoving the body. and cutting, get the skin pushed up until you come to where the wing-joints join the body. Apply cotton, and then cut this joint through, and do the same at the other wing; add cotton, and gently push the skin over the head, cut out the roots of the ears, and continue skinning till you reach the middle of the eye; cut the membrane quite through, otherwise you would tear the orbit of the eye. After this nothing difficult intervenes to prevent your arriving at the root of the bill; when this is effected, cut away the body, leaving just a little bit of the skull: clean well the jaw-bones, and touch the skull and corresponding parts with the solution. Now all that remains to be removed is the flesh on the middle joints of the wings, one bone of the thighs, and the fleshy root of the tail. Fasten thread to the joints of each wing, and then tie them together, leaving exactly the same space betwixt them as your knowledge in anatomy informs you existed there when the bird was entire; hold the skin open with your finger and thumb, and apply the solution to every part of the inside. Neglect the head and neck at present; they will receive it afterwards. body moderately with wool, to prevent the feathers on the belly from being injured. You must recollect that half of the thigh, or, in other words, one joint of the thigh bone, has been cut

. As this bone never moved perpendicular to the body, on the contrary, in an oblique direction, as soon as it is iff the remaining part of the thigh and leg, having nothing to support them obliquely, most naturally fall to their pericular. Hence the reason why the legs appear consider-To correct this, take your zeedle and thread, n the ends round the bone inside, then push the skin just site to it, and then tack up the thigh under the wings with al strong stitches. This will shorten the thigh, and render ite capable of supporting the body without the aid of wire. is the time to put in the cotton for an artificial body, seans of the little stick, and then sew up the orifice you nally made in the belly, beginning at the vent. Lastly, your stick into the solution, and put it down the throat or four times, in order that every part may receive it. n the head and neck are filled with cotton quite to your g, close the bill as in nature. Bring the feet together by , and then run a thread through the knees, by which you draw them to each other, as near as you may judge Nothing now remains to be added but the eyes; st the orbit to them as in nature, and that requires no other ner. After this, touch the bill, orbit, feet, and former oild at the root of the tail with the solution, and then you given to the bird everything necessary, except attitude and oper degree of elasticity. Procure any common, ordibox; fill one end of it, about three-fourths up to the top, cotton, forming a sloping plane. Make a moderate holto receive it, and place the bird in its right position, wish to elevate the wings, do so, and support them with If you wish to have the tail expanded, reverse the r of the feathers, beginning from the two middle ones, and a dry place them in their true order, and the tail will pree for ever the expansion you have given it. days the feet lose their natural elasticity, and the knees n to stiffen. When you observe this, it is the time to give legs any angle you wish, and to arrange the toes. When bird is quite dry, pull the thread out of the knees, and take y the needle, and all is done.

sects for Cases.—Living insects, of which you wish to e "objects," are instantly killed by putting them into a jar

of carbonic acid gas. This gives them no pain, and leaves them in the best state for mounting. As soon as they are dead, spread them in the shape desired, and fasten them down to the box with a corking-pin.

Skeleton Leaves.—Skeleton leaves may be prepared as follows:—

- I. Steep the leaves in rain-water, in an open vessel, exposed to the air and sun. Water must occasionally be added to compensate the loss by evaporation. The leaves will soon putrefy, and then their membranes will begin to open; now lay them on a clean white plate filled with clean water, and with gentle touches take off the external membranes, separating them cautiously near the middle rib. When there is an opening towards the latter, the whole membrane separates easily. The process requires a great deal of patience, as ample time must be given for the vegetable tissues to decay and separate.
- 2. A more expeditious method is the following:—A table spoonful of chloride of lime in a liquid state mixed with a quart of pure spring-water. The leaves or seed-vessels of plants must be soaked in the mixture for about four hours, then taken out and well washed in a large basin filled with water; after which they should be left to dry, with free exposure to light and air. Some of the larger species of forest leaves, or such as have strong ribs, will require to be left rather more than four hours in the liquid.
- 3. Perhaps the most effectual way is—First dip the leaves in boiling water, and then immerse them in dilute sulphuric acid, containing from 10 to 30 per cent. of the acid, according to the delicacy or coarseness of the leaf-structure. In a day or two use a pretty stiff bristle brush to the leaves, adding drop by drop a little saturated solution of bichromate of potassium. When the operation seems complete, wash the leaves carefully in ammoniated water, and finish with a little weak hypochlorite of calcium or chlorine water.
- 4. Dissolve 3 oz. of common washing-soda in a quart of boiling water, and add 1½ oz. of fresh-slaked quicklime; boil it ten minutes. Pour into a pitcher, and let it stand a short time till settled; then pour the clear solution again into the pan, and let it boil. Add the leaves, and boil for say an hour, adding water to supply that evaporated. Take one of the leaves out

into a dish of clean water, and rub it gently between finger and thumb. If the outer covering will leave the mid-rib and veins, they will do; if not, boil longer. Bleach thus:—One drachm of chloride of lime mixed in a pint of water, and allowed to settle; pour off the clear liquid, and put in the leaves. Steep them till white—say about ten minutes. If they stay too long, they become brittle. Wash them in a dish of clean water, and

dry in a book between blotting-paper.

When the "skeletons" are obtained by either of the four processes given above, they may be plated by being dipped into a very weak solution of phosphorus in bisulphide of carbon, dried, placed in a neutral solution of nitrate of silver for fifteen minutes, dried again, and lastly covered with dead silver in a small electro-plating apparatus. An almost equally beautiful result is produced if the "skeletons" are dipped into a clear boiling saturated solution of iodide of lead. When dry, they appear as if frosted with gold. If cautiously painted with a very concentrated alcoholic solution of mauve, skeleton leaves present the appearance of a magnificent and delicate casting in bronze. It is best to prepare leaves of one kind only at a time. as the time it takes to strip them differs considerably. The preparation of skeleton leaves is a very delicate and wearisome process, and should only be attempted by those happily constituted persons who can keep their patience under repeated failures.

Dried Flowers Preserved in their Natural Colours.—Provide a vessel with a movable cover, and having removed the cover from it, fix over it a piece of metallic gauze of moderate fineness, and replace the cover. Then take a quantity of sand sufficient to fill the vessel, and pass through a sieve into an iron pot, where it is heated, with the addition of a small quantity of stearine, carefully stirred, so as to thoroughly mix the ingredients. The quantity of stearine to be added is at the rate of half a lb. to 100 lbs. of sand. Care must be taken not to add too much, as it would sink to the bottom and injure the flowers. The vessel with its cover on, and the gauze beneath it, is then turned upside down, and the bottom being removed, the flowers to be operated upon are carefully placed on the gauze and the sand gently poured in, so as to cover the flowers entirely, the leaves being thus prevented from touching each

other. The vessel is then put in a hot place, where it is lest for 48 hours. The flowers thus become dried, and they retain their natural colours. The vessel still remaining bottom upwards, the lid is taken off, and the sand runs away through the gauze, leaving the flowers uninjured.

To Stock a Fresh-Water Aquarium.—There ought to be about three plants to every gallon of water, and two or three fishes, according to size, to every plant. Respecting the

Fishes suitable for the aquarium we may make the following remarks:—

Crusian or German Carp (Cyprinus curassius).—There are two kinds of them; one is rather broader than the other. Its colour is gold-like, and is darker toward its tail. You ought not to have any, in a little aquarium, longer than two inches. Its back is bream-shaped, and it rises from the nape to a high arch along the line of the dorsal fin. It is a little subject to fungoid growths. It will live in dirty water, and is easily fed with bread crumbs; but you must always be careful not to give it more than it can eat at once, because the bread on the bottom of the aquarium will render the water impure.

The Roach (Cyprinus rutilus) is very common.—It will also live in dirty water, and is very fit for an aquarium.

Prussian Carp (Cyprinus carpis).—It is easily separated from C. curassius, through its olive-brown colour, its beard round its mouth, and its tail and fins are darker. It is not as broad, but rounder.

Gold Carp (Cyprinus auratus), called so by Linnæus, the celebrated Swedish naturalist. It originates from China, its colour is gold, has the shape of C. curassius. When it is young it is silverlike. It is nice to look at, but very dull, and difficult to tame. They sometimes get poorly, and are covered with a white mould; then you must remove it to a shallow basin, put a little salt on its back, and it will soon rub the mould off.

Minnow (Cyprinus Phoxinus), ought to be in every aquarium. An aquarium without minnows is no aquarium at all—it is a makeshift. With a shoal of minnows and a few Prussian carp, an aquarium may be considered fairly stocked, because there is really something to look at, something to amuse, and something to instruct. They are very sharp and amusing, always on the

move; but it is very strange that they live in an aquarium, because you never find them in other than quite clean water in their wild state. Their lower parts have a red colour during the summer-time, but fright will make them assume a pale fawn colour. The back and the top of the head have a dark clive-green colour. It is a little fish, but round. It will never grow longer than three to four inches. You ought never to have any longer than two inches in a small tank. It is very easy to tame; you can soon teach it to eat out of your hand.

The Bleak (Cyprinus alburnus) is also a fitting fish for a tank, especially if you pick small specimens. It is active in its movements, has a white, silverlike colour, and is continually on the move.

Perch (Cyprinus fluviatilis).—You must pick very small specimens. It is a very handsome fish, but must have quite clean water, and can consequently not live long in an aquarium.

Stickleback (Gasterosteus).—Should never be put into an aquarium with other small fishes. They are greedy and uneasy, and scarcely ever let the other fishes alone, often killing They must therefore be kept in a tank by themselves, or where there are only large fishes. They are, however, very interesting. Dr Lankaster, speaking of this fish, says: -- "He has all the ways of other fishes, and many more besides. Look into your tank; see, there is one larger than the rest; he is clothed in a coat of mail like a knight of old, and it is resplendent with purple and gold. See how his eyes glisten, and with every movement present a new colour. He is a male fish, the king of your little shoal. He has important offices to perform. Presently, in the course of a few days, if you watch him, and are fortunate, you will see this wonderful little fish engaged in the most useful manner in building a nest. He first seizes hold of one little bit of weed, then of another, and carries them all to some safe corner, till at last his nest is built. done this, he gently allures his mate to his new-made home. Here she deposits her eggs, and having done this, resigns the care of them to our hero of the purple and gold, who watches over them with an anxiety that no other male in creation but the male stickleback seems to know. He fans and freshens the water with his fins, and at last, when the young are hatched, watches over their attempts at swimming with the greatest

Nor is this habit confined to the fresh-water stickleanxiety. backs. A lady, writing to me from Aberdeen, and describing her aquavivarium, says, 'A fifteen-spined stickleback (Gasterosteus spinachia) constructed a nest on a piece of rock which was covered with a fine green seaweed, depositing the spawn first, then covering it with loose seaweed, and lacing all together with a long thread, composed, apparently, of some The fish afterwards, for about the space of three secretion. weeks, watched the nest, never leaving it at all save for the purpose of driving away the other fish when they approached When a stick was introduced into the vicinity of the nest, the fish would fly open-mouthed to attack it, and would bite it with great apparent fury. At the expiration of the above-named time, the young fry made their appearance by hundreds, but I am sorry to say they soon disappeared, being devoured by the other fish, and caught by the tentacles of the sea-anemones. The mother-fish continued her attendance at the nest as long as any of the young fry were left,"


If you see your fishes go up to the surface of the water in your aquarium, you have too many fishes; so you must either take away some, or put in some more plants. If you then find that the glass sides commence to be green, you are obliged to put in some snails or molluscs, which will in a short time clean the glass; but if you put in too many, they will commence to eat the plants, and then you have to remove some of them, especially Linnaus stagnalis, because that one likes the plants better than the green moss on the glass. The best wood of which to construct an aquarium is East India teak. It is generally very evenly grained, easily cleaned up for polishing, and, all things considered, it seems the most suitable. It may be obtained at shipbuilding establishments, or of coach-builders, at a little over the price of mahogany.

The Size.—For a small room, one to hold ten or twelve gallons of water is a good size. Suppose we get a piece for the bottom 2 ft. long by 14 in. broad, to finish 1 in. clear in thickness, and 4 ft. 4 in. to finish $1\frac{3}{4}$ in. square for the pillars. We yet require a piece for the top frame 6 ft. 4 in. long, $2\frac{1}{4}$ in. by $\frac{1}{2}$ in, thick. This is all the timber required for the tank. After planing up the bottom and squaring the sides and ends, run a cutting guage round it $1\frac{3}{4}$ in, from the outside. This is the outside of the glass; then again a $\frac{1}{4}$ in, within, to

llow for the composition with which the glass is fixed. The roove must be a $\frac{1}{4}$ in. or $\frac{5}{16}$ in. deep. Next guage $\frac{7}{8}$ in. from he edge for the distance the vase mould is worked back. fillars to be planed up to 13 in. square, and grooved on two ides in the centre $\frac{9}{16}$ in. deep, allowing the same for compoition as in the bottom. This groove must be carefully filled up with a piece of deal before turning, and the length must be o show 12 in. of glass. Some care must be taken not to sink :00 much in turning, so as to get to the bottom of the groove. Leave a square 11 in. at the bottom, and 2 in. at the top. The pillar, to get the tank water-tight, ought to be tenoned into the bottom \(\frac{1}{2} \) in. deep. The best proportion of an aquarium is that the length ought to be double the width, and the height equal to the width; as, for example, if the length be 2 feet, the height and width should be I foot. There ought to be neither paint nor varnish inside the aquarium; they are injurious to


the fish. The best time of the year for making an aquarium is April, May, or the beginning of June, because the fish and insects are very still in the cold season, so that they are accustomed to the small space.

A gentleman, with some years' experience of a 40-



gallon aquarium, says that zinc or iron should be most strictly kept out of contact with the water; iron is bad for the plants, and zinc is poisonous to the fish; the metal, being always impure, is dissolved more or less. You can try a varnish made by dissolving marine glue in wood naphtha made thin, and allowed to dry down to necessary consistence. This forms a capital varnish for the joints of aquarium over the lead cement. varnish should be laid on thin for the first coat, as it then runs into small crevices; each coat to stand a day. All lac varnishes are attacked by the ammonia in the water. Should it be impossible to empty the tank or take out pipe, you might try a brass tube just large enough to drop over iron and zinc pipe, an indiarubber ring at bottom coming just below edge of brass tube to exclude current of water setting up between the tubes; or, perhaps better still, a piece of indiarubber tubing slipped over the iron and zinc pipe. Portland cement is also injurious to fish. Roman cement should be exclusively used for rock-work, which should be soaked in water for a month before being placed with the fish.


Aquarium Fountain.—A table or aquarium fountain may be made thus:—The design is simple, requiring no piston, weights, or other mechanism; it is, in fact, a "syphon with an enlarged bend." The experiment was first tried with a pickle



bottle and two bits of tube. The air must be sucked out till the water, rising through a cut of the jug c, begins to run down the tube b; the fountain will then play till all the water in c is exhausted, or as in the second engraving (representing the actual fountain). A is a glass shade fitted air-tight into a tray of tin, or other material; a is a tube with a nozzle, having a hole about 1-16th of an inch; a piece of glass tube drawn to a point will do very well; the lower end should nearly touch

the aquarium, or other reservoir; b is a tube, the top of which should be nearly flush with the tray as shown; say 6 in. may

be metal or glass, the rest may be elastic, or any other tube, and may convey the waste water through the bottom of the aquarium, or over the top, or out of a window. The weight of the water in the longer arm of the syphon b




produces a partial vacuum in A, the water consequently rises

through a.


1. In this plan the pipe conveying the water from the piston to the jet is indiarubber, fastened to a piece of brass tubing about 11 in. long on top of piston, the other end being fastened to the jet-pipe, as shown in present sketch. The running of water is also shown. IT, indiarubber tube, connecting JP, jet-pipe, with top of piston. WP, waste-pipe, conveying the water from B down outside of jet-pipe to cylinder. It may be open or closed at top; if closed, the cap must be drilled full of little holes. The water in B has to rise to top of this waste-pipe, thus keeping a good supply of water for fish. The tube WP may be hidden by artificial rocks.

2. In this diagram, A is a porcelain or other basin, B and C are two glass globes connected by two tubes D and F, of which D commences near the top of the upper globe, and ends near the top of the lower one; and F commences at



L in the basin A, and ends near the bottom of the lower globe. The third tube E commences in the jet at J, and ends near the

bottom of the upper globe. G is a plug fastened by a string at K; H is a stopcock leading out of the lower globe to the outside of the aquarium; WW is water. This fountain is placed in the aquarium till the water is a little above the vessel A. When you wish it to play, pull out the plug G, and open the stopcock H; the water then rushes in at G till it is nearly level with the top of the tube D, and then the plug G is replaced, the stopcock H is closed, and the jet J, which must also



have a stopcock, is opened; the water then rushes down the tube F into the lower globe, the water forces the air up the tube D into the upper globe, and the compressed air forces the water in the upper globe through the tube E, and through the jet J. Then when the water in B is exhausted, shut up the jet, pull out the plug G, and open the stopcock H, &c.

Spirit Blow-Pipes.

Two spirit blow-pipes, figs. 1 and 2, are described below: Fig. 1 has a boiler, A, made of copper, in the most suitable shape. It must be air-tight. B is a safety-valve, which is kept close by a spiral


spring inside. The valve B must be made with a socket, the socket being brazed on top of boiler; it must be made to screw off and on; a pipe, D, must then be brazed in at the top, a stop-

C, must be put on the pipe, and another pipe, Dl, must be sted on the end of stopcock, and brought a little more than ay under the bottom of boiler. If required for making ers' joints, a small round hole in the end G will answer if for melting sheet-brass, the end made flat will do. It

be a good plan to get jets to screw on and A socket should be brazed on the side, with e of iron tapped into it; the piece of iron be tapped at both ends, and a socket with

nbscrew made to screw on to it. A piece of round baror gas-pipe should be put for a slide F, and a piece of iron should be put at the bottom for F to be fixed into, or the lamp H to stand on. I is a regulator to turn the

ip and down. t-hole should t in the top p, the boiler l be filled up nin I inch of with methyspirits, and mp may be vith the same. nust be taken e everything and an inber washer be put on nder side of safety-valve; alve can be out to put in. Stopcan be got I in, long, 2 is another of blow-pipe.




ne of sheet iron is made similar to a pint pot, only the part of the front is cut away to make room to put the H in, and to allow the flame to come out. A is the made of two pieces of copper, with both edges closed to

form a rim outside; the boiler should be made to fit the frame, a safety-valve, B, should have a socket brazed in at the top of boiler; the valve must be made to screw in and out. A spiral spring must be put to keep the valve closed; a pipe, D, must be put in as near the top as possible; a stopcock, C, must be put as near as it can be, so as to come above the frame that holds the lamp and boiler; a pipe, Dl, must be put to conduct the gas down to the bottom, a little more than half-way under the boiler; a lamp, H, must then be put under, leaving about an inch between the boiler and lamp. A small hole must be made in the back of the frame for the regulator I to come through; the pipe should terminate the same as in fig. 1; a small ring should be put on the bottom of fig. 2 of the lamp to draw it out when required. Both boilers must be supplied by taking out the safety-valve, and nearly filled with methylated spirits.

A Spirit Blow-pipe, made on either of the above plans, effects a considerable saving of spirits. On lighting the lamp, the cock can be turned off till the spirits are hot; it can then be turned on, and the flame can be regulated as required.

Spirit Blow-Pipe.—It is all copper, and cylindrical; but shown in section with lid on. The pipe or tube, as will be




seen, forms the handle, and is put in operation by igniting the spirits, which are up to the dotted lines, and extinguished by simply putting on the lid; it can be made to meet the requirements of almost any class of artizan. It is very simple, compact, easy to manage, and stands on its own bottom.

By connecting another vessel for the regular supply of spirits, it can be kept going for any length of time, and by other simple arrangements the flame can be placed in any direction.

Amateur's Gas Blow-Pipe.—This may be easily constructed. All that is requisite is a common blow-pipe and a piece of brass tube about 3-16ths of an inch in diameter. Bend the tube slightly at one end, and at the shoulder make a hole so that the small end of the blow-pipe may pass through into the larger tube, to come about flush with its end. Solder the joint to make it air-tight, and fasten pieces of vulcanized indiarubber tube of any convenient length to each of the other ends

the brass tubes, and the instrument is complete. Let gas use through the larger tube and ignite it; now blow through the blow-pipe, and by regulating the gas-flame you can easily tain any degree of heat you wish, as well as a very steady

ame of any shape, ew who have ace used it will illingly go back the single tube or ordinary blowipe. The fine and of the blowipe should be bout the centre of ne larger or gas abe,



Matches without Phosphorus. — The following mixtures nil be found to answer satisfactorily:—I. Divide a solution f copper into two equal parts; supersaturate one with amnonia and the other with hyposulphate of soda; mix them ogether, and dry the precipitate, which will fall. with strong glue and a small quantity of powdered glass. ucifers made with this mixture will ignite on any rough surace. 2. Take from four to six parts of chlorate of potash, and two parts each of bichromate of potash, and of oxide of ron or lead, and mix with three parts of strong glue. For an guiting surface, take from four to six parts of oxide of either ron, lead, or manganese, two parts of glass-powder, and from wo to three parts of strong glue or gum. These matches will gnite only on the friction surface thus prepared. Another German chemist uses for the match-heads a mixture of chlorate of potash and a salt which he describes as a compound of yposulphurous acid with soda, ammonia, and oxide and subwide of copper. He forms this compound by dividing a soluon of copper into two equal parts, supersaturating one of them ith ammonia, and the other with hyposulphate of soda; then lixing the two solutions, and stirring the mixture well. A olet powder precipitates; one part of it is to be mixed with vo parts of the chlorate of potash, and a small quantity of ounded glass. Lucifers made in this way, however, will ignite on any rough surface, even more easily than the common kind.

Use of Alum in Iron Safes.—In fire-proof safes there is a certain space filled with powdered alum. When the heat reaches this, the water of crystallization is driven off, by which a great absorption of heat is produced, and the temperature of the interior of the safe kept proportionately low. This is the principle of Milner's safe.

Chlorate of Potash.—Mix 3 lbs. of common salt, 2 lbs. of manganese at 8d. or 9d., and 2 lbs. by weight of oil of vitriol, previously diluted with about 2 pints of water, and allowed to cool; distil into a retort containing 6 oz. pearl ash, dissolved in 3 lbs. of water; when the distillation is finished, evaporate the liquid in the receiver slowly in the dark. The chlorate will crystallize in flakes. Of course these quantities may be altered to suit the convenience of the operator.

Spontaneous Combustion of Oil Rags.—When cotton waste or shavings are saturated with oil, a large surface is exposed to the action of the air; and if the oil has the property of absorbing oxygen, it may absorb the gas so rapidly as to take fire. This is the way in which spontaneous combustion takes place. As petroleum naphtha does not absorb oxygen, it never takes fire by spontaneous combustion.


Lubricating Composition.—Good lard, 16 oz.; bees'-wax, 2 oz.; olive or sperm oil, 40 oz.; flowers of sulphur, 8 oz.; blacklead, 4 oz. (in powder, and free from grit); white soap, 1 oz.; all of the best quality, and to be well incorporated.

Crucibles of Lime.—In these experiments a clay crucible of somewhat larger capacity than the desired lime one is filled with common lampblack, compressing the same by stamping it well down. The centre is then cut out with a knife until a mere shell or lining of lampblack is left firmly adherent to the sides of the crucible, and about half an inch or less in thickness, according to the size of the crucible; this lining is now well rubbed down with a thick glass rod until its surface takes a fine glaze or polish, and the whole cavity is then filled up with finely-powdered caustic lime, and pressed down as before, and a central cavity cut out as before; or the lime-powder may

e at once rammed down round a central core of the dimenions of the intended lime crucible. This lime lining is natually rather soft before being placed in the furnace, but upon
leating agglutinates, and forms a strong and compact crucible,
which is prevented acting upon the outer one by the interposed
him lampblack layer, and at the end of the experiment geneally turns out as solid and compact as those made in the lathe.
Experiments made with such crucibles, even up to dimensions
containing several pounds of metal, have proved them extremely
well suited for these operations, and doubtless similar crucibles
could be made lined with magnesia or alumina as required.
In some cases ordinary blacklead crucibles, lined with powdered lime, magnesia, or alumina, might possibly be found to
answer.


Chemical Balance.—A thin piece of fir-wood, not thicker than a shilling, and a foot long, and $\frac{1}{2}$ in. broad, is divided into twenty parts—that is, ten parts on each side of the middle;

these are the principal divisions, and each of them is subdivided into halves and quarters; across the axis is fitted one of the smallest needles, and fixed to its place by sealingwax. The fulcrum is a piece of brass, the middle of which



ies flat upon the table. The two ends are bent at right angles, to as to stand upright, and are ground flat upon a hone. They tand above the surface of the table only 1-5th of an inch. This talance will weigh the minutest quantity, even the 1200th of a rain. A grain weight is placed on one division, and the object in the other; the proportion of the two will indicate the weight of the latter. The other is on the same principle; the scales re of ivory, from which a small bullet is suspended by a wire; the process of weighing as in the former balance.


Laughing Gas.—Laughing gas (nitrous oxide) is prepared om nitrate of ammonia by heating it in a glass retort, or in a clean dry Florence flask, with a bent glass tube attached. The stem of the retort or tube must dip into a pneumatic trough, on the shelf of which the jar to collect the gas is placed. A solution of 2 oz. of sulphate of iron in one gallon of water, warm, should be used in lieu of water, as it purifies the gas. On the application of heat, the gas passes over into the jar,



driving, of course, the water out. An ordinary gas jarwill do to collect the gas, in the mouth of which a cork, with a piece of glass tubing, with an indiarubber pipe attached, passed through it, is in-

serted. A stopcock must be attached to the pipe to prevent the escape of gas till wanted.

To inhale.—Place the tube in the mouth, empty the lungs of air, stop the nostrils with the fingers, and then inhale the gas, say for a few seconds. The effects vary with the constitution. Combative people should not take it, nor should it be adminis-



tered to females. The source of heat must be withdrawn immediately any white fumes appear in the retort; and care should be taken to control those under the influence of this gas, as they are then utterly unable to do so themselves. The frequent use of nitrous oxide is not

conducive to health. A, retort; B, Florence flask; C, pneumatic trough; D, gas jar. a, spirit-lamp; b, stopcock; c, conducing pipe; d, shelf of strength.

Another mode of preparing.—An ordinary retort, purchasable at any glass-house, is shown at A. The stand for the retort is seen at B, with, C, a screw to fix the ring in which the retort tests; D is the spirit-lamp; E is a bottle containing water, into which the gas rises, having escaped at the mouth of the retort at f, and passes through the water in the trough F into the bottle E, in little bubbles, driving the water out of the bottle as the gas rises to the top; GGGGG is a table of triangular form, supporting the trough F. Into the retort A must be

placed some of the salt called nitrate of ammonia; then set light to the spirit-lamp under the retort or Florence flask; a gas will be given off which will pass down the tube of the retort, under the water, and thence rise into the bottle, forcing the water out as it rises.



This process of collecting gas is called "collecting over water." When the bottle is perfectly empty of water, it is full of nitrous oxide—the gas required; and in taking the bottle from the water, the stopper should be placed in before letting the mouth of the bottle come beyond the surface of the water, or else the gas will escape. As many bottles of gas as are required can be prepared in this manner.

Laughing gas is now used as an anodyne by the dentists.

Nitrate of Potash.—New Process.—It has been ascertained, by M. Condurie, that nitrate of potash may be formed from nitrate of soda, by a very simple process. This consists in mixing concentrated and equivalent solutions of nitrate of soda and chloride of barium, or sulphate of baryta, which precipitates the sparingly soluble nitrate of baryta: washing the latter and boiling it with sulphate of lead, which forms nitrate of lead and sulphate of baryta; and boiling the nitrate of lead with sulphate of potash, which forms the required nitrate of potash, and reproduces the sulphate of lead.

To Clarify Impure Water.—The chemical agent to effect this object is a solution of the neutral sulphate of peroxide of iron (Fe₂, O_3 , \times 3 O_3), which is to be added, in a very diluted state, to the water intended to be operated upon.

The proportion in which the solution of neutral sulphate is to be added to the water, for the purpose of the invention, must be determined by the amount of the impurity contained therein. The suitable proportions must therefore be ascertained, by careful experiment carried on from time to time, if it should be found that the impurity of the water varies. The addition of more or less of the neutral sulphate will not materially affect the process beyond the evident fact, that too dilute a solution of the salt would probably either leave some of the impurities in the water, or the purifying process would be more costly than would be necessary for the complete success of the process.

The water to be purified may be run into a tank or reservoir, and the solution of neutral sulphate added thereto as it runs in, so that the solution may be well mixed with the water to be purified. A short time after the neutral sulphate is added to the impure water it becomes decomposed, and forms, with some of the impurities contained in the water, a basic salt, which is insoluble in water. The solid and insoluble particles of this new salt are precipitated, and, together with the impurities contained in the water, form a sedimentary deposit, from which the purified water may be allowed to run off, leaving behind the sedimentary deposit in the tank or reservoir. A repetition of this precipitation process on other bodies of water which may be run into the same tank or reservoir will cause additional deposits, which, when they have been allowed to accumulate to a sufficient depth in the reservoir, may be collected, and removed from the reservoir from time to time This process has been patented by Mr Edward Newton.

Refining Olive Oil.—The best olive oil, in its crude state, possesses that peculiar bland flavour which fits it for the table, and which appears to arise principally from the quantity of mucilage and water, either held in solution, or mechanically mixed with it. By keeping one or two years in jars, a considerable portion of the mucilage and water subsides, which renders such oil not only cheaper, but better qualified for yield-

ng a greater proportion of pure oil than that which is recently expressed from the fruit. Two or three gallons skimmed from the surface of a large jar that has remained at rest for twelve months or upwards is preferable to any succeeding portion from the same jar, and may be considered the cream of the oil. Having procured good oil in the first instance, put about one gallon into a cast-iron vessel capable of holding two gallons; place it over a slow, clear fire, keeping a thermometer suspended in it: and when the temperature rises to 220°, check the heat, never allowing it to exceed 230°, nor descend below 212, for one hour, by which time the whole of the water and acetic acid will be evaporated. The oil is then exposed to a temperature of 30° to 36° for two or three days (consequently winter is preferable for the preparation, as avoiding the trouble and expense of producing artificial cold). By this operation a considerable portion is congealed; and while in this state, pour the whole on a muslin filter, to allow the fluid portion to run through; the solid, when re-dissolved, may be used for common purposes. Lastly, the fluid portion may be filtered once or more through newly-prepared animal charcoal, grossly powdered, or rather broken, and placed on bibulous paper on a wire frame, within a funnel, by which operation rancidity (if any be present) is entirely removed, and the oil is rendered perfectly bright and colourless.

Refining Lard Oil.—Bancroft's Process.—Stir the oil with a lye of caustic potash of the specific gravity of 1.2. A sufficient quantity has been added when a portion begins to settle down at the bottom. After twenty-four hours the clear oil should be decanted from the soapy sediment and filtered. It may be bleached by using a saturated solution of hydrochloric acid with bichromate of potash.

Petroleum Stove.—A neat and compact arrangement for burning mineral oils, as a substitute for gas, in small cooking-stoves, has recently been adopted in the United States. Although such stoves are not likely to come into use in this country for cooking purposes, they might be found convenient in chemical laboratories, where gas is not readily obtainable. The base of the stove is an open-work cast-iron pediment, standing on three feet, and holding a tin can, from the centre of which rises a wide wick, passing through a drum, which

serves as a base for a funnel-like chimney. The case of this chimney is of tin, lined throughout with fine brass gauze. At the bottom the chimney-case has openings on the sides for the admission of atmospheric air. The outer cylinder is of Russian sheet-iron, and is surmounted by a cast-iron ring, having upward projecting points to sustain the cooking utensil. These points elevate the vessel sufficiently to allow the heat from the flame to circulate above the top of the stove around the sides of the kettle. The can is filled with naphtha, benzine, kerosene, or petroleum, the chimney removed, and the wick lighted The chimney is then replaced, and the stove is ready for operation. If the wick is kept down below the point where the flame would produce illumination, there will be no deposits of carbon on the vessel used for cooking, and the gauze, with the plentiful supply of oxygen through the chimney apertures, will yield intense heat.

Sealing-Wax.—The following are the materials and proportions for making red and black sealing-wax:—

For black—					
Venice turpentine	•••	•••	•••	•••	4 d oz.
Shellac	•••	•••	•••	•••	9 oz.
Colophony	•••		•••	•••	
Lampblack mixed to a			l of tur	pen-	
tine, a sufficient q	uantity				
For red—					
Venice turpentine	•••	•••	•••	•••	2 oz.
Shellac	•••	•••	•••		4 oz.
Colophony	•••		•••	•••	I oz.
Chinese vermillion	•••	•••	•••	•••	I d oz.
Magnesia, moistened v	vith oil	of turp	entin e	•••	1 å dr.
For the best red—		-			-
Venice turpentine	•••	•••	•••	•••	4 oz.
Shellac		•••	•••	•••	7 oz.
Cinnabar	•••	•••	•••	•••	4 oz.
Carbonate of magnesia	ι with c	oil of tu	rpentin	е	i dr.

Any of these would also do for white sealing-wax, by substituting flake white for the lampblack, vermillion, and cinnabar. Adding a small quantity of fine gum benzoin will give them an agreeable perfume.

Lime Water is made by adding 2 oz. of slaked lime to I gallon of water, and shaking it well for a few minutes. After twelve hours the excess of lime will have subsided, and the lime water may be drawn off by means of a syphon as required.

Sugar, Use of Lime in Extracting.—Peligot long ago denonstrated that, owing to the insoluble nature of the compound ormed of lime with sugar, the former substance would be a nost valuable agent in the manufacture of the latter. Peligot's suggestion is now being carried out on a large scale in MM. schrötter and Wellman's sugar-factory at Berlin. The molasses s mixed with the requisite quantity of hydrate of lime and dcohol in a large vat, and intimately stirred for more than half an hour. The lime compound of sugar which separates s then strained off, pressed, and washed with spirit. All the alcohol used in the process is afterwards recovered by distilation. The mud-like precipitate thus produced is mixed with water, and decomposed with a current of carbonic acid, which seffected in somewhat less than half an hour. The carbonate of lime is removed by filtration, and the clear liquid, containing the sugar, evaporated, decolourized with animal charcoal, and crystallized in the usual manner. The sugar furnished by this method has a very clear appearance, and is perfectly crys-It contains, according to polarization analysis, 66 per cent. of sugar, 12 per cent. of water, the remainder being uncrystallizable organic matter and salts. The yield, of course, varies with the richness and degree of concentration of the raw material; on an average, 30 lbs. of sugar were obtained from too lbs. of molasses.

Prince Rupert's Drops.—The properties of unannealed slass are beautifully shown in these scientific toys. They are made by dropping melted glass into water, which takes a long Oval form, tapering to a point at one end. While the body of hese drops will bear a smart stroke from a hammer without facturing, if a portion of the smaller end is snapped off, the whole mass will be broken into an almost inpalpable powder with a violent shock. Professor Faraday used to illustrate the acompressibility of water by placing one of these drops in a hial of water, the concussion from the disruption of the drop hattering the glass bottle. Another interesting experiment ith the same toy is this:—In place of water, fill the phial ith melted resin, and when this has solidified, nip off the end f the glass drop. The bottle is broken as before, and the lass of resin is deeply fissured throughout its length. The rop is found as a kernel, loosely aggregated together, but

easily detached from the resin entire. When broken in pieces, the fragments will be seen to have the form of a cone on an hemispherical base, like some forms of hail.

Printers' Ink.—A capital ink is made as follows:—Put linseed oil into an iron pot capable of holding at least two or three times the quantity introduced, heat it over a fire until a dense vapour arises from it; then, having removed the pot from the fire, apply a lighted match, attached to the end of a stick, to the surface of the oil, when the vapour will inflame; allow it to burn for half-an-hour or more, until on taking out a small quantity of the oil, it is found to be thick and tenacious; the flame is then to be extinguished by putting a cover over the pot, and keeping tightly covered. To 6 quarts of oil thus prepared, add gradually 6 lbs. of black resin, and dissolve it by the aid of heat, then add, in small quantities at a time, 13 lbs. dry yellow soap, cut into slices, and effect the combination by stirring and the application of heat; this is the varnish of which the ink is to be made, and on the careful preparation of which the quality of the ink much depends; this is to be mixed with 21 ounces of ground indigo, the same quantity of ground Prussian blue, 4 lbs. mineral lampblack, and 31 lbs. of the best vegetable lampblack, and the whole ground together into a perfectly smooth and uniform paste.

Ink of different colours is made by mixing the varnish with various dry pigments, such as vermilion, redlead, Indian red, chrome yellow, chrome red, verdigris, Prussian blue, &c. &c. These colours are ground up in the varnish with a stone and muller.

In the above process there is considerable danger of the oil boiling over (which would be a serious affair), and wherever it is practicable, the best plan is to buy it of a good printing ink manufacturer.

To Restore Faded Ink.—Ink faded from age may be revived by damping the manuscript with very weak vinegar, and allowing it to remain damp for an hour or two. Then carefully wash the paper over with a solution of prussiate of potash. If the writing does not appear clear at once, expose the paper to the air for a few hours, keeping the whole slightly damp.

Inks.—Black Ink.—Excellent kind of writing ink may be betained by any of the following methods:—

- 1. (Without galls), Logwood chips $\frac{1}{4}$ lb.; boil in three pints of water down to 2 pints, strain well, and let it cool; then add 25 grains of bichromate of potash. Stir well, add a little gum arabic and a few cloves.
- 2. (The same in different proportions.) Take 1 lb. of logwood chips, and pour on a pint of boiling water; let it stand until all the colour is extracted; then strain it, and add to the solution about a thousandth-part of chromate of potash, or sufficient to make it the proper colour. This mixture does not require the addition of gum or anything else to give it consistency; it will corrode steel pens, and is a fine permanent black.
- 3. Take bruised Aleppo galls, 2 oz.; green copperas, 3 drs.; clean rain-water, 1 quart; and best gum arabic, 3 drs. Mix in a bottle, and it will be fit for use.
- 4. A fine Blue-black.—Take bruised Aleppo galls, 51 oz.; bruised cloves, 1 oz.; sulphate of iron, 1 oz.; sulphate of indigo, in the form of a slightly acid paste (sulphindylate of potash?), 11 oz.; sulphuric acid, 35 minims; cold rain-water, 40 oz. Macerate the galls and cloves in 20 oz, of the water for a week; decant the liquor, and add to the residue of the solid ingredients 10 oz, of the water, with which continue the maceration for four days; then decant as before, and repeat the maceration with the remaining 10 oz. of water for another period of four days. Mix now the whole of the liquors, recovering from the galls all that can be obtained by squeezing them in a cloth, and afterwards filter. To this add first the sulphate of iron, then the sulphuric acid, and lastly the indigo paste. Care must be taken that the indigo does not contain This is also a good copying ink. much free acid.

Indestructible Ink for resisting the action of corrosive substances: Twenty-five grains of copal in powder are to be dissolved in two hundred grains of oil of lavender, by the assistance of a gentle heat, and are then to be mixed with two and a half grains of lampblack, and a half grain of indigo.

6. Copying Inks.—1. Three parts by weight of white glycerine; three parts of purified white honey, best quality; 10 parts of violet, black, or other coloured ink. Mix up well, and leave the mixture to settle two or three days before using. 2.

Four parts by weight of white glycerine; four parts of purified white honey, best quality; ten parts of Robertson's ink; a half part of powdered gum arabic. Add one or two drops of strong solution of bichloride of mercury to prevent deterioration of the ink; stir up well, and leave it to settle for two or three days before using. If it should be found, in taking copies from ink according to recipe No. 1, that thicker characters are produced than those of the original, the proportions of glycerine and honey may be respectively reduced to two parts of each, or another quarter by weight of one part powdered gum arabic may be added.

Indelible Ink.—I. A very good indelible black ink, capable of resisting chlorine, oxalic acid, and ablution with a hair pencil or sponge, may be made by mixing some of the ink made by the preceding prescription, with a little genuine China ink. It writes well. Many other formulæ have been given for indelible inks, but they are all inferior in simplicity and useful

ness to the one now prescribed.

Solution of nitrate of silver thickened with gum, and written with upon linen or cotton cloth, previously imbued with a solution of soda, and dried, is the ordinary permanent ink of the shops. Before the cloths are washed, the writing should be exposed to the sunbeam, or to bright daylight, which blackens and fixes the oxide of silver. It is easily discharged by chlorine and ammonia. 2. A good permanent ink may be made by mixing a strong solution of chloride of platinum with a little potash sugar, and gum to thicken. The writing made therewith should be passed over with a hot smoothing-iron to fix it. 3. Nitrate of silver, 1 to 2 drs.; water, \(\frac{2}{3}\) oz.; dissolve, add as much of the strongest ammonia-water as will dissolve the precipitate formed on its first addition, then further add mucilage I or 2 drs., and a little sap green to colour. Writing executed with this ink turns black on being passed over a hot Italian 4. Asphaltum, 1 part; oil of turpentine, 4 parts; dissolve, and colour with printers' ink. Very permanent, 5. 20 grains of sugar dissolved in 30 grains of water, and the addition to the solution of a few drops of concentrated sulphuric acid; the mixture is then heated, when the sugar is carbonized by the action of the acid. It is said that the writing is not only of a solid black colour, but that the acid resists the action of chemical agents.

Permanent Ink for Writing in Relief on Zinc.—Bichloride of platinum, dry, one part; gum arabic, one part; distilled water, ten parts. The letters traced upon zinc with this solution turn black immediately. The black characters resist the action of weak acids, of rain, or of the elements in general, and the liquid is thus adapted for making signs, labels, or tags which are liable to exposure. To bring out the letters in relief, immerse the zinc tag in a weak acid for a few moments. The writing is not attacked, while the metal is dissolved away.

Blacking.—Liquid Blacking.—1. Boil 1 oz. each of powdered galls, starch, and copperas, and 2 oz. of white Castile soap, with 2 quarts of water; then strain and mix with 3 oz. of fine ivory-black and 6 oz. of molasses. 2. Ivory or bone black, 2 lbs.; neat's-foot oil, 4 oz.; mix, and add 3 quarts of sour beer or vinegar, and a spoonful of any kind of spirit; stir till smooth, add 2 oz. of oil of vitriol, and sprinkle on it $\frac{1}{2}$ dr. powdered resin. Then boil together 3 pints of sour ale with a little logwood, and $\frac{1}{4}$ ounce of Prussian blue, 3 oz. of honey, and 8 oz. of treacle; mix, but do not bottle for two or three days. 3. Ivory or bone black, 8 oz.; brown sugar or treacle, 8 oz.; sweet oil, 1 oz.; oil of vitriol, $\frac{1}{2}$ oz.; vinegar, 2 quarts; mix the oil with the treacle, then add the oil of vitriol and vinegar, and lastly the black.

Paste Blacking.—Powdered bone-black is mixed with half its weight of molasses, and one-eighth of its weight of olive oil, and to this is afterwards added one-eighth of its weight of hydrochloric acid, and one-fourth of its weight of strong sulphuric acid. The whole is to be then mixed up with water into an unctuous paste.

Blacking for Harness.— Take 4 oz. of black resin, and put it in a glazed pipkin over a slow fire; when melted, add 6 oz. of beeswax. When the beeswax is melted, take it off the fire, and add I dr. of Prussian blue in powder and I oz. of lamp-black; stir till perfectly mixed, and add turpentine until it becomes a thin paste, then let it cool. When required to be used, rub it over the harness, and polish with a soft brush.

Piecing Indiarubber.—Make a long bevel on the ends you wish to join (with a sharp, rough-edged knife and water), scrape the bevels rough with the edge of the knife, and when quite dry, give each a coat of indiarubber solution—say I oz. of

rubber, not vulcanized, to 5 oz. of turpentine. When the first coat is dry, give it another; and when that is dry, he may put the two ends together. It is impossible to make a firmer joint than by this method.

Vulcanized Indiarubber.—It is impossible to manufacture vulcanized indiarubber that shall be free from odour, and not liable to become rotten. With regard to smell, a good deal can be done towards making it agreeable by exposure to the atmosphere, and by desulphurization; but the best plan is to scent it in the manufacture, and so disguise the natural smell. With regard to rubber becoming rotten or decomposing, it is a question of manufacture and exposure to the sun's rays, which is the most powerful agent in effecting the decomposition. The red rubber is as liable to become rotten as any other of the same specific gravity. It also has the ordinary odour of vulcanized indiarubber, unless artificially scented.

Bones for Manure, Preparation of.—Illienkof, a Russian chemist, gives the following process, which, it is said, has received the approbation of Liebig:—The author mixes 4000 kilos. of ground bones with 4000 kilos. of wood ashes containing 10 per cent. of carbonate of potash, and adds 600 kilos. of quicklime. This mixture he places in a tank or fosse with water sufficient to make the whole moist. In a short time the bony matter is completely disaggregated by the caustic potash, and the pasty mass formed is then taken from the tank, dried, mixed with an equal weight of mould, and is then ready to be distributed.


Chimney Lamp.—Some chimneys will last for months, while others, apparently as sound and good, will break after a short use, without any apparent cause. The great cause of their being brittle and breaking so easily lies in the material they are made from. There is "shoddy" in glass as well as in cloth. A great many manufacturers make chimneys from silicate of lime instead of silicate of lead. The glass made from the silicate of lime has about the following proportions:—Sand, 100; soda, 45; lime, 20 to 25; nitre, 7 to 10. Lime being a non-conductor of heat, the chimney will not bear the expansion caused by the heat; and if, by gradual heating, the chimney does not break on the lamp, a few times heating

s it so brittle that it breaks with the least effort at cleaning matter how much care is used. The silicate of lead has the following proportions:—Sand, 100; lead, 40 to 50; 20 to 25; nitre, 10 to 15. Lead being very ductile, and d conductor of heat, a chimney made from this formula almost melt before it will crack with the heat. The lated may tell the difference of the chimneys made of different qualities of glass by ringing them; the vibration the lead glass chimney has a sweet, bell-like sound, whilst me glass has a short, harsh sound. The difference of the f manufacture is only, in material, about 8d. per dozen, er point is in annealing; chimneys as a general rule are mealed; under a powerful microscope the difference can en in the glass; the particles in the annealed glass lie close ompact, while the unannealed seem ready to diverge.

ss Chimneys, Why they Break.—The shattering of gas eys is caused by sudden and excessive change of temperaIf, on extinguishing the light, the chimneys are allowed I slowly, the spontaneous shattering complained of will cur. A slit made by a diamond along the whole length


chimney will save the glass such rupture. glasses were, ng taken down, ded, while still hot ashes or such material, us left to cool, less breakage occur.

following proa flame with heat, but not light. G is a



, with air-tight brass top, in which is screwed the valve and T the tube which contains the piece of spongy platina S; Z is a ball of zinc, suspended in the inner vessel I; H is a hole to permit the air to pass to and fro; and D, dilate sulphuric acid; p and p show the relative positions of the same in the two vessels G and I, when the valve is closed. The dilate acid acting on the zinc gives off hydrogen, which, having no way to escape, forces the liquid into the outer vessel, and so prevents any further chemical action until the valve is opened, when the pressure of the atmosphere forces the acid to attain an equal level in both vessels, and so forces the hydrogen out at the nozzle and through the tube, causing the platina to become red hot and ignite the gas.

The "A B C" Gas Meter.—This meter has attached to it an index which performs at once the double duty of giving the consumption of gas and the price thereof. In the sketch is



shown the patent index: 5250 ft. are supposed to have been consumed, and the money payable at the assumed price of 55 per 1000 ft. is £1, 6s. 3d., as indicated. As 16\frac{2}{3} ft. from the 3d. gradually changes to 4d., and so on for every 16\frac{2}{3} ft consumed, till the quantity amounts to 5400 ft., when "7 appears under the shillings' heading and "0" under the pence

the total being £1, 7s., and so on for any larger quantity. This index should prevent all disputes as to cost. It is intended that the registration should be continuous, but that the cash index should, upon each quarterly taking of the state of the meter, be put back to zero, and a ticket of the cash, as well as the number of feet to be charged, to be left with the consumer; the one will be a check on the other. When the price of gas is changed, the index can be altered at a trifling charge, and the meters may have the cash index added for about a crown. The manufactory is at the Meter Company's Works, Johnson's Place, Lupus Street, Pimlico.

Water in Gas-Pipes.—Where the pipes have been properly laid (that is, inclining every way to the meter) it is impossible for the water to remain in gas-pipes. But it is possible that the water may have condensed in the pipes in sufficient quantity to run back into the meter, and raise the water in it above the proper level; in that case the lights would certainly go out. The remedy is to unscrew the plug of the meter, and let the surplus water run out.

Removal of Bisulphide of Carbon from Coal Gas.—This substance imparts a very disagreeable odour to gas, and the sulphur it contains is, during combustion, changed into sulphurous acid, which is injurious to animal life, destroys vegetable colours, &c. The bisulphide is a highly volatile liquid, and its entire removal from gas has been hitherto extremely difficult, if not impossible. Mr Lewis Thomson, however, has found that it may be entirely got rid of by passing the gas, after it has left the hydraulic main, and before it enters the condenser, along with a certain quantity of steam, through a tube or retort of cast iron, heated to about 1200° Fahr. The vapour of water and the bisulphide then mutually decompose each other, sulphuretted hydrogen and carbonic acid being formed. Both these are removed in the usual way.

Royal Blue Dye for Silk.—Into a tub partly filled with cold water pour 2 pints of nitrate of iron; then take I pint of water and $\frac{1}{2}$ pint of muriatic acid; to this add 3 oz. of crystals of tin; when dissolved, pour it into the vessel containing the iron solution, stir well, throw in the silk, and work for some time. In another tub dissolve 8 oz. of yellow prussiate of

potash, and add to it 2 oz. (by measure) of vitriol; the silk is wrung out dry from the iron solution and put directly into the prussiate solution, in which it is worked for some time. It is then washed in cold water with 2 oz. of alum dissolved in it. If the dye is not dark enough, instead of being washed in the alum-water, the silk may be put into the iron again and through the prussiate in the same way, and worked for about the same time as before, but add a little more prussiate. Deeper shades are obtained by using more iron and tin, or by giving several dips. The silk must be perfectly freed from grease before commencing the dyeing operation. The mixture above recommended will dye 5 lbs, weight of silk.

Dyes for Woollens.—For 60 lbs. of woollen yarn take 2 lbs. of flavine, 6 lbs. of alum, 1 lb. of tin crystals. Dissolve in boiling water. Then dissolve separately 4 oz. of red prussiate of potash, and add it to the above. Then add $4\frac{1}{2}$ lbs. extract of indigo and 12 oz. oxalic acid. Dye in the usual manner. This makes a full green. For deep scarlet take $3\frac{1}{2}$ gallons of cochineal liquor, containing $1\frac{1}{2}$ lbs. of cochineal per gallon, 36 oz. of starch. Boil, and add $\frac{1}{2}$ pint of mixed berry and fustic liquor at 15° , 1 lb. bin-oxalate of potash, 3 oz. of crystals of tin, and 12 oz. of bichloride of tin at 100° .

For Black Silk and Wool.—Silk to be dyed black must be first washed free from grease, and then gently boiled for half an hour in a dilute solution of nitrate of iron. Take out and rinse in cold water, and then boil with logwood of half the weight of the silk itself for one hour. To dye wool black, boil it with its own weight of logwood for an hour, and then add sulphate of iron in the proportion of about one pound to every thirty of wool.

For Ostrich Feathers, &c.—For ostrich feather dyeing, first expose them to sulphur-vapour to bleach them, then dye. Black.—Immerse for two or three days in a bath (hot at first), of logwood eight parts and copperas or acetate of iron about one part. Blue.—The indigo vat. Brown.—Any brown dyes for silk or wool. Crimson.—A mordant of alum followed by a hot bath of Brazil wood and a weak one of cudbear. Pink or Rose.—Safflower and lemon juice. Plum.—Red dye followed by an akaline bath. Red.—Alum mordant and a hot Brazil-

wood bath. Yellow,—Alum mordant turmeric bath. Other shades by mixtures.

Aniline Dyes.—The colouring-matters produced from aniline and analogous matters are all, with the exception of the Fuchsine and Perkins's violet, insoluble in water, and many attempts have been made to substitute a less costly solvent for the alcohol hitherto employed. M. Gaultier de Claubry, a French chemist, has recently taken out a patent for a method of accomplishing this. He says that a great number of substances, such as gum, mucilage, almond, and other soap, glucose, dextrine, the gelatinous portion of various feculæ, of lichens, and of fuci, render water a solvent of such colouringmatter, but that the best and most economical results are to be obtained by means of decoctions of the bark known as Panama (Quillaia saponaria), or of the root of the Egyptian soap-plant (Gypsophila strutium). The Saponaria officinalis, he adds, may be employed, but is less energetic in its action than the The solutions are obtained by pouring the boiling liquors upon the colouring-matter in powder, agitating, decanting, and, if the solution be not complete, repeating the process. The solutions thus obtained may be reduced to extracts by evaporation, but continued ebullition, especially if the water contain sulphate or carbonate of lime, may injure the colours. A better method, according to M. Gaultier de Claubry, is to triturate the powdered colouring-matter with the extract of Gypsophila strutium, and then afterwards to add water by degrees: but as the reds dissolve more readily than the blues, it is necessary afterwards to mix all the products together. solutions obtained by means of the extracts above-named are said to work readily with gum, dextrine, and albumen, separately or combined. The advantages claimed for the process by the patentee are economy, perfect unity of tints, which will not soil linen by contact, and suppression of inconvenience caused to the dyers by the use of alcohol or wood-spirit. connection with the latter, it should be mentioned that the attempt to substitute it for alcohol has been defeated by the workmen, who have, in many instances, refused to use it on ecount of its effect on their health.

To Colour Straw Black.—The quantities are intended for wenty-five hats or bonnets. The articles are kept for two

hours in a boiling decoction of 4 lbs. of logwood, 1 lb. of sumach, and of 5 oz. of fustic; afterwards they are dipped into a solution of nitrate of iron, then well rinsed with water, and when dry, are painted over with a solution of gum or dextrine. The iron liquor, as well as the other ingredients, are kept by all dealers in dye-stuffs.

Printed Cottons, to Wash.—Infuse three gills of salt in four quarts of water; put the cotton goods in while hot, and leave till cold, and in this way the colours are rendered permanent, and will not fade by subsequent washing.

Bleaching-Powder.—When hydrate of lime, very slightly moist, is exposed to chlorine gas, the latter is eagerly absorbed, and a compound produced which has attracted a great deal of attention: this is the bleaching-powder of commerce, now manufactured on an immense scale, for bleaching linen and It is requisite in preparing this substance, to cotton goods. avoid with the greatest care all elevation of temperature, which may be easily done by slowly supplying the chlorine in the first The product, when freshly and well prepared, is a soft, white powder, which attracts moisture from the air, and exhales an odour sensibly different from that of chlorine. soluble in about ten parts of water; the unaltered hydrate being left behind, the solution is highly alkaline, and bleaches feebly. When hydrate of lime is suspended in cold water, and chlorine gas transmitted through the mixture, the lime is gradually dissolved, and the same peculiar bleaching compound produced.

Waterproofing with Paraffin.—The materials which in modern times were first employed for waterproofing were beeswax and the various kinds of drying oil, especially linseed oil, which were rendered more siccative by boiling or some other of the processes usually employed for that purpose. About forty years ago caoutchouc was first successfully used, for rendering fabrics and other materials waterproof, by the late Mr Charles Macintosh; and after an interval of about twenty years, gutta-percha was first imported into this country, and immediately applied for similar purposes. In 1832 paraffin was discovered by Reichenbach in the course of his admirable researches on wood and coal tars; he, however, only succeeded in obtaining it in very small quantity, so that for a long time

it was only known as a chemical curiosity. It is to Mr James Young that we are indebted for the production of this material on an industrial scale, by his process which he patented nearly fifteen years ago.

A few years ago a patent was taken out by Dr Stenhouse for employing paraffin as a means of rendering leather waterproof, as well as the various textile and felted fabrics; and since then additional patents have been granted for an extension of, and improvement on the previous one, which consisted chiefly in combining the paraffin with various proportions of drying oil, it. having been found that paraffin alone, especially when applied to fabrics, became to a considerable extent detached from the fibre of the cloth after a short time, owing to its great tendency to crystallize. The presence, however, of even a small quantity of drying oil causes the paraffin to adhere much more firmly to the texture of the cloth, from the oil gradually becoming converted into a tenacious resin by absorption of oxygen.

In the application of paraffin for waterproofing purposes, it is first melted together with the requisite quantity of drying oil, and cast into blocks. The composition can then be applied to fabrics by rubbing them over with a block of it, either cold or gently warmed, or the mixture may be melted and laid on with a brush, the complete impregnation being effected by subsequently passing it between hot rollers. When this paraffin mixture has been applied to cloth such as that employed for blinds or tents, it renders it very repellent to water, although still pervious to air.

Cloth paraffined in this manner forms an excellent basis for such articles as capes, tarpaulins, &c., which require to be rendered quite impervious by subsequently coating them with drying oil—the paraffin in a great measure preventing the well-known injurious influence of drying oil on the fibre of the cloth. The paraffin mixture can also be very advantageously applied to the various kinds of leather. One of the most convenient ways of effecting this is to coat the skins or manufactured articles, such as boots, shoes, harness, pump-buckets, &c., with the melted composition, and then to gently heat the articles until it is entirely absorbed. When leather is impregnated with the mixture, it is not only rendered perfectly waterproof, but also stronger and more durable. The beneficial effects of

this process are peculiarly observable in the case of boots and shoes, which it renders very firm without destroying their elasticity. It therefore not only makes them exceedingly durable, but possesses an advantage over ordinary dubbing in not interfering with the polish of these articles, which, on the whole, it rather improves. The superiority of paraffin over most other materials for some kinds of waterproofing consists in its comparative cheapness, in being easily applied, and in not materially altering the colour of fabrics, which in the case of light shades and white cloth is of very considerable importance.

Waterproofing for Rick Cloths.—Plunge the fabric into a solution containing 20 per cent. of soap, and afterwards into another solution containing the same percentage of sulphate of copper; wash the fabric, and the operation is finished. An indissoluble stearate, margarate or oleate of copper, is formed in the interstices of the tissue, which thus becomes impervious to moisture. This process is particularly recommended for rick cloths, awnings, &c.

Waterproofing Cotton Fabrics.—If for black work, mix enough lampblack and boiled oil to cover the whole surface; if yellow, use yellow ochre; add about ½ lb. of driers for each gallon of oil. Give the cloth two or three coats of the above; and if, after the last coat is dry, it should remain sticky, give it a coat of the following mixture:—Boil 2 lbs. of shellac in 4 quarts of water, and add a little ammonia; when cold, add lampblack or yellow ochre as required.

Textile Fabrics, to Render Fireproof.—A very excellent method of rendering textile fabrics fireproof without injuring their colour, whatever it may be, consists in dipping them in a solution containing 35 per cent. gum, 35 per cent. starch, and 30 per cent. of the compound which is obtained by dissolving superphosphate of lime, decomposing the salt by excess of ammonia, filtering, purifying with animal charcoal, concentrating by evaporation, decomposing with 5 per cent. silex, evaporating to a crystalline mass, and then drying and pulverizing.

Electrotyping.—Wash article or mould over with a solution of acetate of copper, or nitrate of silver in alcohol, and then, without allowing it to dry, expose to the action of sulphuretted hydrogen gas. A sulphuret is formed which is an excellent

onductor of electricity; and, when dry, may be put into the opper bath. Minute animals and delicate objects may be eadily coated in this way.

To prepare the gold solution, make a saturated solution of cyanide of potassium as before, and pour off this solution upon the contents of a 15-grain bottle of chloride of gold until the latter is quite dissolved; then dilute with water in the same ratio as in the silver electrolyte—that is, one part of the solution of chloride of gold in cyanide of potassium, with three parts of water. This solution filtered forms the gold electrolyte.

Mounting the battery for plating or gilding is the next opera-If the article or articles to be plated or gilt are small, a single element will, in all probability, be sufficient to produce the requisite amount of electric current. Place the zinc in the middle of the tumbler, then insert the earthenware cell in the zinc, and holding it down with the left hand, pour into the tumbler dilute sulphuric acid until it reaches to the upper rim of the cell. The cell itself is next filled with concentrated nitric acid. The plate or strip of platinum is finally inserted in the nitric acid. The zincs are generally amalgamated when you buy them; if this operation has been omitted, you can do it yourself by rubbing over the moistened surfaces a cloth dipped in nitrate of mercury. Place one connecting-wire in the zinc binding-screw, and the other in the platinum binding-screw. The zinc wire is the negative pole, and is frequently called the "zincoid;" whilst the platinum wire is the positive pole, and is denominated the "platinoid," At the end of the negative wire the object to receive the deposit is placed by suspension on a hook, or otherwise, in metallic contact, and then immersed in the electrolyte. On the end of the positive wire either the piece of silver or of gold is fixed; if the electrolyte be silver, the silver plate is attracted, and the gold plate in the other case. The silver and the gold coin can be beaten out into thin plates for the purpose, and then soldered to their respective wires, or attached by drilling holes and then suspending each on a hook. The objects to be gilt or plated must be thoroughly cleaned of all impurities, by means of a brush and rouge (sesqui-oxide of iron); and they must then be dipped in a solution of salts of tartar to remove grease, and finally washed in water. So prepared, they are suspended on the negative hook and immersed in the electrolyte. The plate on the

positive hook is likewise immersed in the same solution, and brought near to the object, but on no account in contact with it. The electric current now circulates, because the circuit is complete, passing along the positive wire to the plate at its end, where it comes in contact with the metallic solution between it and the object connected with the negative pole. tion, consisting of water and a metallic salt, is decomposed by the circulating current in the following manner; -The water is decomposed into its elements oxygen and hydrogen, which being separated, rush in opposite directions, the hydrogen towards the object, whilst the oxygen affects the positive pole or plate; and the metallic salt, infinitesimally divided by solution, is also broken up or decomposed into its elements; thus the chloride of silver is separated into silver and chloring the latter affecting the positive pole, whilst the silver is deposited on the negative pole. Take out the object from time to time and examine it. If the coating is purely white (if silver), or purely yellow (if gold), the operation is going on right, and may continue until the requisite amount of deposition has been obtained. By this means the metallic film thus deposited may be made of any thickness whatever. Sometimes, however, this metallic film is not pure of its kind; on the contrary, it oftentimes granular or crystalline, and at others quite black To prevent these irregularities is the electrotyper's chief cartile and much experience and patient study are required before best conditions can be obtained at once. Changing the dis tance between the two poles, moving the positive pole about increasing or diminishing the thickness of the positive win warming the electrolyte, diminishing or increasing the number of elements in the circuit; these and other operations are at time necessary; when to perform them experience alone can teach As soon as the object has received the required thickness deposit, it is taken out of the electrolyte, washed, dried, and burnished on those parts which are to appear brilliant, while tools are sold for such purposes; but, in case of need, a dopobject, rubbed on with a tooth-brush or wash leather.

The operation of plating or gilding over, the next care is the apparatus. The dilute sulphuric acid, once used, is through away; but the nitric acid is poured back into the stock-bottle, with

r future use. The latter has, however, undergone decomosition during the operation, and has become diluted with ater formed by the elements liberated during the circulation if the electric current through the sulphuric acid and nitric cid; and in consequence of this gradual dilution the nitric cid becomes in course of time too much impoverished for use, and must be replaced with concentrated acid. Place the orous earthenware cell in a dish of water when it is emptied, a also the zincs for an hour or two; then remove them to rain dry.

To Electro-Gild without a Battery.—Take $\frac{1}{2}$ oz. of nitric ad $\frac{1}{2}$ oz. muriatic acid; dissolve in these 1 dwt. of gold, gently vaporate until it crystallizes, then add 2 oz. of cyanide of otassium dissolved in 15 oz. of water. The article to be gilded 5 to be simply put in the solution, and a piece of *clean* zinc laced on it, and moved from one spot to another until it is ufficiently covered with gold.

Gilding on Steel.—In any quantity of nitro muriatic acid *qua regia) dissolve gold or platina, until, on the application f heat, no effervescence ensues. Evaporate the solution thus rmed to dryness by means of a gentle heat; then dissolve e dry mass thus formed in the least possible amount of water. ake the instrument known by chemists as a separating funnel. hich may contain a liquid ounce; a quarter fill it with the luid, and the other three parts fill with the best sulphuric The two liquids should not mix. Then holding the be in a horizontal position, turn it round with the finger and When the ether has become impregnated with the ald or platina, which may be known by its change of colour, place it in a perpendicular position, and having stopped up e orifice with a cork, let it stand for twenty-four hours. e end of this time the liquid will be divided into two parts. we darkest coloured being below. Take out the cork and let be dark liquid flow off, and stop the tube immediately with ie cork. What remains in the tube is the gilding liquid. he article to be gilded must be perfectly free from rust or rease, and have received the highest possible polish. tocess of gilding is as follows:—A vessel of glass or unglazed are having been procured, it should be filled nearly to the with the gilding liquid. The article should be dipped in

this for a moment, and then be plunged into clear water and well rinsed. After having been thoroughly dried with blotting-paper, it should be placed in a temperature of 150° Fahr. until it is heated throughout, and then polished with rouge and washleather; or, better still, be burnished. Take care that the muriate of gold is quite free from excess of acid, and be careful to follow exactly the above directions in every particular, as only by doing so can perfect success be ensured.

Electro-Gilding for Copper Chains, &c.—Take a solution of nitro-muriate of gold (gold dissolved in a mixture of aquafortis and muriatic acid), and add to a gill of it a pint of ether or alcohol, then immerse your copper chain in it for about fifteen minutes, when it will be coated with a film of gold. The copper must be perfectly clean, and free from oxide, grease, or dirt, or it will not take on the gold.

Gilding on Glass.—Glass can be gilded in two ways, by means of fire, and by an adhesive varnish. It is gilded by fire, by tempering powdered gold with borax and gum-water. mixture is applied to the surface of the glass with a soft pencil brush; when dry, the article is put into a stove heated to the temperature of an annealing oven; the gum burns off, and the borax cements the gold firmly to the article by vitrification; after this process, the gold on the article is burnished, ing is also effected by an adhesive drying varnish, which is prepared by dissolving gum anime in drying linseed oil. mixture is diluted with some oil of turpentine, and applied as thin as possible to the parts that are to be gilded. the article is to be placed in a stove or near a fireplace, till it is warm enough to almost burn the fingers when handled, at which temperature the varnish is glutinous, and a piece of gold leaf applied will instantly adhere. When nearly cold, it is burnished; but care must be taken to intervene a piece of very thin India paper between the gold and the burnisher. size is also used as an adhesive substance. The requisite burnishing-tools can be bought at any oil and colour shop.

Below we give four methods of performing this operation:-

1. Take 2 oz. isinglass, and dissolve in just sufficient water to cover it; when dissolved, add 1 quart rectified spirits of wine and 1 quart water. This size must be kept in a bottle well corked. Thoroughly clean and polish the glass, and lay it on a perfectly

level table. With a brush dipped in the size flood the glass over, and then with a tip carefully lay on the gold leaf, which will instantly adhere to it. Then place the glass on its edge to dry, and leave it for twenty-four hours. On a piece of paper draw the required pattern, and with a pricker pierce holes along the outline. Then lay this on the gold surface, and dust some powdered whiting over it, so that it may penetrate the holes, and leave the pattern on the gold underneath. Carefully remove the paper, and fill in the outlines of the design with gold size, mixed with orange chrome, and thinned with boiled oil and turpentine. When quite dry, remove the surplus gold with a piece of cotton wool dipped in water, and back the glass with the ground colour.

2. First sketch on paper the exact size and shape of the figures or letters required; then prick holes (in the outlines) through the paper with a pin; take the paper and cover the glass on the front side with it; now dust the paper over with whiting, so that it goes through the holes in the paper on to the glass; remove the paper, and coat the back of the glass with gum size, and before the gum is dry take gold leaf and place it on the gum size, so that the leaf covers the dust-marks on the glass. Do not be particular about the shape of the gold leaf then; only see that the letters are covered. When dry, paint the exact shape of the letters on the back of the gold leaf with gold size, to which has been added some chrome yellow. When perfectly dry, take a little cotton wool and water and wash off all the superfluous gold leaf. You can then shade or back the letters with any colour.

3. Make a mixture of powdered gold, borax, and gum arabic in water, and brush the device upon the glass, earthenware, or porcelain with a hair pencil dipped in the above mixture; then expose the article to heat in an oven or furnace, by which means the gum is consumed and the borax vitrified, cementing the gold to the glass or earthenware, after which it may be

burnished.

4. Breathe on the glass, apply the gold leaf, then hold a hot iron at the back a small distance off till all the moisture is dried out; it will then assume a bright appearance. Then immediately paint on the back of it, or it will get dim. By this process no size, or anything of the kind, is needed, but only a little dexterity.

Silvering Globes, Tent Mirrors, &c .-- 1. The mirror to be silvered is suspended, face downwards, in a silver bath prepared thus: -A large flat shallow vessel of glass or porcelain is provided to contain the solution. One hundred and fifty grains of nitrate of silver are dissolved in 6 oz. of distilled water, and to this is added pure liquid ammonia, drop by drop, until the precipitate is re-dissolved. caustic potash are dissolved in 50 oz. of rain-water, and 15 oz, of this solution are added to the ammoniacal solution, when a brown-black precipitate is thrown down. Ammonia is again added, drop by drop, until this precipitate is just re-dissolved; and 29 oz. of distilled water are then added to the whole. To this mixture is again added, drop by drop, stirring with a glass rod, a strong solution of nitrate of silver, until a precipitate which does not re-dissolve is formed. Previous to immersing the mirror, one part by weight of powdered milk-sugar to ten parts by measure of distilled water must be prepared in a separate vessel, and filtered until a clear solution is obtained. Then, to ten parts by measure of the silvering solution must be added one part by measure of the milk-sugar solution, and, finally, 50 oz. of the compound solution will be sufficient to silver a speculum 9 inches in diameter. The glass surface should be made chemically clean by using whiting-cream, free from grit, and rubbing it off, when dry, with the purest cotton; it should then be wetted with dilute nitric acid, and afterwards washed with distilled water. To suspend the mirror, a circular block of wood is firmly cemented to its back with marine glue or pitch, and three pins inserted at equal distances, to which the strings may be fastened. On lowering into the bath, care must be taken that no air-bubbles intervene, that the speculum be not deeper in the liquid than half its thickness, and that two inches at least intervene between the mirror and the bottom of the vessel It should remain in the bath for four hours, by which time the process will be completed; it is then removed, washed with distilled water, and placed to dry. It is now ready for polish-Rub the surface gently, first with a clean pad of fine cotton wool, and afterwards with a similar pad covered with cotton velvet, which has been charged with fine rouge.

2. The following is one of the cheapest and most durable methods:—Make an alloy of 10 oz. bismuth, 6 oz. lead, and

4 oz. tin; put a portion of this alloy into the globe, and expose it to a gentle heat until it melts; then turn the globe slowly round, so that an equal coating of the alloy is spread over the whole surface. This, when cold, will harden, and cannot be surpassed for durability.

- 3. Take I oz. of clean lead, I oz. of fine tin, and melt them together in a clean iron ladle; then immediately add I oz. of bismuth, skim off the dross, take the ladle from the fire, and before the mixture sets add IO oz. of quicksilver, stirring all well together.
- 4. The "Humid Process," as it is called, is as follows:—Four solutions are to be prepared—No. 1. Ten grammes of nitrate of silver in 100 grammes of distilled water. No. 2. An aqueous solution of ammonia standing at 13° of Cartier's aerometer. No. 3. Twenty grammes of pure caustic soda in 500 grammes of distilled water. No. 4. Into a solution of common white sugar there is to be poured one cubic centimetre of nitric acid at 36°; it is then to be boiled for twenty minutes to produce interversion. There is then to be added 50 cubic centimetres of alcohol at 36°, and as much distilled water as will bring the whole to 500 cubic centimetres. Into a flask holding about 200 cubic centimetres there is to be poured—

12 cubic centimetres of solution No. 1.

8 ,, ,, No. 2.

20 ,, ,, No. 3.

50 ,, of distilled water.

The liquid should remain perfectly limpid. This solution is allowed to repose for twenty-four hours. Now as to its application. The surface of the glass to be silvered must be scrupulously cleaned, and then passed over with a ball of cotton wet with nitric acid at 36°, and finally washed with distilled water, and drained from this and placed upon supports at the surface of a bath composed of the silvering fluid as above, to which has been added one-tenth or one-twelfth of its bulk of solution (No. 4). Under the influence of diffused daylight, the surface to be silvered (immersed in the bath) is seen to become first yellow, then brown, and in two to five minutes the silver will be found to be uniformly spread over the glass; in ten or fifteen minutes the coat will be found to be thick enough. The glass is then to be washed in common and afterwards in distilled

water, and left to dry in free air. When dry, the surface presents a perfect metallic polish, covered, as it were, by a thin veil. It is then polished with chamois leather and the finest rouge; a metallic surface of the utmost brilliancy will be the result. The gramme = 15.434 grains. Cubic centimetre = 165 of a cubic inch.

Silvering Brass.—Brass and copper are the only metals that can be silvered without a battery. The process of silvering brass is thus described :-- In 8 oz, of water dissolve 2 oz. of cyanide of potassium, and in the same quantity of water I dr. of nitrate of silver. Into the vessel containing the silver throw about half a spoonful of common salt; stir this well with a glass rod until the silver is precipitated. Mix a little salt and water, and add a few drops to the solution after it has had time to settle. If any cloudiness follow, more salt must be added. When the addition of salt water has ceased to have any effect, carefully pour off the water and preserve the deposit. Wash this deposit two or three times in boiling water, and then carefully dry. Place this powder in a vessel, and pour on it about a pint of water, and add the cyanide solution about 102 at a time until the precipitate is dissolved, then add enough water to make about a quart. While adding the cyanide solu-If when dipping the article into this solution tion stir well. the silver deposits too quickly, more water must be added; if it coats very slowly, the solution must be strengthened with more precipitate. This must be also done whenever the solution becomes weak. The solution when in use should be kept at a temperature of from 60° to 70° of heat. After polishing and burnishing, the article silvered should be as brilliant and durable as can be wished.

Silvering-Powder for Coating Copper.—Take 60 grains of nitrate of silver; 60 grains of common salt, and 7 drs. of cream of tartar. Mix them, and moisten with water, and then apply.

Silvering Mirrors.—The process of employing a layer of tin-foil and mercury, commonly but falsely called "silvering" is as follows:—A sheet of tin-foil corresponding to the size of the plate of glass is evenly spread on a perfectly smooth and solid marble table, and every wrinkle on its surface is carefully rubbed down with a brush. A portion of mercury is then

poured on, and rubbed over the foil with a clean piece of very soft woollen stuff, or a hare's foot, after which two rules are applied to the edges and mercury poured on to the depth of a crown piece, when any oxide on the surface is carefully removed, and the sheet of glass, made perfectly clean and dry, is slid along over the surface of the liquid metal, so that no air, dirt, or oxide can possibly either remain or get between them. When the glass has arrived at its proper position, gentle pressure is applied, and the table sloped a little to carry off the waste mercury, after which it is covered with flannel and loaded with heavy weights. In twenty-four hours it is removed to a wooden table, and further slanted; and this position is progressively increased during a month, until it becomes perpendicular.

Picture-Frame Stain.—To stain a picture frame black, procure some logwood chips, and boil them; give your frame a coat of the boiling liquid. You will find this generally raise a roughness on the wood; let it dry, and then use sand-paper; then give it another coat of the warm liquid, and before it dries give it a coat of iron liquor. If you want a good job, put a little ivory-black in your polish.

To Gild Picture Frames.—Provide yourself with the following articles: a cushion, made by covering a board of about 8 in. square with a double thickness of flannel, and over that a piece of buff leather, and fastening it tight round the edges; a palette knife, for cutting the leaves into the requisite sizes; a tip, a fitch pencil, a ball of cotton, and a large camel's-hair brush. The frame intended to be gilt should first be well sized, and then done over with seven or eight coats of size and whiting, so as to cover it with a body of considerable thickness. Having got a sufficient quantity of whiting on, it must be carefully cleaned off, taking care to free all the cavities and hollows: it is then to receive a coat of size, and be left till nearly The work being thus prepared, place it a little declining from you, and having ready a cup of clean water, and some hair pencils, moisten a part of the work, and apply the gold leaf by the tip to the part. The gold will immediately adhere, and is then to be pressed down by the ball of cotton. Proceed thus until the whole is finished, leave by for twenty-four hours, and then burnish the prominent parts with an agate burnisher.

Gilding and Plating.—The following instructions are condensed from an article by Professor Towler, a capable and experienced instructor:—

The first thing required is a galvanic battery. great variety of galvanic batteries to be had, but we prefer a Grove's battery. A single element consists of a cylinder of zinc, a thin plate of platinum, a tumbler, a cell of porous or unglazed earthenware, two binding-screws, two solutions (dilute sulphuric acid and concentrated nitric acid), two connectingwires, and a plate of silver and one of gold (a two-shilling piece for one, and a gold dollar for the other). Two of these elements will be sufficient for almost all ordinary operations of gilding. and sometimes only one is required. The zincs, plates of platinum, porous cells, binding-screws, tumblers, and connectingwires, can be bought already prepared for electrolyte operations and ready for mounting. Mix one fluid ounce of commercial sulphuric acid with ten fluid ounces of water for one solution. The strongest aquafortis or commercial nitric acid is suitable for the other solution.


In the second place a silver and a gold solution have to be prepared, and kept on hand ready for use. Each of these solutions is denominated an electrolyte, and the art of decomposing such a solution by means of an electric current is known by the name of electrolysis. To prepare the silver solution, take a solution of nitrate of silver, and add to it a solution of common salt as long as any white precipitate is produced. Perform this operation in a darkened room, because the white precipitate (chloride of silver) is very sensitive to light, thereby changing into a violet-coloured powder, which is insoluble in the fluid into which it is subsequently mixed. As soon as the precipitate has completely subsided, pour off the supernatant fluid, and add to it a few drops of the salt solution: if no milkiness is produced, the silver has all been removed as chloride, and consequently the fluid may be thrown away as useless. Mix the white chloride with rain-water, and stir the mixture with a glass rod, and allow the precipitate to settle again; this is called washing the precipitate. When the precipitate has subsided, the fluid part is poured off, and the residue is again washed. This operation is repeated several times, and the chloride, finally separated by decantation from the wash-water, is ready for the next treatment. Make a saturated solution of cyanide potassium in rain-water—that is, add lumps of the cyanide s long as it is dissolved, and finally a small part is left undisslived. The water is then saturated with the salt. Pour this aturated solution of the cyanide upon the chloride of silver, nd keep pouring and stirring until the chloride is entirely issolved. Filter the solution, and dilute as follows:—Silver lectrolyte: saturated solution of the chloride of silver in yanide of potassium, 4 oz.; rain-water, 12 oz. The solution s then ready for use.

Picture-Frame Making.—The following is a simple and asy plan for making picture frames. Take a common deal ward 9 in. wide and 1 in. thick; cut it into four slips, run a abbit plane on one edge, for the glass, picture, and back to fit nto. Ct it into lengths, according to the size of the pictures; wuntersink the sides into the top and bottom; one screw in ach angle, put in from the back, will keep them firmly together. A cord round the projections at the top will serve to lang the picture.

Deal may be stained a dark oak-colour, by giving it two or bree coats of a solution of 1 oz. bichromate of potass, and 2


2. of bluestone, in 2 oz. of water; fter which, apply lain drying oil, and nish with copal arnish. The oil eepens the colour and brings out the atural graining.

For clamping picure frames, proeed thus: — Cut ur pieces as No.1; rill a hole through s shown; cut a nall channel as



nown; cut two pieces as No. 2 and 3 six inches long; drill No. half-way through for end of screw, the same as the ordinary amp. No. 3 is to be tapped to fit screw. In addition so small holes same size as through angles and as shown.

Get a length of catgut about $\frac{1}{6}$ in. thick. Put it through the angles and No. 3. Before glueing, see that the catgut is about the size of the frame. Then glue and put the angle-pieces on and screw up as shown in No. 4. They can all be made of beech I in, thick. This plan is expensive, and rather slow. Prints must have a glass over them, and so be secured from the entrance of dust, flies, and damp. The glass of each frame is laid in with a composition like plaster, blackened to suit the dark frames; and, besides this, glass is pasted all round inside to the frame with a narrow strip of paper. Within the glass is the gilt moulding, which thus serves to keep the print and the glass a quarter of an inch apart. The print, being attached by its edges, or its corners, to the backboard, is put in over the gilt moulding, and the whole of the back securely pasted over with strong paper. The only prints that turn yellow are those pasted on to canvas stretchers. This is probably caused by the pasts, The paste to be used for all prints and drawings should be



shoemakers' paste, which has alum in it; and besides, not breeding insects, will attach paper to wood thoroughly. The putty, paste, &c., used must be quite dried after each part of the process of framing, before proceeding to paste up the back The print itself must be also thoroughly dried. The best composition for picture-frame cornics

is composed of size and whiting. The best size is made by well-soaking buffalo skin, and then boiling it to the consistency of jelly. For touching up old frames the common size will do

Compo Ornaments for Picture Frames.—In a quart of water boil 3½ lbs, of the best glue, and in 3 gills of raw

linseed oil melt $1\frac{1}{2}$ lbs. of white resin. When these ingredients are well boiled, let them simmer together in a large vessel for about half an hour, stirring the mixture, and taking care it does not boil over. When this is done, pour out the mixture into a large quantity of finely-ground whiting, and roll it to the consistency of dough, and it is then ready for use.

Composition Ornaments.—Dissolve ½ lb. of glue in 2 quarts of water. Boil together 1 lb. of resin, ½ gill of Venice turpentine, and 1 gill of linseed oil. Put these two mixtures into one kettle, and boil together, stirring well until all the water has evaporated; then add finely-powdered whiting until the mass has attained the consistency of putty. This composition becomes hard when cold, but when warm may be readily moulded to any pattern required, and is more durable than wood.

Gilding Organ Pipes.—After being perfectly cleaned, the pipes should be painted over with flat lead colour finely ground, mixed with plenty of patent driers, and a little boiled linseed oil. (Two coats may be given, the first to be thoroughly dry before the second is applied.) After the second coat is thoroughly dry, the surface must be covered with gold size (which can be purchased ready prepared at the colour-shops, or made as directed (page 286). When the gold size is nearly dry, or in a "tackey" or slightly sticky state, the gold leaf must be applied carefully, and pressed down evenly with a soft ball of cotton wool. After a short time all the loose particles of gold may be removed by carefully rubbing with the ball of cotton wool. The coloured patterns are produced by the following method: -Sheets of glazed paper, having the patterns it is desired to colour cut out, are placed Over the gilded parts, and oil colour dabbed carefully through with a soft brush. The colours should be mixed with patent driers, turps, and very little oil, to make them flat. If two or more colours are desired in the pattern, papers for each different colour in the pattern must be cut out.

Imitation Silvering or Gilding.—A small quantity of melted tin is poured into a box, which is then closed and violently shaken, so as to reduce the tin to a fine powder. This powder is mixed with a small quantity of size or thin glue. The article

to be gilded or silvered is then coated and allowed to nearly dry. Burnish with an agate burnisher, and, if required to imitate silver, coat with seed lac varnish; but if to imitate gold, colour the varnish with a mixture of gamboge and anatto. The chief difficulty is to obtain the proper proportion of size to tin; for if too much size is used, the burnisher will produce no effect; and if too little, the tin will crumble off.

Mosaic Gold.—To make what is termed "mosaic gold," heat together in a crucible or iron ladle a mixture of six parts of tin, three of mercury, three of sal-ammoniac, and about the same of flowers of sulphur. Most of these will be sublimed by the heat, and a solid shining substance of the appearance of gold will remain.

Bronze and Bronzing.—Bronzing is of two kinds: the purpose of the one is to cover objects of all kinds with a coating which shall give them the appearance of bronze, while the other kind of bronzing modifies the surface of various metals, and protects them from the action of the air. The operation varies according to the nature of the body to be bronzed, as explained below.

Bronzing Plaster Casts.—To cover plaster casts, statuettes, &c., with a very durable green coating, which will protect them against atmospheric agencies, and give them a colour resembling antique bronzes, employ ferro-cupreous soap, which is prepared thus:—A soap is made with linseed oil and caustic soda; a concentrated solution of sea-salt is added, and the whole evaporated until the soap begins to float in grains on the surface; it is then filtered through a metal strainer, and the grains of soap thus collected are dissolved in boiling water, and the solution again filtered to remove impurities. On the other hand, dissolve in hot water four parts of sulphate of copper and one part of sulphate of iron; then pour the liquid into the solution of soap slowly, and continue to stir the mixture until no more precipitate is formed. This precipitate is the ferrocupreous soap named above—that is to say, a mixture of brownish-red ferruginous soap, and a very beautiful green cupreous soap. These two colours, when mixed, yield a brownish-green tint, very similar to the verd antique, soap, collect it upon a filter, and boil it for a few minutes in the solution of iron and copper; then wash it in pure boiling water, next in cold water, then drain and dry it as much as possible.

To bronze a plaster cast, mix in a bain marie 30 oz, of refined boiled linseed oil, 16 oz. of ferro-cupreous soap (made as directed above), and 10 oz. of white wax; when the mixture is melted, apply it with a brush upon the plaster (heated in an oven to a temperature of 180° to 200°). Repeat the application where needed, and leave the cast in the stove for a few The mixture thoroughly penetrates the plaster, filling its pores, without in any respect injuring the delicacy of detail. When small pieces are to be prepared, they may be immersed in the melted mixture, drained, and placed before the fire until the mixture has completely sunk into the plaster. Finish by rubbing the surface with a tuft of cotton. Plaster figures may be silvered by rubbing them with an amalgam formed of equal parts of mercury, bismuth, and tin, and afterwards covering them with a coat of pale varnish. A metallic lead-grey colour is imparted to the figures by brushing them over with fine plumbago or graphite.

Another method.—Go over the figure with isinglass size until every part is covered, and the plaster has ceased to absorb. Then go over the whole with a stiff brush, taking care that none of the size lodges in the more delicate parts of the figure. When it is dry, with a brush containing just enough thin oil gold size to damp it, go over the figure, and set it aside to dry for about forty-eight hours. Touch then the whole figure with bronze powder, and let it stand for twenty-four hours; then with a soft brush remove all the loose powder, particularly from the more prominent parts.

Monze Powder.—Dissolve copper filings in aquafortis; when the copper has impregnated the acid, pour off the solution, and put into it some pieces of iron, or iron filings; the effect of this will be to sink the powder to the bottom of the acid; pour off the liquor, and wash the powder in successive quantities of fresh water. When the powder is dry, it is to be ubbed on the figure with a soft cloth, or piece of leather; but observe that, previously to the application of the bronze powder, and dark blackish sort of green is to be laid on the figure; and f you wish the powder to adhere stronger, mix it with gumwater. Lay it like paint, with a camel's-hair brush, or pre-

viously trace the parts to be bronzed with gold size, and when nearly dry rub the powder over it.

Gold Size.—Take 1 lb. of linseed oil, add 4 oz. gum animi gradually, stirring well over a clear fire until the whole is dissolved. Then boil until a drop, when taken out and cooled, becomes as thick as tar; strain through a coarse cloth, and put aside ready for use. When used, add as much vermilion as will make it opaque, and thin with oil and turpentine.

Gold Powder.—Grind leaf-gold with virgin honey until the leaves are thoroughly broken up and divided; then stir the whole in a basin of water until the honey is dissolved. Leave the basin then undisturbed for a short time; and when the gold has subsided, pour off the water, adding several fresh quantities until all the honey is washed away, after which filter and dry for use,

Copper Bronze.—Copper articles are bronzed by the following process: - Dissolve in vinegar two parts of sal-ammoniac and four parts of verdigris. Boil, skim, and dilute with water until a white precipitate ceases to fall. Thoroughly cleanse the articles from grease or other impurities, and set them in a Boil the above solution, and pour it over the articles, and then boil them in it until a reddish-brown colour is pro-When this is the case, which must be ascertained by frequent inspection, the articles must be at once removed, and then repeatedly washed and dried. The solution must not be too strong, as should it be so, the bronze will come off with friction, or turn green when exposed to the atmosphere. best bronze for copper is that used by urn-makers and medal-It is essential that the preparation of iron should be of a good quality and free from grit, and that it shall be mixed in boiled clear water until it is of the thickness of cream, copper articles being ready, the surface must be coated with the red cream, and then held over a very hot fire which is free from sulphur, and turned round and round so that all parts may come in contact as soon as possible. To perform this operation well great practice is required. The articles are subsequently burnished.

Brown Bronze Dip.—Iron scales, 1 lb.; arsenic, 1 oz; muriatic acid, 1 lb.; zinc (solid), 1 oz. Let the zinc be kept in only while it is in use.

Green Bronze Dip.—Wine vinegar, 2 quarts; verditer green, oz.; sal ammoniac, 1 oz.; salt, 2 oz.; alum, $\frac{1}{2}$ oz.; French rries, 8 oz.; boil the ingredients together.

Olive Bronze Dip for Brass.—Nitric acid, 1 oz.; muriatic id, 2 oz.; add titanium or palladium; when the metal is issolved, add 2 gallons of pure soft water to each pint of the solution.

To Bronze Gun Barrels.—Dilute nitric acid with water and ab the gun barrels with it; lay them by for a few days, then up them with oil and polish them with beeswax.

Green Bronze.—Bronzes steeped for several days in a strong olution of common salt, if washed in water and allowed to dry lowly, become permanently green; or a strong solution of agar with a little oxalic acid will produce the green colour. A lilute solution of ammonia allowed to dry on the surface produces an evanescent green.

Black Bronze for Brass.—Put 31 lbs. of scales that fall fom the red iron hammered at the blacksmith's anvil into 1 lbs. spirits of salt, and both into an earthenware pan, in which let them stand for about five hours, covered close, to teep in the fumes; stir it three or four times; strain off into a tone bottle, into which put 11 lbs, of white powdered arsenic; hake well, let it stand for a day or two, and the mixture is eady for use. Before using cleanse the brass from grease ither with emery-cloth or a brush, with sand and plenty of 'ater. Next dip the brass in the bronze until it is black; then rash it in clean water, then in boiling water-for thus heat is iven to dry the work and preserve the bronze. A soft blackad brush is then applied with some good lead; then the article to be lacquered with a very pale lacquer and heated in an ven or on a hot plate to set it hard. For green do the same rork with green lacquer for brass, to be had in any colour-To make iron green, cleanse it first from grease, then ive it a coat of blacklead, next one of green lacquer; then nake the article hot in an oven or on a plate, put on another oat of lacquer, and heat finally.

Black Bronzing Iron and Steel.—The following method of plouring iron and steel to serve both as an ornamentation and

preservative from rust is the discovery of M. Thirault, and he been successfully adopted in many factories. The followin mixtures are not the only ones that can be employed, but ar given as examples:—

Liquid No. 1.—A mixture of bichloride of mercury and sal ammoniac.

Liquid No. 2.—A mixture of perchloride of iron, sulphate of copper, nitric acid, alcohol and water.

Liquid No. 3.—Perchloride and protochloride of mercury, mixed with nitric acid, alcohol and water.

Liquid No. 4.—A weak solution of sulphide of potassium.

A sponge is slightly moistened with liquid No. 1, and rubbed upon the metal, previously well cleaned, and when quite dry, second application of the liquid is made; the crust of oxid formed upon the application of the liquid is removed by a win brush, and the metal rubbed with a clean piece of rag, and the operation is repeated after every fresh application of the sever liquids. Several coats of liquid No. 2 are then applied, and also of No. 3, with a full sponge; and after drying for to minutes, the pieces of metal are thrown into water health nearly to the boiling-point, where they are allowed to remain five or ten minutes, according to their size. After being cleaned they are again covered with several coatings of liquid No. 1 afterwards with a strong coating of No. 4, and again immers in the bath of hot water. When removed from the bath, t pieces are dried and wiped several times with carded cotton dipped in liquid No. 3, diluted each time with an increase quantity of water; then they are rubbed with a little oli oil and wiped; they are again immersed in water heated 140° Fahr., and upon being removed from it they are rubb The pied briskly with a woollen rag, and, lastly, with oil. thus treated are of a beautiful glossy black, especially if the have been polished. Iron and cemented steel are well adapted to receive this black polish; cast steel is still better adapte for it, as it assumes a more uniform brilliancy. Cast iron pa sents more difficulties, because it does not assume the sal tint all over equally.

Bronzing Wood.—First cover the wood with a uniform of ing of glue, or of drying oil, and when nearly dry the bronpowder, contained in a little bag, is dusted over it. The

bronze powder is made of various materials, such as brass, tin, gold, ormolu pulverized, or of metallic copper obtained in a pulverulent form by precipitation from its saline solutions by The process is as follows:—They begin with means of iron. preparing the proper alloy, either of copper and zinc or copper and tin, in due proportions. These alloys are cast in plates and hammered out into sheets by steam hammers. have been brought to the thickness of a stout sheet of paper. these sheets, with frequent intervening annealings, go through a system of rollers, from whence they go to the acid room, where diluted acid and washing with water removes the scale and stains. The cutting of the sheets into shreds is the next operation, after which the shreds of fine sheet metal are well mixed with dextrine, to avoid the dust of the next stage of manufacture. Powerful quartz crushers then soon reduce the metal to coarse powder, ready to go to the grinding and polishing mills, which consist of tempered wavy steel plates, over which steel rods travel at a great speed, grinding and polishing the bronze at the same time, and the quality or grain of the article is determined by the length of time to which it is subiected to the operation of these mills. Washing and straining the bronze powder, to get rid of accidental impurities of the dextrine, are the next steps, after which the bronze is put into bags of fine but strong cloth, and exposed to the pressure of a hydraulic press, to squeeze the water out and lessen its bulk. Drying at a low temperature and packing into pound or ounce packages makes the article ready for the market. The surface of the objects is afterwards rubbed with a piece of moist rag, or the bronze powder may be previously mixed with the drying oil and applied with a brush.

Broazing Paper.—When bronzing paper, use gum instead of drying oil. When dry, the paper should be burnished.

Pyrotechny.—A few of the simple and more effective fireworks are given below. The utmost care should be observed in all preparations of the kind—in filling, mixing, and exhibiting—as most of the ingredients are highly explosive, either on concussion or at a comparatively low temperature.

Coloured Fires.—The following may be burnt open:—Red.

1. Nitrate of strontia 12 parts; chlorate of potash, 3 parts;

shellac, I part, The strontia to be heated until deprived of its water of crystallization, then finely powdered. The chlorate and shellac also powdered, and all mixed intimately. The rationale of this formula is that the chlorate supplies oxygen, the shellac carburetted hydrogen. The perfect combustion of these gases gives no smell, 2. Spirits of wine burnt on finely-powdered nitrate of strontia, 3. Dry nitrate of strontia, 5 oz.; finely-powdered sulphur, 14 oz.; chlorate of potash, 5 drs.; sulphuret of antimony, 4 drs. Powder the chlorate and sulphuret separately; mix on paper, and add the others previously powdered. For use, mix some powder in a small quantity of spirits of wine. Should the fire burn badly, add a very little powdered lampblack or charcoal. Green or Blue.—When copper is burned in a hydrogen flame it gives a bright green colour, but the moment a little free chlorine is introduced the colour becomes a beautiful blue.

In addition to the above, any of the simple preparations of colours given under "Rockets" and "Roman Candles" may be adapted for burning open.

Roman Candles.—The cases are made by tightly winding stout paper around a mandril or ruler, the desired size, and between each wind or roll round the ruler paste should be applied to the paper. When the case is thus made and wet, it must be tied round the bottom to close that aperture, and to form a solid bottom to work upon.

Before filling the case (which is the next process) introduce a little clay to the bottom, thereby forming a better and firmer bottom. Next add a little coarse powder, and cover it with paper. It is now ready to receive the composition which is thus made: -Mealed powder, \(\frac{1}{2}\) lb.; saltpetre, 2\(\frac{1}{2}\) lb.; sulphur, \(\frac{1}{2}\) lb.; glass This should fill about a sixth, and be covered dust, & lb. in about two-thirds of its diameter. Then add corn powder and a ball smaller than the diameter. More composition should now be added, until the case is one-third full; then paper, powder, and ball again until it is finished, the top being composition. Paste touch-paper round the hole and add a priming of powder.

The best way of exhibiting these Roman candles is to place them in rows on a stand, some perpendicular, others declining in divers angles, that the balls may be projected to various distances, and produce a more splendid effect. The greatest de-

clension should not exceed 45° or 50°.

Composition for the Coloured Balls.—Various forms are sed, but the best is to make the composition into a paste, then all it into shape (as directed above), and when rolled in pulerized powder (whilst moist) they are ready for use. Blue alls or stars: - Mealed powder, 8 oz.; saltpetre, 4 oz.; sulthur, 21 oz.; isinglass, 2 oz.; spirits of wine, 2 oz. Stars or halls of fine colour: - Mealed powder, I oz.; saltpetre, I oz.; sulphur, 1 oz.; oil of turpentine, 4 drs.; camphor, 4 drs. Purple stars: -- Chlorate of potash, 42 parts; saltpetre, 22 d parts; sulphur, 22 parts; black oxide of copper, 10 parts; Ethiop's mineral, 21 parts. Green stars:—Nitrate of barytes, 621 parts; sulphur, 101 parts; potash, 231 parts; orpiment, 11 parts: charcoal, 11 parts. Yellow stars:—Nitrate of soda. 74 parts; sulphur, 198 parts; charcoal, 6 parts. Crimson stars: -Chlorate of potash, 17 parts; strontian, 55 parts; charcoal, 4 parts: sulphur, 18 parts. They may be slightly moistened with spirit, Great care must be taken, or spontaneous combustion will take place.

Coloured Stars for Rockets.—The different fires should always be made up wet—mixed into a rather dry paste with gumwater (8 oz. of gum to a pint is sufficient), and the stars pressed into a little mould, by which means they will do with much less gum-water. The proportions for the stars have been given thus:—Mix meal powder, 2 parts; camphor, 1 part; sulphur, 1 part; coloured fire, moistened with oil of turpentine, 1 part. Work together in little round balls, and place in rocket,


Sulphur and potash should never be rubbed together by hemselves, but French polish enough should be used to make a dough, which should be rolled well on a board to the thickness of a quarter of an inch; when dry, the dough should be rut into small cubes. It is better to buy the chlorate of potash all ready ground, and care must be taken in mixing, as it explodes at a low temperature with all combustible substances, and the stars should be well dried in a tin water-bath, and the red stars kept in a dry well-stopped bottle.

The various colours are made in the following proportions:—Red.—1. Dry nitrate of strontia, 72 parts; sulphur, 20 parts; gunpowder, 6 parts; coal-dust, 2 parts. 2. Nitrate of strontia, 16 parts; chlorate of potash, 8 parts; sulphur, 4 parts; charcoal (fine), 1 part.

Rockets.—Among the most effective of fireworks are rockets.

To make them, erect a small monkey machine, two uprights 3 ft. 6 in, high, with head and pulley fixed in same. A piece of beech for monkey, 4 lbs. weight, and sliding up and down between uprights, being kept to its place by beads nailed to uprights. A ring and cord are fixed to monkey to raise it by the pulley, and a pin or other contrivance for keeping the monkey suspended when required.

The moulds required for supporting the cases while being rammed are generally cast-brass cylinders, bored to the exter-



nal diameter of the case. Use pieces of brass tube of the proper bore, driven into a hollow cylinder of beech to support it. The foot of the mould is a cast-brass flange \(\frac{3}{2} \) in. thick, with a solid cylinder I in. high for the mould to fit over and nipple cast on; the brass spindle

is then screwed into the nipple and the whole turned up in a lathe; finally a 1-in. hole is bored through the mould I ft. 1/2 in. above the bottom, through which a pin fastens the mould to the foot during the ramming.

The rammers are pieces of cast bar brass turned down to I 16th in. less than the internal diameter of the case, and bored to fit over the spindle the exact size of same; the second rammer half way up spindle, and the exact size of the taper half way up; the third rammer to be short for the solid charge above the spindle. It is useless to make wooden rammers, as they would not last under the monkey for half-a-dozen cases.

The charges are introduced with ladles made of thin brass tube, with a handle driven in one end and cut obliquely at the other, and should contain sufficient composition to rise \frac{3}{4} of a diameter after ramming.

The internal diameter of the case determines the length and

proportions of the spindle. It will be best to give the sizes of the cases in ounces and diameters. I oz. case, 4-10ths of an inch internal diameter; 2 oz. ditto, $\frac{1}{2}$ in.; 4 oz., 7-10ths; 8 oz., 9-10ths, and the thickness of the paper cases one quarter the internal diameter, making a 2 oz. case of $\frac{1}{2}$ in. internal diameter $\frac{3}{2}$ in. external ditto.

The rule for the proportions of spindle. The length is $4\frac{1}{4}$ times the internal diameter of case, thickness at bottom $\frac{1}{4}$ diameter, tapering to the top at one half the diameter at the bottom.

The sticks should be of clean yellow pine, and of such length that, when tied on the rocket charged with stars, they should balance one another $\frac{1}{2}$ an inch from the mouth of the case. The lighter and longer the sticks are the better, but must be strong enough to bear the great force of the fire against them. 2 oz. rockets 3 ft. long and $\frac{1}{4}$ in. square; 4 oz. ditto, 3 ft. 6 in. long, and $\frac{1}{2}$ in. $\times \frac{1}{4}$ in.; 8 oz., 5 ft. long, $\frac{1}{2}$ in. $\times \frac{8}{8}$ in.

Composition for Rockets.—One of the best compositions for the body of sky rockets is 8 parts nitre, 3 parts charcoal, and 2 parts sulphur. 1. For one or two-ounce rockets—1 lb. of gunpowder, 2 oz. of charcoal, and 1½ oz. of saltpetre; powder separately and mix. 2. Two to three-ounce rockets to 4 oz. of gunpowder add I oz. of charcoal, or to 9 oz. of powder add 2 oz. of saltpetre. 3. Four-ounce rockets—to I lb. of gunpowder add 4 oz, of saltpetre and I oz, of charcoal, 4. Five or six-ounce rockets—gunpowder, 2 lbs. 5 oz.; saltpetre, 1 lb.; sulphur, 2 oz.; charcoal, 6 oz.; and iron-filings, 5. Seven or eight-ounce rockets—gunpowder, 17 oz.; saltpetre, 4 oz.; sulphur, 3 oz. 6. Eight to ten-ounce rockets -gunpowder, 2 lbs, 5 oz, ; saltpetre, 8 oz, ; sulphur, 2 oz, ; charcoal, 7 oz.; iron-filings, 3 oz. 7. Ten or twelve-ounce rockets-gunpowder, 1 lb. 1 oz.; saltpetre, 4 oz.; sulphur, 3½ oz.; charcoal, 1 oz. 8. Twelve to fourteen-ounce rockets -gunpowder, 2 lbs. 4 oz.; saltpetre, 9 oz.; sulphur, 3 oz.; charcoal, 5 oz.; iron filings, 3 oz. 9. One-pound rocketsgunpowder, I lb.; charcoal, 3 oz.; sulphur, I oz. Io. Twopound rockets—gunpowder, 1 lb. 4 oz.; saltpetre, 2 oz.; charcoal, 3 oz.; sulphur, 1 oz.; iron-filings, 2 oz. 11. Threepound rockets-gunpowder, 4 oz.; saltpetre, 1 lb.; sulphur, 81 oz.; charcoal, 2 oz. 12. For rockets of the largest sizeno it like an eximperne and no on of subplant and 44 on of charcomi. The improximents in each of these are to be separately

batia vidgamete sate ina insabave

Another variety of composition is made thus:—For tworunce reclass—meal powder, S on ; steel-filings, 2 on ; charcual thrun as line as single F powder, 1 on, rammed with 8 hirws of member, with a fall of no in, to each laddeful of charge. The same composition for a four-ounce rocket, reducing the hirws of members in six. This is a very brilliant charge, and leaves a line tail in the assent. Eight-ounce rockets—meal powder, 12 on; mine 12 on; sulphon, 2 on; charcoal, 2 on; with live hirws of ministry. The solid charge over the top of spandle should be 1; financies.

Furnation: Chierans of petaste 2 parts; black onde of connect 1 parts support 1 parts; nitrate 2 Nitre, 25 parts; nitrate of separts; 2 parts; support 1 parts; realgar, 2 parts;

impinist : juri

Files.—Nitre, it pairs a sulphurer of antimony, 1 part; sulphure, 2 pairs; lamphinule it part.

Frenc.—1. Surum mirrare. To parts; sulphur, 13 parts; perissium revinurare. 5 parts; merallic arsenic, 3 parts; and calamine. 2 parts. 2. Nitrate baryta, 16 parts; chlorate of perissà. 3 parts; sulphur. 4 parts; sulphurs of antimony, § part; charcoal. § part. 3. Nitrate of baryta, 84 parts; real-gar. 4 parts; sulphur. 15 parts; lampblack, 2 parts.

Failure.—Nimure of social "14 parts; sulphur, 194 parts;

educació cares

With:—1. Magnesium wire and chlorate of potash. 2. Nitre, 6 parts; sulphur, 2 parts; meal powder, 3 parts.

Fire Balloon Construction.—Procure a quantity of coloured tissue paper, some passe made by mixing flour with water till of a creamy consistence, and then boiling it till thick. One cance of alum to a quantern of flour improves the quality. Furchase about three feet of stout wire for a hoop, a little light wire to suspend the sponge, tow, &m., saturated with spirits of wine or other light burning liquid. Make the paper into gores, the shape of which can be arrived at by dividing a well-grown pear into six or more parts, then taking the rind of one of the parts and laying it that. The greater the number of gores the more trouble, but the greater the probability of


symmetry. It is seldom advisable, however, to have more than twelve gores, unless the balloon is to be a very large one. Join the gores in twos; first let them dry, and then in fours, and so on, never having two sides of a gore wet at the same time, or your patience may be tried by one side parting whilst the other is being pasted. When all the gores are joined, finish the top by pasting on it a circular piece of paper, to which is attached a loop of string or wire to put a stick through as a support during the inflation. Fasten the hoop in the neck with thread, pasted paper, &c.; light and suspend the sponge.

Pharaoh's Serpent.—This curious toy really constitutes an interesting chemical experiment. It consists of a little cone of tinfoil about an inch high. This cone is lighted at its apex, when there issues from it a thick, serpent-like coil, which continues twisting and increasing in length to an almost incredible extent. This coil is solid, and may be handled, although it is very fragile. The white powder with which the cones are made consists of sulphocyanide of mercury, which, when heated to a temperature below redness, undergoes decomposition, grows in size, and produces a mixture of mellon (a compound of carbon and nitrogen), with a little sulphide of mercury. It is yellow on the exterior, but black within. The "serpent" shape, of course, results from the salt being burnt in a cone of tinfoil.

Electrical Machine. How to Make.—Having procured a cylinder 61 in. long and 4 in. in diameter-cost half-a-crown -you will require a stand. Take a piece of wood 8 in. by 7 in, by 3 of an inch thick, which will form the bottom of the Two uprights support the cylinder. Let these be about 7 in. high by 3 in., and of the same thickness as the piece forming the bottom, and let them each have a hole made in them, about $5\frac{1}{8}$ in, from the bottom, to admit the ends of the axle of the cylinder to revolve freely, but not too loosely within them; these must be screwed on to the bottom piece (the cylinder having been first put in its place with the handle end to the right). The cushion is made of wash-leather stuffed with wool, fastened to a piece of wood 4 in. long by 14 broad and & an inch thick, at right angles to another piece, so that when fastened to the stand it shall press softly and evenly against the side of the cylinder. This cushion should have attached to it a piece of black silk as broad as the cushion is

long, and of sufficient length to hang over the cylinder to within an inch from the metallic points of the conductor. The cushion should fix in a hole on the front side, or the side nearest half to you, when the handle is to the right. When the machine is to be put in motion, the cushion is to be smeared with an amalgam which costs sixpence per oz.

You now want a conductor. Stick some (five) pieces of wire, sharpened at each end, into a cylinder of wood covered with tinfoil. The cylinder is to be 4 in, long and 1 in, thick, rounded at each end, and fastened at right angles to a piece of glass rod of such a length that the points shall touch, and only just touch, the side of the cylinder. A piece of wire, with a brass ball at its extremity, is to be fastened to one end of the




conductor, to which you apply the knob of the Leyden jar you wish to charge. Paint your machine, and everything is ready for operation.

Electro - Magnetic Engine. —
PP, two permanent magnets; S, a bar of soft iron covered with two coils of wire, a left hand and a right hand coil; MM, two cups with mercury; B, a bar to move in R; a rest, with two arms to dip

alternately in MM; A, an arm being moved by W, the beam; F, the flywheel; C, being stationary; P and N the positive and negative poles of a battery. As soon as the current is set on S, the bar of soft iron is turned into a magnet, so that it is drawn by one of the P magnets and repelled by the other, next the current is set into the other coil by the movement of

A and B, which reverses the poles of S, the bar of soft iron, so that it is drawn by the magnet that repelled it before and repelled by the one that drew it.

Magnetic Engine.—By this plan it will be seen that by enlarging GG and E, and attaching magnets, greater power will be obtained. When E is down, the current is sent into the top magnets by the spindle KKK, and drawn up again, and vice versa, the current never being allowed to be in both top and bottom magnets at the same time, which, if properly arranged, the spindle and springs will prevent. The soft iron, E, should be allowed to approach as near the faces of the




magnets as possible, but never allowed to touch, or it will stick and retard speed of engine.

AAA, the bed, to be made of hardwood; BB, support for beam; CC, the beam; D, connecting rods; E, soft iron plate for magnets to act upon; size according to number of magnets, of course. FF, supports for magnets; GG, cross piece for top magnets to be fastened to, and to be made of hardwood; H, brass terminal clamps for the battery wires, i.e., the clamps that are disengaged. III represent magnets made of 1-inch soft iron 4 in. long, and each core covered with five layers of number 16 cotton-covered copper wire. K is the spindle and crank motion, to which is attached two projections for making

and breaking contact with the springs facing them, which are shown at HH, and which reverse the current from one set to the other, one of these projections touching each spring at every half revolution of the spindle.

Electro-Magnetic Engine for Small Battery Power.—A is the beam, B the wheel, C the pillars for wheel, DE the magnet, which, if the stands be about 6 in. high and the other parts in proportion, should be about $2\frac{1}{2}$ in or 3 in, long, with soft iron core $\frac{1}{2}$ in. thick, and should be wrapped with about half a pound of covered copper wire. This magnet is fastened down on the base, between the stands, as shown; F is one of two oscillating iron arms made in one piece similar to fig. 2, the distance between this arm F and H must slightly exceed the length of the magnet; this armature must be fixed between the stands to oscillate on the centres K, from one side to the




other of core of magnet (the magnet being fastened down between the two arms), thus giving motion to the lever I, thence by means of the beam to the crank and wheel. The current breaker consists of two revolving arms

L, which strike alternately on the spring M, two contacts being made during one revolution of wheel. The breaker action is as follows:—Suppose the wheel to revolve in the direction shown, and the crank to be at bottom, it will be seen on examination that one arm of breaker will touch the spring M, thus completing the circuit, while the armature F will be on the left side of the magnetic core. The galvanic current now flowing through the copper wire magnetizes the core, which immediately attracts the armature, and draws it downward till opposite the core, when the breaker leaves contact with the spring, stopping the current and destroying the magnetism (otherwise it would hold the armature and prevent its moving to either side), thus allowing the arm to complete its oscillation, and the crank one-

volution. At this point the other arm of breaker touches ing, the current again flows, the former action is repeated her way, and the crank completes the remaining half ion. The wire ends of magnet are connected one to one al, and the other to the spring as shown, while the other al is connected to one of the pillars of wheel, the springallowed to touch any conducting part except the breaker evolutions.

tro-Magnetic Engine.—The peculiarity of this machine construction of the electro-magnets. BB, fig. 1, are two

wooden cv-, and round is coiled a ength of cocopper wire. . There are ores of soft e one XPX, is fixed. s half-wayup linders BB; ner, KLK, is le, and enters tfriction into linders. To e is attached R, which is s a connect-In this (fig. 2) two ese electrots are used, ovable cores. eing suspendtheworking EFG, which



onged to A, where a connecting-rod, AK, gives motion fly-wheel by the crank KL. Now, when a voltaic curmade to circulate in the electro-magnets, both cores e powerfully magnetized, and in opposite directions,


therefore they attract each other; but the one being fixed, the other is drawn down, thus giving motion to the working beam, By sending a current alternately round the two electro-magnets, the beam is made to oscillate at the point F. in which the current is so changed from one electro-magnet to the other is thus :- The axis of the fly-wheel carries an eccentric, which gives a reciprocating motion to a slide ii, of ivory, covered in a part of its length by a brass strip h; a copper wire, c, is bent so as to press continually on the brass strip, and which wire also is in communication with the zinc of the battery by the wire y. Two other wires, ac, press on the slide ii, and communicate, one with the magnet by the wire e, and the other with the magnet B by the wire g. cating motion of the slide brings the strip, a, alternately under the wires a and c, so that the current is made to flow from the battery by the wire f, either round the coils B, and by ghby to the zinc, or round the coils P and by eahby to the zinc.

Simple Electrical Machine.—This consists of a disc of strong paper, 30 centimetres in diameter, mounted on an axis made of glass tube or some other nonconducting material, and capable of being made to revolve about fifteen times in a second by means of wheels, an endless band, and a handle, of the disc are two metallic rods, having pointed extremities, which are perpendicular to the disc, being turned towards it, and at equal distances from its centre. The remaining portions of the rods are bent perpendicularly, one up and the other down, so that the metallic balls on their other extremities may be at an adjustable distance from each other. paratus is charged by placing a sheet of paper that has been well dried at the fire, and electrified by friction, very near, but not in contact with the disc, opposite to one of the pointed collectors, but not at the same side of the disc. the machine, a luminous jet will pass between the balls, the disc is covered with gum lac, and sheets of paper oppositely electrified are placed opposite the points of the collectors -one sheet being opposite to each collector—the intensity and duration of the effects obtained will be greatly increased. When the experiment is carefully made, sparks, five centimetres in length, will pass between the balls, and a Leyden jar, the matings of which are connected respectively with the latter, will be charged with great rapidity.

Constant and Cheap Battery.—For telegraph purposes there are two batteries which possess these qualities in a high degree. The first is Mr C. V. Walker's platinized carbon battery, and a modification of Daniell's. Mr Walker's is much used for railway telegraphs. In constructing it, it is best to have the graphite plate about 2 in higher than the jars, and the connecting stips of copper should be well tinned and carefully riveted as near as possible to the tops of the carbons, and then well coated with shellac varnish; this prevents sulphate of copper falling into the cells.

The second battery referred to is as follows:—I is a flat copper cell, having a piece of leather secured between two sheets of perforated copper on one side; 2, side view of the same cell; a, cop-

per cell; δ , δ , perforated copper; c, leather; 3, a cell of the battery complete. The whole of the outside of the copper cell should




be well varnished, and the perforated side placed opposite a piece of very stout unamalgamated zinc in a stoneware or other jar. The outer cell is merely charged with water, and the copper one filled with crushed sulphate of copper moistened with water. It is obvious that several cells of this battery are required for a telegraph owing to its feeble intensity, but we are informed it remains constant between twelve and eighteen months.

Flower-Pot Battery for Electrotyping.—Common red flower-pots will answer the purpose of porous battery cells. Wood diaphragms, ox-gullet, brown paper, prepared canvas, &c., have all some fatal objection, which precludes their use where long and constant action is desirable. The form of action used with success is a modification of Daniel's, wherein the common red flower-pot is made to do duty as a porous vessel, and, when properly selected and prepared, it answers the purpose exceedingly well. Other advantages of this battery

are, that nitric and other acid fumes are dispensed with; it is the least costly to construct, no amalgamation required, and is easy to manage in the hands of an amateur or inexperienced person.

Electric Rattery.—It is not necessary that the plates of zinc and lead be rolled up together, provided the battery jar is large enough to admit the plan. You cannot roll up amalgamated zinc plates in consequence of their brittleness. A is the primary battery, B the induction coil, C the secondary battery, D, stand for the coil, showing the ends of the wire connected to the binding-screw E, on the one side, and the other end connected with the spring of the contact-breaker F. The other portion of the contact-breaker G is connected to the binding-screw H. The zinc of the secondary battery is connected to



the binding-screw H, and the lead connected to the primary coil of wire as shown at I. The connections from the primary battery are from zinc to H, and copper to E.

You will now be able to understand the arrangement, as there is nothing very complicated in it. I and K are wires leading from the secondary battery for experiments. If any other form of coil be used, the same plan of connections must be adhered When setting the machine in operation the screw of the contact-breaker must be brought in contact with the spring portion, and as long as the vibration of the contact-breaker continues the operation is going on. The peculiar arrangement of the connections is made in this manner, so that we may obtain the extra or dynamic current, which is only produced at each break of the contact-breaker. This extra induced current, being in an opposite direction to the inducting primary current, passes only in the direction of secondary battery. tion on the lead of peroxide of lead by the decomposition of the electrolyte causes the immense power of these batteries. Two plates of platinum may be used even in the place of lead and zinc, and then the secondary batteries are even more **powerful.** The power of the platinum batteries depends upon the formation of oxygen on one plate and hydrogen on the other.

Earth Batteries.—Zinc and coke may be used with advantage in the formation of an earth battery. To construct one of this description, a sheet of zinc, about I ft. square, should be buried perpendicularly, about 4 ft. deep, in a moist soil, and the coke placed 3 in. from and parallel to the surface of the sinc plate. It matters little whether the wires leading from this battery be insulated or not; the value of an earth battery depends on the moisture of the ground it may happen to be placed in, the strength of current diminishing on the soil becoming dry, and increases when it becomes moist.

A simple and convenient form of earth battery may be formed by merely burying some coke, or a copperplate in the ground, to form one pole of the battery, and the gas or waterpipe can be used for the other pole. Either of the above forms of earth batteries would efficiently work an electric clock of the usual description, very small power being required. batteries under the most advantageous circumstances are never very powerful, or, to speak more correctly, they rarely exhibit much "quantity," whilst induction coils can only be worked efficiently by the use of good "quantity" currents, on account of the thickness of the primary wire. "Smee's" arrangement of coil, of about a pint capacity, would answer. In the absence of information as to the gauge and length of primary wire, it would be well if different proportions of exciting solution were tried. commencing, say, from I part sulphuric acid to 12 water, up as high as I part acid to 6 water. It would then be seen which proportion suited the coil best. Smee gives good quality, is compact, easily managed, and very cleanly.

Another method.—A coke battery will be strong enough without the addition of zinc, and it is not necessary for the wires to be insulated. In making the earth battery there are several ways. Dig a hole about 3 ft. deep, and put two or three hundred weight of coke, and attach a wire in any way to the coke, and attach another to a gas or water pipe, and the battery will be complete. Another way would be, to attach a wire to a gas-pipe, and another to a water-pipe. This battery is strong enough to drive an electric clock. Another battery


can be made by attaching a wire to one of the pipes, and simply sticking the end of the other wire 3 or 4 in. in the ground; but the first battery will stand any length of time, and four or five electrical clocks have been worked at the same time on this battery, and is much superior to one in which copper and zinc plates are used. No earth battery will drive a shock machine.

Artificial Magnet.—Take a piece of round inch bar, 13 in, long, and bend it into the form of a horse shoe with the end strictly parallel; then get half a pound of covered copper wire, No. 16, and commence to wind on. The power may be increased by covering the iron first by winding on strips of silk, so that the surface of the iron is protected from contact. Leave a free end of about 3 feet for attachment to the battery, and begin about half or a quarter of an inch from the end and fasten the first turn with a piece of packthread, and proceed to wind the wire on as closely and neatly as possible. It does not make any difference whether it is coiled to the right or the left, as it does not matter which is the north pole, and go right round the magnet, fastening the other end same as the first; the coils round the bend will be a little open at the outside, or it will not come square on the second limb. You may then attach it to the battery, and see if all is right; if so, varnish all over with red sealing-wax dissolved in spirit, and it is finished; but connecting one end of the wire will not be sufficient, as it is necessary that both ends of the wire should be attached to the battery to complete the circuit, or the magnetic influence will not be set up. With this magnet you can suspend 28 lbs., using a single pair, zinc and copper, same as for electrotype plates 6 in. by 3½ in.; but an increase in the battery power would make it very much more powerful.

Electrical Machine—Regulation Coil.—A^T, A², are the two ends of the primary helix; B¹, B², the two ends of the secondary helix, which are in direct communication with the two binding screws to which the brass handles for administering the shock are attached. D¹, D², are two binding screws to which the battery is connected. To D² is soldered one end of the primary helix, but between the other end and D¹ the break must be fixed. A glance at the diagram will show the manner in which this is done. The brass tube used in some


coils for regulating the shock does so by shutting off the magnetism of the core of iron wires, or rather by preventing the primary helix from inducing magnetism in the bundle of wires; and it effects its purpose nearly as well as the drawing out of the bundle; for brass, although an excellent conductor of electricity, presents a most effectual barrier to magnetism, as may be proved by interposing a piece of plate brass between a permanent magnet and its keeper, when the magnet will be found

to attract but very alightly. For medical purposes the current should not flow only in one direction. Copper in combination with zinc does not evolve nearly so much elec-



tricity as platinized silver, but a sheet of platinized iron will answer nearly as well. To platinize the iron, first clean it well, and then pour over it a solution of platinum in nitro-muriatic acid, which will cover the iron with a black precipitate, which is platinum in a state of very fine division. The iron must then be well washed in clean water. Varnishing the surfaces of the zinc, which does not face the platinized silver or iron plate, must in a measure save the zinc, and not prove detri-

mental to the power of the battery. To regulate, coil gradually by means of a series of brass wires let into the stand, wind on the primary wire in the ordinary way, and bring out the ends




from the secondary. Before commencing to wind the secondary wire, bring out the end a, which will subsequently have to be soldered to the terminal b. Now lay on three layers, and without breaking the wire rub off a portion of the cotton or silk covering, and solder to the exposed part the wire d, which must be brought through the cheek of the coil, and will be afterwards

soldered to the brass knob 1. Next wind two more layers on, and repeat the above process, bringing out another wire ϵ , which will have to be connected with the knob 2; and continue winding and bringing a wire out every two layers until the coil is full. In the coil represented there would be eleven layers of secondary wire. The other secondary terminal, ϵ , is connected with the sliding arm i. It will now be seen that, by turning the handle to 1, but three layers of wire are in use; at 2 there are five, and so on, until at 5 the current circulates through the entire number of layers, and consequently the full power of the coil is obtained.

Amalgam Pad.—Take a piece of red leather 4 in. or 5 in square, and spread on the middle of the rough side a small quantity of amalgam, to which has been added about 1-6th its bulk of tallow. They should be well blended together, and all the mercury that can should be pressed out. If this pad is kept dry and free from dust, it will answer for a very long time. To excite the machine, first remove all dust from the cylinder and stand with a warm dry cloth. Then turn back the silk flap of the rubber, lay the amalgam side of the above pad on the top of the cylinder, holding it in its place with a slight pressure with one hand while turning the machine with the other, and it will soon speak for itself. This will be a much cleaner and quicker mode than putting the amalgam on the rubber.

Condenser for Rhumkorff.—Take a sheet of varnished cartridge paper, 12 in. by 8 in., or larger if required, and lay




on it a sheet of tin-foil II in, by 7 in., to allow half an inch margin all round; then at one corner lay a slip of foil 3 in. by I in. to serve for a connection, lay over that another sheet of varnished paper, then a sheet of tin-foil and a strip of foil in the opposite corner, and so continue building it up, being

careful not to put two strips of foil following in the same corner, but alternately, first in one, and then in the other, so as to connect together every other sheet. The condenser for the Rhumkorff consists of 50 sheets so put together, enclosed in a


box for safety. The manner of connecting the condenser with the break of the coil may be seen in the annexed diagram.

The condensers are generally placed underneath the coil; but that the manner of connecting them may be the more easily understood they are drawn at the side. In those coils the primary wire is laid on in separate layers, with all the ends brought out, and so that by connecting the handle with the first piece of



brass, the battery current passes only through the first layer, thus magnetizing the iron core but little, and rendering it


capable of inducing but a weak current in the secondary wire; but as the handle is moved onwards each successive piece of brass



connects one more layer of primary wire, until at the last all the layers are connected, and the core becomes, when the cur-


rent passes, highly magnetized, and capable of inducing a strong secondary current.

Another machine for covering wire with cotton, silk, &c., is made entirely of deal. A is a tube for carrying the wire through; B is a wood disc, which can be glued on A, carrying one or any number of reels; B, the covering material, which




is passed through the disc and a wire eye, and on to the wire

to be covered. By turning the crank with one hand, and drawing out wire with the other, any length of wire can be rapidly covered.



which are mortized the two uprights BB, only one of which is



A third machine for use with cotton is thus made :- A is the handle for driving: B, the driving strap; C, the uncovered wire on the reel; D, 1-inch tube conductor; E, bobbin table with cotton bobbins mounted; F, round zinc table, with holes corresponding to number of bobbins; G is the receiver for the covered wire. The box containing the whole is of threequarter stuff, and is 3 feet by 11 feet.

AA, sole of machine made of wood, into only one of which is shown. They are placed about 3 in. apart. C, upright frame, for carrying shaft D and tube E; FF, two rollers for drawing through wire as it is covered; the top roller is made of lead, so as to give pressure to the wire to take it

Another plan is thus described:-


hrough; E, tube or hollow spindle through which the wire

Passes; GG, speer-wheel, and pinion for driving hollow spindle and bobbin; HI, bracket for carrying end of hollow spindle; I, endless screw for working the pulley-wheel O, fixed on the Outer end of the under roller F; R, support for steadying the wire as it passes through the spindle E; H, bobbin containing the threads for covering the wire; L is a small eye, fixed into the frame that carries the bobbin, through which the thread In using the machine, wire to be passes on to the wire. covered is held by the hands, and kept stretched as it is drawn through by the two rollers; another pair of rollers might be applied to keep the wire stretched the same as the drawing The speeds of the machine are as follows, viz.:-Large wheel 60 teeth, pinion 15 teeth, drawing screw 6 teeth to the inch, pulley for do. 35 in. diameter, drawing rollers 3 in. diameter.

Electro-Magnetic Clocks.—AA is a mahogany case, with a glass front; B is a metal bracket fixed to the back of the case, to which the pendulum D is suspended; NS are permanent steel magnets, fixed to the sides of the case in such a manner that the pendulum-ball D can vibrate freely between the poles of each magnet. The magnets are placed so that the poles of dissimilar names face each other. E is a small platinum ball, affixed to a brass stem, free to move to one side or the other, being fastened to a light spindle carried by the pendulum-The plate of copper, F, is deposited in the moist rod at H. earth, from which a wire, C, leads to the bracket B. The plate of zinc, G, is likewise deposited in the earth, and its wire leads to the piece of metal I. To the lower end of the suspension spring of the pendulum is attached a wire coated with silk. is let down the back of the rod, which is wood, and then coiled longitudinally in many convolutions around the edge of the pendulum-ball in a groove previously made for that purpose.

It is then taken up the back of the rod, and terminates in the bearings of the spindle H. The action of the apparatus may be explained thus:—A constant and uniform current of electricity would be established, and would pass through the earth, the plates, and wires in the direction of the arrows, so long as the platinum ball E rests on the platinum pin projecting from the metal I. But if the pendulum is put in motion, suppose that, first, it were drawn aside until the ball D should

be between the poles of the right-hand magnet, the point H being now farther to the right than the ball E, the latter would fall to the left and rest on the pin K, until the pendulum took its vibration to the left, when the ball E would fall to the right; and so on continually, the action being produced by the change of the centre of gravitation at each vibration of the pendulum. This action of the ball E lets on and cuts off the flow of elec-




tricity at or near the extreme ends of the pendulum vibrations, so that the convolving wire of the pendulum-ball is attracted and repelled by the magnets at the proper points of its vibrations, and thus a continual motion is kept up for an indefinite period of time. No explanation is needed of the remaining portion of the clock.


Cheap Electric Bell.—This will work about 25 yards away from one small Daniell's cell. Total cost, 3s. 6d. A, bell;

B, a small block of wood upon which the bell and magnet are placed; C, two binding-screws; D, a quarter of a pound of copper-covered wire, No. 16, for magnet; E, clock-spring for hammer.

Galvanometer. — Fig. 1 represents the machine when complete; fig. 2 the coils and leedle, made of hardened iteel magnetized; fig. 3 the leedle and finger; fig. 4 the keleton coil-boxes covered




keleton coil-boxes, covered with ten layers of No. 30 silk-




covered copper wire, for intensity purposes, but for quantity hey should be wound with four layers each of No. 16 cotton-

covered wire. Figs. 5, 6, 7, should be made of ivory, brass, or bone, and when put together they will form the coil-box or frame, fig. 4, ready for winding on the wire. If the boxes are made of brass, they should be varnished with shellac varnish,



shellac and naphtha. The wire can be varnished when wrapped on the boxes, but the operator must be careful to wind the wire on both boxes, in the same direction, or he will not obtain any good effect. The two inside wires should

1 together as at C, and the outer wires to the ter1 the case.



ng Magnet.—The following is the most simple form: are the poles of a horse-shoe magnet fixed on a stand, is a wooden cup for mercury, divided into two parts, a is connected to one end, and b to the other, of a



battery. C is the electro-magnet, consisting of a of soft iron, surrounded at its ends with a continuous out copper wire, the two terminations of the wire dip-

ping into the mercury. The electro-magnet is supported on a central vertical axis, which passes through a collar, and terminates in a point, resting in a small agate cup, so that the electro-magnet is free to move in a horizontal plane.

Mounting a Magnetized Needle.—Having your needle magnetized, cut a piece of cork cylindrical of the following dimensions:—Height $\frac{1}{2}$ in., diameter $\frac{1}{4}$ in.; push the needle through the cork near the top, and in the bottom of the cork



insert a part of another needle, leaving the point projecting Balance this on the top of a piece of glass rod by inserting pins loaded with small shot opposite each other on either side of the magnetized needle. The glass rod may be fastened to the foot of a wine-glass by means of a piece of guttapercha, or wood, or brass. If the cork be varnished with sealing-wax varnish, it will be improved in appearance. annexed figure will illustrate this arrangement. A, cork; B, needle; C, loaded pin; D, the point on which the whole is balanced.

Electric Telegraphy.—The battery, or generator of electricity, is the fundamental part of the electric telegraph. The two ends or extremities of a battery wherein electricity is generated by chemical action are termed poles—one of them the positive

and the other the *negative*. From the former the current of positive electricity issues, and from the latter the negative. Before the two metals of which a battery is composed are joined together no electricity is evolved, and when metallic


on is established, the electricity simply makes a circuit; the opinion of many eminent electricians that no parortions of that circuit can be said to be either negative we to another portion.

are two theories of the electric fluid—the single and ble fluid theory—and the student, while adhering to the aid theory, by which the action of the battery is geneplained, may confound the existence of two different I tensions in the conductor forming the voltaic circuit, idea suggested by the terms mentioned of *two* distinct passing through this conductor from each of the extre-

the battery.
ver theory of
y is adoptrms positive
ative will be
qually conand expresor reverse the
i of the elecrent, or to
alternate

alternate in reverse is along the ng wire, are ons not limisinterpref the words and negative arly under-

oattery most for telegraph is is the Daniell's Battery.



Pole with a variety of Insulators.

s are very constant, requiring very little attention, are usive in smell, and furnish a steady, reliable current, ing a "Daniell's battery," not a little care should be obtain a porous cell free from defect. Two extremes be carefully guarded against in selecting a porous cell; er it may be over-fired, baked, or at too great a heat,

when it will not be sufficiently permeable by liquids, that is, it may not be so porous as to permit the liquid to pass through without rupture or displacement of its parts, or it may not be sufficiently baked, when any metallic solution will act upon and partly dissolve its substance.

To prove universal porosity of a cell, it is necessary to ascertain whether water will pass slowly, but entirely, through every part of its texture, or by touching it with the tongue when the amount of dryness produced by the absorption of the moisture will show the freedom with which liquids will pass. The more porous the cell is, the greater the quantity of electricity developed, and, therefore, the greater the quantity of metal deposited, as the degree of deposit is always in relation to the quantity of electricity generated.

The zinc plates should be well amalgamated, and the porous cell supplied with a saturated solution of sulphate of copper. Very little acid should be added to the water in the cell containing the zinc plate. The outward vessel is formed of porcelain, and consists of two battery cells. The copper element is immersed in a porous vessel containing sulphate of copper. In order to prevent as much as possible the copper solution passing to the adjacent cell, and its consequent action upon the zinc element, the porous vessel is saturated with tallow, excepting upon a portion of the surface which is directly opposite to the zinc plate. Instead of a porcelain vessel, battery cells constructed of ebonite are also employed with success.

The quantity and intensity of the electricity in the voltaic pile are respectively modified by the size and number of the plates, and by the action of the intervening liquid. When the zinc plates are perfectly clean, pure water produces certain electrical effects. These are considerably modified by dissolving common salt in it, or employing other saline liquids, but dilute acids are best calculated to increase them.

When the poles of the voltaic battery are brought near to each other in acidulated water or saline solution, or when these liquids are made parts of the electric circuit, so as to enable the electric current to pass through them, decomposition ensues, that is, certain elements are evolved in obedience to certain laws. The water, which is a combination of two gases, yields oxygen and hydrogen, and the neutral salts yield acid and alkalis. In these cases the ultimate and proximate appear at

the poles of the battery, not indiscriminately and indifferently, but oxygen and acids are developed at the positive pole, and


hydrogen and alkaline bases at the negative pole.

The intensity of the electric current is dependent on the energy of the chemical action on the zinc, and the quantity produced in a certain space of time depends solely on the amount of decomposition produced, or the weight of zinc dissolved in the cell, in order to increase the number of cells containing voltaic pairs. The nature of the exciting fluid materially affects the resistance which is afforded to the galvanic current, for no strength of two fluids conducts the galvanic power with equal facility.

In making a galvanic battery, it is necessary to have two good conducting substances, separated by a good intervening liquid. The amount of action which it will produce will be proportionate to the ready action of the liquid on one substance and its inaction on the other, and will depend on the size and the power of the battery, but it is always lessened, first, by a slight resistance which the metals afford to the passage of the current; secondly, by the resistance which the intervening liquid is certain to afford, which is proportionate to its thickness.

If, instead of a good conducting metal, the connection between the terminal plates is made by any imperfectly conducting substance or any great length of wires, then will also the power be still materially decreased. One cell, containing two metals and an intervening fluid, provided it be large, is sufficient to produce any amount of action where no resistance is afforded to the passage of the electric current. These will remain inactive while they do not touch; but as soon as contact takes place, either in the exciting fluid at a distance, or through a fluid of more easy decomposition than the exciting fluid of the battery, the action immediately commences. The contact may be made through a great length of wire with the same result. In this case, however, if the wire be either long, of small diameter, or of a metal of no great conducting power, it will be seen that the hydrogen evolved from the negative metal will be materially lessened, showing that an obstacle is presented to the electric fluid.

In constructing a line of telegraph, some discretion is necessary as regards the selection of posts for the support of the wires. It has been decided that it is far better to suspend wires than to bury them, owing to the liability of the insulating material employed for the encasement of subterranean wires to increase the expense of repairing faults; therefore the majority of our inland wires are supported on wooden posts along the lines of railways or canals. The poles should be at least 5 in in diameter at the top, and about 15 feet out of the ground and 5 feet in. The length of the posts must necessarily vary according to the locality in which they are placed. Young firs are generally used for telegraph service abroad, but in our country English larch is preferable. In Germany and America insulators have been put up on the stems of living trees, and



found to answer This very well. idea arose from the fact that the sap ingredients of the tree are the prime movers in the rotting of dead wood and, in order to obviate the drawback to this system, occasioned through the violence with which trees are moved in heavy storms, Lieut.-Col. Chauvin constructed a swinging insulator. This contrivance is hung

upon a hook free to swing about (see engraving). The stalk is bent in a curve, away from the stem of the tree, that when the latter is deflected by wind, the line wire in swinging may not come into contact with it, the hook A, held in the loop B of bracket C, C', is twisted, so that in case of a sudden jerk the line cannot be thrown upwards, and the insulator disengaged from the bracket. The hook D is also bent over the wire to prevent the line jumping out. This is a very ingenious contrivance, and could be used with advantage in America, where lines have to be extended through forests. The number of


per mile average from 20 to 30. Iron posts are so ged that they fit telescopically into each other; thus they great facilities for shipment, and can also be conveyed by hand or by the cheapest mode of conveyance. Being the with turned and bored points, they can easily be ogether. The similar portions of the poles are inter-

geable. Should a tage occur, the part is destroyed can, fore, be easily red,

of the pole is also ladvantageous in house telegraphs, as, fastening the wires e insulators, the pole raised or lowered easure. The arrange-

for fixing the inors is admirably con-

he wire used for telehe lines is No. 8 gauge wire, coated with zinc, unized, in order to ent oxidation or rust. zinc is applied to the ce of the iron while state of fusion. Zinced lines have been several years. When ain first falls on the covering, an oxide of is formed, and this



being insoluble in water, a second fall of rain cannot disor penetrate it. The zinc covering and the iron wire e are thus prevented from rusting away.

isulation is the next important matter connected with the ric telegraph; and although many forms of insulators, a of various substances, have been invented, proper insula-

tion of our telegraph lines has not hitherto been attained. When the insulators are clean, and in dry weather, there is a loss at every point of support. In wet weather the loss is increased; and when insulation is imperfect, and heavy showers of rain occur, the loss is often so great as to completely suspend the working of the line. Certainly, much can be done by increasing the power of the batteries, still it is with difficulty that we can work the wires in wet or foggy weather. Glass insulators are covered with a thin film of water. Some electricity will escape over every insulator so covered with moisture; in fact, the glass becomes a conductor. As it is exposed to humidity, it attracts to its surface the aqueous vapours of the atmosphere; they form there a thin film of water, by which the electricity passes away. The first aërial insulator introduced in this country was an earthenware tube of the size and form of an egg, slightly flattened at the ends. The wire was passed through a hole in its longer axis. Porous earthenware and baked clay insulators are principally defective, from the fact that the body is so porous as readily and easily to absorb moisture. Whenever the glazing is broken through by the wire and the spike, a moist communication is at once established, and the insulator is highly imperfect. An objection somewhat similar holds against the use of gums, resins, and other non-conducting substances, less hard than glass, as the wire would soon wear through, and touch the pin upon which the insulator rests. The surface is also liable to gradual decomposition or exposure. Varley's insulator is extensively used in England. It consists of two cups cemented together with sulphur: the outer cup is provided with a groove, to which the wire is bound. In the recess of the inner cup a wroughtiron bolt is cemented, by which the insulator is attached to the bracket on the post. A further insulation is obtained by coating the stalk with vulcanite. The rim of the outer cup is rounded off inside. The purpose of this is to avoid the sprinkling of the interior with rain water, when a drop hanging upon the bottom rim is blown off by the wind. When a strong current of air separates a drop of water from a sharp corner, the drop is never carried bodily off, but bursts in the direction of the current. With the form given to the rim by Mr Varley, when a drop happens to hang on that side from which the wind comes, it is driven a little way up between the two cups, and does not burst.

Siemen and Halske's stretching insulator is shown in the diagram. It is made with a stronger and larger cast-iron bell than the ordinary insulator. The porcelain cup carries a stalk with two notches, through which the wire is drawn and wedged on each side, leaving a loop between them. In cold weather, when the line contracts, this loop allows the wire between the posts to be slackened, and also, in case of a rupture, gives sufficient space for making a joint.

The subtle agent electricity, that we see, feel, and know to be moving in things around us, is composed of minute particles unsusceptible of any further division, electricity being in that respect analogous to all other kinds of matter. The induction action starts into immediate existence on the slightest disturbance of the normal electricity. Distribution shows us the wire of the electric telegraph under two perfectly distinct aspects. It seems always to have been constructed for performing two different functions not generally known to be separable from one another either in theory or in practice. The causation in both cases has been too profound to be understood.

In both cases—electrical conduction, as well as electrical charge, distinct though they be when considered as resultsthere is in operation for attaching plus electricity to neutral matter a cause that we have not yet made known. Imagine a spherical particle of common matter to have a portion of its surface occupied by comparatively minute portions of electricity. attracted towards its centre as part of its natural electrical equivalent, then three things will become apparent. First, that the particular particle of common matter will have room to receive upon its surface some additional number of electrical Secondly, that that particle, without attracting a larger total quantity of electricity, can attach to its surface an additional number of electrical particles if placed upon it, because some part of every one that will be so placed must be nearer to the common centre of attraction than all the parts of any one of them. Under these circumstances, the parts that are nearest making up in their total a quantity required to complete the electrical equivalent will be held by attraction. the remaining parts not attracted by the common centre will be attached to the particles of matter by the indivisibility of the particles, and be to it a plus charge. The third thing that will become apparent is, that as many particles of electricity as

shall be so placed on one side of the surface of a common particle, in addition to its natural equivalent, may, if an adequate removing cause be in operation, be taken from it at the same or any other side without the particle of matter losing its normal

quantity.

Apart from the consideration of all surrounding circumstances, the electrical condition of the particles of common matter just described may be the condition of all the particles throughout the whole substance of a conductor in its interior as well as its exterior portions. If then, in practice, we find the condition to be at any time limited to any particular part of a conductor, we must conclude that its locality is alone determined by surrounding circumstances for the time being. No conductor can appropriate to itself absolutely a single particle of plus electricity, common matter universally having had assigned to it at its creation a particular and unchangeable quantity, so that any additional particle that may be placed upon it, it can only hold, as it were, in trust for some rightful owner, on the conditions called artificial electrical equilibrium.

The artificial electrical equilibrium is that state of matter which becomes established whenever plus electricity, exerting attractions for its equivalent of common matter from which it is temporarily separated, acts upon surrounding non-conducting neutral particles virtually, though by reason of their insulating nature not actually dismissing from them some of their natural electricity, and causing the same action to be propagated to progressively increasing quantities of insulating matter until, by reason of electrical law of the squares of the quantities, the intensity becomes so reduced as to be insensible on our most This, the ordinary form of artificial delicate instruments. electrical equilibrium, is sometimes somewhat modified by the intervention of neutral conducting matter, which, if it be near enough to sustain the induction, can actually as well as virtually relinquish a portion of its own electricity, and thus promote the reduction of intensity, especially if the electricity relinquished cannot pass into earth, from the surface of which it can act inductively with an intensity that may be regarded as infinitely small. As the facilities for the reduction of intensity increase, so will, of course, the charging capacities or quantities of plus electricity, susceptible of being held under any specified

intensity, and, owing to this law, if a conducting surface have contiguous to it another conducting surface communicating with the earth, it can receive upon it under a given intensity far larger quantities of charge than when it is simply surrounded by air. Considering, then, that the distance at which the electrical attraction may be acting between a common particle and its electrical equivalent is shortened by an accession of plus electricity, and that plus electricity on the surfaces of common particles can have the intensity of its attraction reduced to an insensible amount by induction, we can understand plus charge to be both possible and in perfect harmony with the doctrine of limited electrical attractions. Now, when we lay an insulated telegraph wire between two distant places, and deliver electricity continually into one of its extremities with greater rapidity than it can find its way out of the further extremity put to earth, it is impossible not to charge its surface, and that charge may have an intensity of action to any amount not exceeding the source from which the plus electricity is delivered.

This is true, whether the further end of the wire be freely uninsulated or insulated. We can surround a long conductor with a cylindrical vacuum of diameter large enough to put common matter beyond the reach of induction, or we might establish a telegraph wire with perfection; for, under such circumstances, electricity would either not enter the wire at all, or only do so in order to arrive through it at some charging capacity at the other end, capable of holding it under an intensity below that of the source. At the best, our telegraph wire has a very similar capacity for charge derived from the air around it.

And even the degree of imperfection is always necessarily abandoned for a worse whenever the circumstances of our locality constrain us to convert naked wires into "cables" for the purpose of their "interment" or submersion, for in either of these cases the solid insulating material by which the wires are enveloped for maintaining their charges is far too thin to keep the external conducting matter at an effectual distance, and thereby preventing it from dismissing by induction comparatively large quantities of electricity to find on the surface of the earth or sea a lower intensity of charge than could otherwise be afforded. The greater charging capacities thus occasioned are known practically to give rise to evils of enor-

mous magnitude, and of which every telegraphist is sufficiently sensible.


We now reach the laws of electrical conduction as applied to electro-telegraphy, and we will proceed with the following simple experiment. Place upon a large insulated sphere a plus charge, and against it on either side an end of an insulated rod, one of the sides being of metal and the other of glass, dry and clean. Part of the charge will immediately distribute itself over the surface of the conductor, but not over that of the non-conductor. Remove the glass rod, and slide the numerous parts of its surface into contact with the charged sphere. Then, upon removing it, it will be found with a plus charge distributed upon those parts of its surface like the other rod. In this experiment, had not conduction been a preliminary necessity, charge would have ensued along both sides of the rods directly they were placed with their extremities against the charged surface of the intermediate sphere, for both cylindrical surfaces were susceptible of charge, as is proved by the two being ultimately found plus electrical. It is proved that, although it should be possible to have conduction along a wire without charge with the attendant induction, we cannot have the reverse of this, that is, a charge on the wire or its induction, unless the wire has previously acted in some way as an electrical conductor.

Let us now endeavour to explain more minutely the nature of electrical conduction along a telegraph wire. For the sake of simplicity of conception, suppose the insulated wire to consist of only a single line of particles of common matter, and that we present to one of its ends a quantity of plus electricity, emanating from a source maintained at a given intensity by virtue of the shortening distance, as before explained, the common matter of the line acting by ordinary electrical attractions, will attach to itself the electricity so presented.

Now, if the line be insulated at its further end, the electricity will be held by it as a plus charge under some intensity, not exceeding that of the source from whence it is derived; but if, on the contrary, the further end of the line be put to earth, or other sufficiently large mass of conducting matter, surrounded by air, and the supply of electricity be not too rapid, then conduction and not charge will ensue, for immediately that a particle of plus electricity enters the wire

and, another particle of electricity, natural to the other ill leave it—all the common matter of the line still ng its normal equivalent of electricity, because every the common particles will have acquired an electrical from its neighbour, situate between itself and the of the plus charge. It may be that each of the common s in the conducting line is capable of so parting with ree, or some greater number of particles of electricity neously, and in proportion as it can do so will it be the lectrical conductor; but its capability in that respect

we a limit, and instead ngle line, as we have ed, every wire will, of have some large numsuch lines bundled toproportionate to the f its sections; from t follows, all other conbeing constant, that its tivity will be as its area ied into the number of al particles that each n particle can charge neighbour. So far, e, as the wire is concharge and conduction niefly in this-in the forplus electricity of the passes from it to the act from its surface



Siemen and Halske's Insulator.

diminished intensity on the surrounding air, and, in ter case, it is handed on from particle to particle of the to be conveyed to some other conductor, having a sign capacity that will enable it to do the same thing; there of these results will take precedence of the other, surrounding circumstances shall enable it to be accomby the lower intensity. If the plus electricity meet the inductive reaction by remaining in the wire than by yout of it, charge will take precedence of conduction; contrary, if the plus electricity can pass out of the a lesser amount of inductive reaction, then conduction

will supersede charge, and therefore it is that conduction is consequent upon uninsulation and charge upon insulation of the wire. This is the theory of an eminent electrician of the present day.

Alphabetical Dial Telegraph.—The Voltaic Alphabetical Dial Telegraph Instrument was formerly made by Breguet in




three separate parts, namely, the manipulator, receiver, and the alarum bell. The three parts are now combined in a compact case. In fig. 1 we have a view of the case open, showing the face of the receiver and the plate of the manipulator with the handle. As will be seen in fig. 2, another part of the case is hinged, and is capable of being opened. On the



inside of the lid of this part is screwed the bell, which is an ordinary "Tremulo" bell. At the bottom of the two sides, and at the back of the case, are placed brass terminals, to which are connected the line wire, the battery wire (copper), and the

By turning the handle on the dial-plate once earth wire. round, we send, by means of a "cranked" arm not shown in the drawing, thirteen copper currents on the line, or half as many currents as there are signs on the dial-plate; these, entering the instrument at the distant station, cause the hand or pointer on the face of the receiver to revolve once round, or should the handle at the sending station be stopped at any letter, the pointer at the receiving station will likewise stop at the same letter. A glance at fig. 2 will serve to show how this A train of clockwork, which on the average only requires winding up once a week, drives a common ratchetwheel with thirteen teeth, the shaft of which is carried through to the face of the receiver, and on which the pointer is placed, This ratchet-wheel is released, half a tooth at a time, by a light rod, fitted with a catch, which is attracted to the armature of the electro-magnet, as it is attracted to or pulled back from the poles of the magnet—an attraction and a repulsion making two When the case is closed, by means of a spring and a point seen at the left-hand corner of fig. 1, the bell is put into circuit, so that when a current travels on the line the bell commences to ring, and continues to do so until the arrival of the clerk, who opens the case, and thus brings the receiver into It is possible to work these instruments at the rate of twelve words per minute, and a Daniell's battery of twelve elements is quite sufficient for a distance of four or five miles.

Simple Electric Telegraph.—The base consists of a piece of mahogany 8 in. square and 1 in. thick, with a hollow groove




cut in its centre 2 in. long and a half inch wide. The coil consists of 50 ft. of covered copper wire, No. 30 gauge, wound on a

frame of card $1\frac{5}{6}$ in, long, $\frac{1}{2}$ in, broad, $\frac{8}{6}$ in, deep in the open part; an edge or flange of card $1\frac{1}{2}$ in, wide, 2 in, long, is stuck to each side to keep the wire in its place. Now commence winding the wire at the lower left corner, and wind from right to left. Each end of the wire must be stripped of the cotton.


so as to have the wire clean for the electricity to pass. The coil is mounted in the stand by inserting the two lower edges

in the groove, so that the floor of the coil is level with the stand. The needle is I in. long, I-I2th of an inch wide, of hardened and thin steel, and fitted with a brass



cap turned to a true cone, to receive the steel point on which it is to be balanced. The needle is then to be magnetized by drawing it across the face of a common horseshoe magnet three or four times. This needle is now balanced on a steel point 3-16ths of an inch high, soldered into a copper slip 2 in. long. Now glue on the needle a piece of glazed letter-paper, tapering from $\frac{1}{8}$ in. to a point, and 2 in. long, at right angles to the magnetized needle. To limit the vibrations of the paper index,


drive two copper pins in the base $\frac{1}{2}$ in, away each side of the index. Place outside the coil a small magnet at right angles to the



coil to keep the paper index in the middle of the two pins; it will then appear as shown in the last diagram.


Domestic Telegraph. — Cut four pieces of bright brass, and join two by soldering with a copper wire 4 in. long, as in fig. 1. Then take the two other pieces and join them in the same manner by a copper wire 2 in. long, as in fig. 2. The wire must be soldered to one side, the two pieces to the left or to the right; solder two more wires; these wires are to go in the screw-cups of the battery. Drill a hole in the centre of each piece of brass, and countersink each hole so that the heads of the screws may be level; now screw the four pieces on a piece of dry wood, as in fig. 3. The size of the brasses should be 1 in. wide, and 1½ in. long. After the wires to convey the electricity are put up, and the telegraph instrument is at the top of the house, and the con-

veyance wires, two in number, are attached to each end of the coil of the instrument, the two ends at the bottom are to be attached to two small handles of brass, as in fig. 4. When a message is sent, the two handles are to be made to touch the right pair of brasses, if the index is meant to turn to the right; if wanted to turn to the left, the handles are to be



put on the left pair. Now perhaps when you put the handles on the right pair, the index will turn to the left; you can remedy this by reversing the battery, i.e., put the positive wire where the negative was, and the negative where the positive was. By the adoption of what is called a code of signals, the deflections of a single index may be made to denote all the

letters of the alphabet. The code for a single index instrument is shown in the following diagram, the number of deflections



of the index to the right and left being made to indicate the letters under which the marks are placed. The deflections of the symbols for each letter commence in the direction of the short marks, and end with the long ones. Thus it will be seen, that to indicate the letter D, the index is deflected to the right once, then to the left once; whilst two deflections, beginning with one to the left, and ending with one to the right, make the letter R.



INDEX.

stries printed in Capitals indicate that several articles relating to the subject named will be found at the reference given.

3as meter, 264. harp, 228. ne, 38. ps, 39. . 192. irilling machine, 28. r journal boxes, 23. tical dial telegraph, 326. safes, 250. n pad, 306. black varnish, 84. dyes, 266. m cementing, 81. m, fresh-water, 240. m fountain, 244. ardening, 9.

chemical, 251.
;, fire, 294.
;, varnishing, 85.
.'s lard oil process, 255.
ws, brazing, 16.
er, simple, 78.
constant, 301.
cast-iron, breaking weight,

ctric, 311. heels, 59. balls, dyeing, 54. ffing, 235. Bisulphide of tin, 101. Black for telescopes, &c., 74. Black Japan varnish, 84. Blacking, 261. Blast engine, 106. Bleaching ivory, 53. Bleaching powder, 26& Blow-pipe, 246, 247. Blow-pipe jointing, 92. Boats, model, steam propeller, 128. Boilers, 105, 106, 127, 128. Bone manure, 262. Book marbling and sprinkling, 32, 48. Boring, 31. Boring cork, 3. Boring-machine, 29. Bowls, cutting out, 53. Brakes, railway, 141. Brass, bronzing, 287. Brass, casting, 93. Brass, lacquering, 90. Brass, melting, 92. Brass, pickling, 93. Brass, silvering, 278. Brass-soldering, 91. Brass tubes, bending, 93. Brazing band-saws, 16. Brewer's pitch substitute, 88.

Bright's electric clock, 160. BRONZING, 284. Brooch stones, cutting, 33. Buckles in sheet-iron, 98.

Camera lucida, 77. Camera obscura, 43. Cameras, dead black, 74. Candles, Roman, 290. Capstan-pumps, hydraulic, 41. Carrier, adjusting, 24. Carvings, wooden, protecting, 184. Case hardening, 96. Castings, brass, 93. Castings, shrinkings, 101. CEMENTS AND GLUES, 79. Centre-bit, 35. Chemical balance, 251. CHEMICAL PROCESSES, &c., 246, Chimney cowls, 187, 188. Chimney lamp, 262. Chlorate of potash, 250. Chronometer escapement, 157. Chronometer oven, 169. Circle, diameter, 174. Cisterns, 194. Clarifying water, 254. Cleaning paint, 185. Cleaning pictures, 199. Cloak peg frame, 192. CLOCKMAKING, 150. Clocks, electro-magnetic, 160, 309. Closet construction, 189. Coal gas, bisulphide of carbon, 261. Collodion filter, 211. Colour vehicle, 88. Colouring maps, 198. Columbia metal, 29. Combustion of oil rags, 250. Composition ornaments, 186, 282. Composition pictures, 222. Condenser, Rhumkorff, 306. Copal varnish, 85. Copper, bronzing, 286. Copper, coating, 94. Copper, electro-gilding, 274. Copper, silvering, 278. Copying ink, 259. Cork-boring, 3. Cork-springs, 42. Cotton photographs, 223.

Cotton waste, 36.
Cotton, waterproofing, 270.
Cowls, chimney, 187, 188.
Crucibles of lime, 250.
Curves, quickening, 5.
Cutting glass, 175, 176.
Cutting microscopic sections, 74.
Cyanide of silver, 204.
Cylinders, Geneva, 168.

Damp on walls, 184. Dead-black for telescopes, &c., 74. Designs on glass, 177. Dials, sun, 171, 173. Diameter of circle, 174. Diamonds, polishing, 47. Distances, ascertaining, 6. Distances, rifle stædia, 148. Domestic telegraph, 329. Door spring, 185. Double photographs, 214. Dovetailing, 180. Drawing, 197. Drawing camera obscura, 43. Drawing on glass, 177. Drawing spirals, 4. Drawing varnishes, 84, 200. Drilling glass, 27. Drilling-machines, 3, 26, 28, 30, Drills, home made, 32. Drills, tempering, 9. Driving-straps, 47. Drowning: a rescue apparatus, 55. Dryers, 88. DYES, 265. Dyeing ivory, 54. Earth batteries, 303.

Earth batteries, 303.
Edge tools, sharpening, 9.
ELECTRICITY, &c., 295.
Electric bell, 311.
Electric clock, 160, 309.
Electric railway signal, 135.
Electro-gilding, 273, 274.
Electrotyping, 270.
Enamel, opaque, 178.
Enamel for card photographs, 212.
Engines, garden, 195.
Engines' powers, 112.
Engine, rotary, 102.

s, transferring to glass,

lal wheel, 175. nt, chronometer, 157. nt, double-roller, 159. nt, four-legged, 154. nt, verge, 150.

11.

; float, 60.

ostrich, dyes, 266.

ry, 202.

vvating, 4.

>.

\$\$, 148.

ons, 294.

I. ing textile fabrics, 270. cs, 289. ister moulds, 202.

otographs, 217.

t battery, 301. lried in natural colours,

screen, 217. ls, 138. or aquarium, 244. nixtures, 219. ights and measures, 1.

ights and measures lish, 86. 14. olish, 88. laster moulds, 202. smelting, 101.

d silver separation, 95.
attery, 317.
eter, 311.
gine, 196, 197.
pipe, 249.
ttor, 49.
ing, 251.
, ABC, 264.
soldering, 91.
water in, 265.
linders, 168.
lver, 100.
lver, polishing, 94.
ector, 109.
270.

GLASS, 175. Glass, cementing, 80. Glass, drawing on, 177. Glass, chimney breakage, 263. Glass-cutting, 175, 176. Glass-designs, 177. Glass, drilling, 27. Glass, gilding, 274. Glass-globes for magnifying glasses, 218. Glass-plates, photographic cleaning, 213. Glass, soluble, 179. Glass, transferring on, 177. Glass, varnishing, 84. Glazers for polishing metals, 97. GLUES, 79 Gold, artificial, 95. Gold, dissolving, 95. Gold, lacquer, 89. Gold, mosaic, 284. Gold powder, 286. Gold size, 286. Governor's steam, 103, 107, 108. Grease, wheel, 148. Grinding pebbles, 33.

Gold powder, 286.
Gold size, 286.
Governor's steam, 103, 107, 16
Grease, wheel, 148.
Grinding pebbles, 33.
Grinding lenses, 60.
Grindstones, 12.
Gum, postage stamp, 82.
Gun-barrels, 149.
Gun-barrels, bronzing, 287.
Gun-cotton, 149.
Gunpowder force, 149.
Gauge for watch hands, 170.
Gypsum, 201.
Gyroscope, 68.

Hair springs, reducing, 165.
Handkerchiefs, photographic, 223.
Hand-press, 21.
Harness blacking, 261.
Harp, Æolian, 228.
Hat-peg frame, 192.
Heights, measuring, 5.
Hinges cutting, 56.
HOROLOGY, 150.
Hot-water pipes' cement, 82.
HOUSE, 184.
Huxley's tappet-pump, 110.
Hydraulic capstan pumps, 41.
Hydraulic ram, 37.

Hydrogen lamp, 263. Hyposulphite of Ammonia, 207.

Indelible pencil writing, 199. Indiarubber, 261, 262. Indiarubber cementing, 79. Incrustation in boilers, 105. Injector, Giffard, 109. INKS, 250. Inks for writing in relief on zinc, Inlaying with mother of pearl, 96. Insects for cases, 237. Instantaneous photography, 204. Instruments, miscellaneous, 3. Instruments, to keep from rust, 78. Insulation, telegraphic, 319. Iron, bronzing, 287. Iron, buckles in sheet, 98. Iron solders, 91. Iron stains, removing, 186. Ivory, bleaching, 53. Ivory, cleaning, 54. Ivory, dyeing, 54. Ivory, softening, 54. Ivory, fictile, 202.

Joiners shooting boards, 184. Journal-boxes alloy, 23.

Kaleidoscope, 57.

LACQUERS, 88. Lamp, chimney, 262. Lamp, hydrogen, 263. Lard oil, refining, 255, Lathe, rose bit, 4. Laughing gas, 251. Lead ores, working, 102. Leakage in smoke-box, 23. Leather, cementing, 79. Leather washers, 35. Leaves, skeletonising, 238. Lenses, cleaning, 22. Lenses, grinding, 60. Lenses' magnifying power, 65. Life-saving apparatus, 55. LIGHTING, 262. Light, artificial, for photography, 215. Lime-crucible, 250.

Lime-process in sugar extraction, 257.
Lime-water, 256.
Linen photographs, 223.
Lock, magnetic, 19.
LOCOMOTIVES, 130.
Lubricant, 250.

Machines, boring, 29. Machines, drilling, 26, 27, 28, 30. Magic lantern photography, 220. Magnesium light, 215. Magnetism, 296. Magnetic Lock, 19. Mainsprings strength, 166. Manure, bone, 262. Map-colouring, 198. Marble imitating, 185. Marble, to remove stains, 188. Marbling books, 48. Marine propulsion, 60, 65. Matches without phosphorus, 249. Measures, French, 1. Measuring distances, 6. Measuring heights, 5. Meek's watch hand gauge, 170. Mercurial pendulum, 163. Mercury, extracting, 100. METALS AND METAL-WORKING, 92. Metals, cementing, 80. Metal glazers, 97. Metals, mixed, 99. Metric system, 1. Micagraphy, 178. Microscope hints, 76. Microscope, wood sections, 74. Mirrors, silvering, 276, 278. Modelling, 200. Mosaic gold, 284. Mother of pearl, inlaying, 96. Mortar, waterproof, 184. Moulding plaster, 202. Moulding small objects, 202. Moulding, to prevent sand sticking, 100. Music, Æolian harp, 228. Music, violins, 230.

Nails, French and English, wire hand, 26. Needle, magnetised, 314. Negatives, reproducing, 222. Nitrate of potash, 253. Nitrate of silver, 209. Norton's well-pump, 45.

Oil for watches, 171.
Olive oil, refining, 254.
Omnibus register, 50.
Organ pipes, gilding, 283.
Ornaments, composition for, 186.
Ostrich feather dyes, 266.
Oxychloride of zinc, 102.

Paint, cleaning, 185. Painters' cream, 201. Painting on glass, 177, 178. Paintings, varnishing, 84. Paper bronzing, 289. Paper varnishing, 85. Paper for transfers, 197. Paper for tracing, 198. Papiér-maché, 49. Paraffin waterproofing, 268. Parchment cleaning, 56. Parkes' plastic moulding, 202. Pebbles, grinding and polishing, 33. Peet's safety-valve, 117. Pencil drawings, preserving, 199. Pencil writing, indelible, 199. Pendulum, compensating, 157. Pendulum, mercurial, 163. Peroxide of nitrogen, 215. Perpetual motion, electric clock, 160. Petroleum stove, 255. Pewter, 99. Pharaoh's serpent, 295. PHOTOGRAPHY, 203. Photographometer, 206. Picture-cleaning, 199. Picture frames, gilding, 279. Picture frames, making, 281. Picture frames, in compo., ornaments, 282. Picture frames, staining, 279. Pillar drilling-machine, 30. Pin, new style, 25. Pinion and rack, 174. Plant preserving, 258. Plaster of Paris, 201. Plaster casts, bronzing, 284. Plaster casts, varnishing, 203.

Plate cleaning, 95. Plate soldering, 91. Plateholder, photographic, 220. Plating, 280. Plating skeleton leaves, 239. Plumbers' solder, 91. Polariscope, 77. Polish, French, 86. Polish, friction, 88. Polishing diamonds, 47. Polishing pebbles, 33. Porcelain cementing, 81. Postage-stamp gum, 82. Potash, chlorate, 250. Potash, nitrate, 253. Power of engines, 112. Preserving plants, 238. Preserving skins, 234. Prince Rupert's drops, 257. Printed cottons, washing, 268. Printers' ink, 258. Printing photographs, 214. Prints, fixing, 211. Prints, varnishing, 200. PROCESSES, MISCELLANEOUS, 3. Pumps, air, 39. Pump, tappet, 110. Pump, deep well, 43. Putty for steam joints, 83. PYROTECHNY, 289.

Quickening curves, 5.

Radii-drawing to inaccessible centres, 48. Rags oily combustion, 250. RAILWAYS AND LOCOMOTIVES, 130. Rain-water, storing, 195. Ram, hydraulic, 37. Ratchet wheels, 52. Registering machine for 'buses, 52. Retouching photographs, 221. Reversing motion in engines, 125. Rhumkorff condenser, 306. Rick cloths, waterproofing, 270. Rifle stadia for distances, 148. Rock-drilling, 27. Rockets, 291, 292, 293. Roman candles, 290. Rose-bit for lathe, 4. Rotary engine, 102.

Rotating magnet, 313. Rupert drops, 25. Rust on instruments, 78.

Sackholder, 46. Safes, alum in, 250. Safety-valves, 112, 117, 118, 120, 121. Saw benches, 13. Sawing machine, 18. Saws, band, brazing, 16. Saws, fret, 14. Screw-driver, 20. Screw-propeller, 67. Sealing wax, 256. Semaphores, 131. Sharpening edge tools, 9. Shooting boards for joiners, 184. Shrinkings of castings, 101. and Halske's insulator, Siemen 321. Signals, Aug 33 Signals, fallway, 130, 135, 139. Silk, blue, dye, 265, 266. Silk photographs, 211. Silver cyanide, 204. Silver dial cleaning, 168. Silver in photography, 207, 208, 209. Silver, hardness, 94. Silver, separating from galena, 95. Silver, soldering, 91. Silver, German, 100. Silvering, brass, 278. Silvering, copper, 178. Silvering, imitation, 283. Silvering globes, &c., 276. Silvering mirrors, 278. Skates, wheeled, 50. Skeleton leaves, 238. Skins, preserving, 234. Slide-valve, 119, 122, 126. Smelting furnace, 101. Smoke-box leakage, 23. Smoky chimney, cowl for, 188. Solders and soldering, 90. Soluble glass, 179. Speculum metal, 100. Spirals, 4, 5. Spirit blow-pipes, 246, 247. Spring for doors, 185.

Springs, cork, 42. Sprinkling book-edges, 32. Stains of nitrate of silver, 217. Stains on marble, to remove, 188. Staining wood, 182. STEAM ENGINE, 102. Steam-joints, cementing, 82. Steam-pipes, cementing, 82. Steam-propeller for model boats, 128. Steel, bronzing, 287. Steel, gilding, 273. Steel, polished, preserving, 97. Steel, soldering, 91. Steel surfaces, preservation, 98. Steel, tempering, 10. Steel welding composition, 96. Stencil-plates, 198. Stereotyping, paper process, 25. Stone cementing, 80. Straps, driving, 47. Straw, to colour black, 267. Stud-box and wrench, 23. Studio photographic design, 224. Stuffing birds, 234. Sugar extraction, lime process, 257. Sulphate of iron preservation, 99. Sun-dial, 171, 173. Superheater and safety valve, 118. Swann's safety valve, 113. Syphon, 38.

T-square, protracting, 10. Tappet-pump, 110. Taps, tempering, 9. Taxidermy, 234. TELEGRAPHY, 314. Telescopes, dead black, 74. Telescopes' stand, 73. Telescopes, making, 71. Tempera, 186. Tempering drills and taps, 9. Tempering steel, 10. Tent, photographic, 227, 228. Textile fabrics, fireproof, 270. Tin bisulphide, 101. Tin lacquer, 89. Tinning, 101. Tinware, solder, 91. Tissue-paper, oiling, 198. Titanium, German, 99.



77 520st 005 LOOT



T49 49

T 49 .A9
The mechanic's friend:

Stanford University Libraries
3 6105 041 644 084

MAY 2 8 1992

STANFORD UNIVERSITY LIBRARIES STANFORD, CALIFORNIA 94305

